




dji Osmo Action 4 Action Camera User Guide

[Home](#) » [DJI](#) » dji Osmo Action 4 Action Camera User Guide 

Contents

- [1 dji Osmo Action 4 Action Camera](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 DJI Mimo App](#)
- [5 Operation](#)
- [6 How To Use](#)
- [7 Caution](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)



dji Osmo Action 4 Action Camera



Product Information

The product is the DJI Osmo Action camera. It is a high-quality action camera designed for capturing various activities and adventures.

Key Features:

- 4K video recording
- Waterproof up to 18 meters
- Built-in stabilization technology
- Easy-to-use interface
- Compatible with the DJI Mimo App

Product Usage Instructions

Step 1: Download DJI Mimo App

To enhance your experience with the DJI Osmo Action camera, download and install the DJI Mimo App. You can find the app at <https://s.dji.com/guide60>.

Step 2: Power On and Basic Settings

Press the power button to turn on the camera. Once turned on, you can access the basic settings.

- **Video Resolution:** The default resolution is set to 1080P30. You can change it according to your preference.
- **Zoom:** The default zoom level is 1.0x. Adjust the zoom level as desired.
- **Auto Power Off:** By default, the camera will turn off after 1 second of inactivity. You can change this setting to your preference.

Step 3: Recording Videos

To start recording videos, follow these steps:

1. Ensure the camera is powered on and in video mode.
2. Press the shutter button to start recording.
3. To stop recording, press the shutter button again.

Step 4: Capturing Photos

To capture photos, follow these steps:

1. Ensure the camera is powered on and in photo mode.
2. Press the shutter button to capture a photo.

Step 5: Contact DJI Support

If you encounter any issues or have questions regarding the DJI Osmo Action camera, feel free to contact DJI Support for assistance. **Contact Details:** [Provide relevant contact information]

Step 6: Subscribe for Updates

To stay informed about the latest updates and information related to the DJI Osmo Action camera, subscribe to DJI's newsletter or follow their social media channels. [Provide relevant subscription and social media links]

DJI Mimo App

<https://s.dji.com/guide60>.


1




<https://s.dji.com/guide60>

Operation


2



3






4





How To Use


5







Caution



WE ARE HERE FOR YOU



Contact
DJI SUPPORT

SUBSCRIBE FOR MORE INFO



<https://www.dji.com/osmo-action-4/downloads>




This content is subject to change without prior notice.



YCBZSS00244202

- DJI and OSMO are trademarks of DJI.
- Copyright © 2023 DJI OSMO All Rights Reserved.

Documents / Resources

	<p>dji Osmo Action 4 Action Camera [pdf] User Guide</p> <p>Osmo Action 4 Action Camera, Osmo Action 4, Action Camera, Camera</p>
---	--