




DOC JOHNSON I-MX-0801-05 Body Extensions Instruction Manual

[Home](#) » [DOC JOHNSON](#) » DOC JOHNSON I-MX-0801-05 Body Extensions Instruction Manual 

Contents

- [1 DOC JOHNSON I-MX-0801-05 Body Extensions](#)
- [2 Cleaning and Storage:](#)
- [3 To Assemble Product for Use:](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)



DOC JOHNSON I-MX-0801-05 Body Extensions



Cleaning and Storage:

- Disassemble harness completely by pressing down on attachment tabs to separate it from the silicone section, and undo the snaps to remove the elastic waistband
- Clean each piece according to individual instructions
- **Elastic Waistband:** Hand wash with mild soap and warm water and lay flat to dry. Silicone
- **Vibrating Harness:** Spray with Doc Johnson Toy Cleaner or wash with mild soap and warm water. Do not submerge
- **Hollow Silicone Attachment:** Sprayed with Doc Johnson Toy Cleaner, wash with mild soap and warm water, boil for 5-10 minutes, or clean in top rack of dishwasher
- Allow each piece to air-dry completely before storing separately from other toys in a cool, dry place. Use with water-based lubricant/glide. Doc Johnson Toy Cleaner sold separately.

To Assemble Product for Use:

- Make sure the tabs on the base of your silicone attachment are aligned to the notches in the silicone front piece of your harness.
- Place the attachment behind the silicone front piece and push the tip of the attachment through the large hole

(for larger attachments, insert through front of harness).

- Press the attachment's tabs into the front piece's grooves until they push all the way through and lock in place
- Use multiple snaps to adjust harness to your ideal fit.



To Power Vibrations On:

On Silicone Harness:

1. Press and hold (C) until the LED button lights up.
2. Press (C) again to change vibration pattern.

On Wireless Remote:

3. After completing step 2, press (C) to power on wireless remote.

4. press NI to change vibration pattern.

- Product can be used with or without wireless remote.

To Power Vibrations Off:


On Wireless R.emote:

Press to power off vibrations TEMPORARILY.


On Silicone Harness:

Press and hold to power off product AFTER USE. Make sure to power off both wireless remote and silicone harness after use.

DOCJOHNSON®

Die #: 11" x 8.5"	Date: 10/12/2020	Artist: LMYOUNG
Item #: INS-0801-00	Substrate: Paper	
<div></div> <div>INKS: CMYK</div>		
COATING:		
TREATMENTS:		
* PLEASE REFER TO LAYERS IN THE FILES FOR TREATMENTS *		

Documents / Resources

	<p>DOC JOHNSON I-MX-0801-05 Body Extensions [pdf] Instruction Manual I-MX-0801-05, IMX080105, 2AVJ9-I-MX-0801-05, 2AVJ9IMX080105, I-MX-0801-05 Body Extensions, I-MX-0801-05, Body Extensions</p>
---	---