

# **DOMETIC DM50C D Drawer Minibar Instruction Manual**

Home » Dometic » DOMETIC DM50C D Drawer Minibar Instruction Manual

DOMETIC DM50C D Drawer Minibar



law. The underlying technical design and the products contained herein may be protected by design, patent or pending patent. The trademarks mentioned in this manual belong to Dometic Sweden AB. All rights are reserved.

### Explanation of symbols

Please read these instructions carefully and follow all instructions, guidelines, and warnings included in this product manual in order to ensure that you install, use, and maintain the product properly at all times. These instructions MUST stay with this product.

By using the product, you hereby confirm that you have read all instructions, guidelines, and warnings carefully and that you understand and agree to abide by the terms and conditions as set forth herein. You agree to use this product only for the intended purpose and application and in accordance with the instructions, guidelines, and warnings as set forth in this product manual as well as in accordance with all applicable laws and regulations. A failure to read and follow the instructions and warnings set forth herein may result in an injury to yourself and others, damage to your product or damage to other property in the vicinity. This product manual, including the instructions, guidelines, and warnings, and related documentation, may be subject to changes and updates. For up-to-date product information, please visit documents.dometic.com.

# **Contents** 1 1 Explanation of symbols 2 2 Safety instructions 2.1 2.1 General safety 2.2 2.2 Operating the minibar safely 3 3 Scope of delivery 4 4 Intended use 5 5 Technical description 5.1 5.1 Description of the device 6 6 Installation 6.1 6.1 Notes on mounting into furniture 6.2 6.2 Mounting the minibar into a piece of furniture 6.3 6.3 Connecting the minibar electrically 6.4 6.4 Mounting hotel's own door decor (DM50C F only) 7 7 Operation 7.1 7.1 Saving energy 7.2 7.2 Using the minibar 7.3 7.3 Setting the temperature 8 8 Cleaning and maintenance 9 9 Troubleshooting 10 10 Warranty 10.1 10.1 United States and Canada 10.2 10.2 All Other Regions 11 11 Disposal 12 12 Technical data 13 Documents / Resources 13.1 References

## 1 Explanation of symbols



### DANGER!

**Safety instruction:** Indicates a hazardous situation that, if not avoided, will result in death or serious injury.



## WARNING!

**Safety instruction:** Indicates a hazardous situation that, if not avoided, could result in death or serious injury.



### **CAUTION!**

**Safety instruction:** Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.



#### NOTICE!

Indicates a situation that, if not avoided, can result in property damage.



#### NOTE

Supplementary information for operating the product.

## 2 Safety instructions

### 2.1 General safety

△ WARNING! Failure to obey these warnings could result in death or serious injury. Electrocution hazard

- Ensure that the minibar has been installed by a qualified technician in accordance with the Dometic installation manual.
- Do not operate the minibar if it is visibly damaged.
- If this minibar's power cable is damaged, it must be replaced by the manufacturer, service agent or a similarly qualified person in order to prevent safety hazards.
- This minibar may only be repaired by qualified personnel. Inadequate repairs may cause serious hazards.
- When positioning the minibar, ensure the supply cord is not trapped or damaged.
- Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- Plug the device to sockets that ensure proper connection especially when the device needs to be earthed.

## Fire hazard

- After installation, it must still be possible to disconnect the minibar from the supply mains. This may be achieved by having the plug accessible or by incorporating a switch in the fixed wiring according to the wiring rules.
- Keep ventilation openings, in the minibar enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit. Do not open the refrigerant circuit under any circumstances.
- Do not use electrical devices inside the minibar unless they are recommended by the manufacturer for that purpose.

## **Explosion hazard**

Do not store any explosive substances, such as spray cans with propellants, in the minibar.

## Health hazard

- This minibar can be used by children aged from 8 years and above and persons with reduced physical, sensory
  or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction
  concerning use of the minibar in a safe way and understand the hazards involved.
- Children shall not play with the minibar.
- Cleaning and user maintenance shall not be made by children without supervision.
- Children aged from 3 to 8 years are allowed to load and unload the minibar.

△ CAUTION! Failure to obey these cautions could result in minor or moderate injury. Risk of crushing

• Do not put your fingers into the hinge.

## **Health hazard**

- Foodstuff may only be stored in its original packaging or in suitable containers.
  - NOTICE! Damage hazard
- Check that the voltage specification on the type plate is the same as that of the power supply.
- The minibar is not suitable for storing substances which are caustic or contain solvents.
- The insulation of the cooling device contains flammable cyclopentane and requires special disposal procedures. Deliver the cooling device at the end of its life-cycle to an appropriate recycling center.
- Keep the drainage outlet clean at all times.
- · Only carry the minibar upright.

## 2.2 Operating the minibar safely

 $\triangle$  DANGER! Failure to obey these warnings will result in death or serious injury. Electrocution hazard

• Do not touch exposed cables with your bare hands.

 $\triangle$  CAUTION! Failure to obey these cautions could result in minor or moderate injury. Electrocution hazard

Before starting the minibar, ensure that the power supply line and the plug are dry.

#### Health hazard

- Make sure that you only put items in the minibar which may be chilled at the selected temperature.
- Food may only be stored in its original packaging or in suitable containers.
- Opening the door for long periods can cause significant increase of the temperature in the compartments of the minibar.
- Clean regularly surfaces that can come in contact with food and accessible drainage systems.
- If the minibar is left empty for long periods: Switch off the minibar. Defrost the minibar. Clean and dry the minibar. Leave the door open to prevent mould developing within the minibar.
  - NOTICE! Damage hazard · Do not use electrical devices inside the minibar unless they are recommended by the manufacturer for that purpose.
- Do not place it near naked flames or other heat sources (heaters, direct sunlight, gas ovens etc.).
- · Never immerse the minibar in water.
- Protect the minibar and the cable against heat and moisture.

• Make sure that foodstuffs do not touch the walls of the cooling area.

# 3 Scope of delivery

The following main alternatives are obtainable:

- Minibar DM50C D with door panel, without lock
- Minibar DM50C D with door panel, with lock
- Minibar DM50C F without door panel, without lock
- Minibar DM50C F without door panel, with lock

Quantity	Description	
1	Minibar	
1	AC connection cable	
4	Screw ø 4 x 45 mm (ø 0.16 x 1.77 in.,installation)	
4	Plug (Installation)	
1	Handle	DM50C D only
2	Plug (Handle installation)	DM 50C D only
2	Plug (Wooden panel)	DM 50C F wooden version only
1	Lock decor (Wooden panel)	DM 50C F wooden version with lock only
2	Key	Lock version only
1	Installation and Operating manual	

## 4 Intended use

The refrigeration appliance (also referred to as minibar) is intended to be used in household and similar applications such as:

- · Staff kitchens in stores, offices and other work areas
- Farmhouses
- By clients in hotels, motels and other residential type environments
- · Bed and breakfast type environments
- · Catering and similar non-retail applications

The minibar is not suitable for installation in caravans or mobile homes.

The minibar is intended for installation in a piece of cabinetry or an installation niche.

The minibar is designed exclusively for cooling and storing of beverages and foods in closed containers.

The minibar is not suitable for storing medicine or freezing foodstuffs.

This minibar is only suitable for the intended purpose and application in accordance with these instructions.

This manual provides information that is necessary for proper installation and/or operation of the minibar. Poor

installation and/or improper operating or maintenance will result in unsatisfactory performance and a possible failure.

The manufacturer accepts no liability for any injury or damage to the product resulting from:

- · Incorrect assembly or connection, including excess voltage
- Incorrect maintenance or use of spare parts other than original spare parts provided by the manufacturer
- · Alterations to the product without express permission from the manufacturer
- Use for purposes other than those described in this manual

Dometic reserves the right to change product appearance and product specifications.

# 5 Technical description

The minibar has a main drawer for bottles and cans as well as a mini drawer for miniatures and snacks. The main drawer has room for 23 bottles with a maximum height of 27.5 cm (10.8 in.).


The minibar DM50C D comes with a anthracite panel and pull handle.

The minibar DM50C F is delivered without panel and is prepared for fitting the hotel's own door decor.


A lock is optionally available.

#### 5.1 Description of the device

## Front panel




Item	Description
1	Lock (optional)
2	Handle (DM 50C D only)
3	Door panel (DM 50C D only)




Item	Description
1	Stopper
2	AC connection cable
3	Drip tray

Control panel (inside the device)




Item	Description
1	Lamp
2	Error LED
3	Status LED
4	Setting button

# Main drawer




Item	Description
1	Small bottle holder
2	Wide divider
3	Separator
4	Bottle finger
5	Small divider

# Mini drawer



Item	Description
1	Rotatable divider
2	Miniature bottle holder

# **Dimensions**



# 6 Installation

## **△ WARNING!** Fire hazard

- Damage to the refrigerant circuit at the back of the minibar causes a fire hazard as the cooling agent is highly flammable. To avoid a damage to the refrigerant circuit due to instability of the minibar, always fix the minibar in accordance with the instructions.
- When positioning the minibar, ensure the supply cord is not trapped or damaged.
- Do not locate multiple portable socket-outlets or portable power supplies at the rear of the minibar.
- The AC plug must remain accessible after installation to allow for disconnection from the AC power supply.

#### 6.1 Notes on mounting into furniture

You can mount the minibar in four ways into furniture. Choose your favored alternative according to the following figure (page 15).

Observe the following:


• The cut-out dimensions H x W x D are:

DM50C D:  $443 \times 570 \times 490 \text{ mm}$  (17.4 x 22.4 x 19.3 in.) DM50C F:  $443 \times 570 \times (488 + d) \text{ mm}$  (17.4 x 22.4 x (19.2 + d) in.)


d is the thickness of the hotel's own decor

- The clearance between the minibar's back and the furniture wall should be 10 mm (0.4 in.) or more.
- The ventilation openings for the chosen alternative have to be produced as shown in following figure (page 15).
- Air passing through the inlet air duct must not be heated by any heat sources (heaters, direct sunlight, gas ovens etc.).

NOTE The minibar must be leveled carefully to ensure proper function.



# 6.2 Mounting the minibar into a piece of furniture



Item	Description
1	Screw ø 4 x 45 mm (ø 0.16 x 1.77 in.)
2	Plug

- 1. Fasten the minibar with the four screws (1).
- 2. Insert the four plugs (2) into the boring.

### 6.3 Connecting the minibar electrically

- ➤ Connect the AC connection cable to the AC mains supply.
- ✓ The status LED lights up.
- ✓ The minibar starts cooling the interior.

### 6.4 Mounting hotel's own door decor (DM50C F only)

The hotel's own door decor has to comply with the following requirements:

- Maximum weight: 4 kg (8.8 lb.)
- Maximum thickness: 18 mm (0.7 in.)
- > Fasten the decor with four screws.

# Mounting the lock (lock version only)

- 1. Drill a hole with a diameter of 35 mm (1.4 in.) into the decor.
- 2. Mount the lock together with the lock decor.

## 7 Operation

### 7.1 Saving energy

- Only open the minibar as often and for as long as necessary.
- Avoid unnecessarily low temperature settings.
- For optimal energy consumption, position the shelves and drawers according to their position on delivery.
- On a regularly basis, make sure the door seal still fits properly.
- Clean dust and dirt from the condenser at regular intervals.


#### 7.2 Using the minibar

The minibar starts cooling when connected to power. During normal operation the Status LED is glowing. If an error occurs the Error LED is blinking (see chapter "Troubleshooting" on page 20).

#### **SLEEP mode**

In "SLEEP" mode the compressor stops running, and the minibar stops cooling.

"SLEEP" mode will only last 10 hours. The minibar will automatically resume normal cooling mode after 10 hours. If the power supply is disconnected during the "SLEEP" mode and then resumed, the status of the "SLEEP" mode will not be affected.



# Entering "SLEEP" mode:

- ➤ Press briefly the setting button (1).
- ✓ The internal lamp (3) turns off, the status LED (2) is still on.

The minibar stops cooling.

# Leaving "SLEEP" mode:

- ➤ Press briefly the setting button (1).
- ✓ The internal lamp (3) turns on, the status LED (2) is still on.


The minibar resumes cooling.

## 7.3 Setting the temperature

To avoid food waste, note the following:

- Keep temperature fluctuation as low as possible. Only open the minibar as often and for as long as necessary. Store the foodstuff in such a way that the air can still circulate well.
- The minibar is equipped with an automatic temperature regulation function. Select the average of the possible temperature values.
- Adjust the temperature to the quantity and type of the foodstuff.

The minibar is set by default to a cooling temperature of 7 °C (47 °F) at an ambient temperature of 25 °C (77 °F).



You can use the setting button (1) to set the cooling temperature to one of three values: 4 °C, 7 °C and 12 °C (39 °F, 45 °F and 54 °F).

Thereby the temperature will be changed in the order 4 °C ... 7 °C ... 12 °C ... 4 °C (39 °F ... 45 °F ... 54 °F ... 39 °F) etc.

- 1. Press the setting button (1) and keep it pressed for 3 s, until the lamp (2) starts to blink.
- 2. Press immediately the setting button (1) again.
- ✓ The lamp (2) indicates the setting temperature:
- 4 °C (39 °F): the lamp flashes five times in three intervals
- 7 °C (45 °F): the lamp flashes three times in three intervals
- 12 °C (54 °F): the lamp flashes once in three intervals

NOTE The minibar sets the cooling temperature automatically to 7 °C (45 °F), when it is connected to a power source.

## 8 Cleaning and maintenance

△ WARNING! Electrocution hazard Always disconnect the device from the power supply before you clean and service it.

- NOTICE! Damage hazard
- Never clean the cooler under running water or in dish water.
- Do not use abrasive cleaning agents or hard objects during cleaning as these can damage the cooler.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
  - ➤ Occasionally clean the device interior and exterior with a damp cloth.

## 9 Troubleshooting

Fault	Possible cause	Suggested remedy
Device does not function, Status LED	No voltage present in the AC socket.	➤ Try using another power socket.
does not glow.	Power circuitry is defective.	This can only be repaired by an authorized service agent.
The device does not cool (plug is inserted, Status LED glows).	Defective compressor	This can only be repaired by an authorized service agent.
The Error LED flashes once per second.	Temperature sensor is defective.	This can only be repaired by an authorized service agent.
Device does not cool sufficiently, Status LED	Defective compressor	This can only be repaired by an authorized service agent.
glows, Error LED does not glow.	Poor ventilation	<ul> <li>Check the ventilation.</li> <li>Clean the filter underneath the device.</li> </ul>

# 10 Warranty

Refer to the sections below for information about warranty and warranty support in the US, Canada, and all other regions.

### 10.1 United States and Canada

LIMITED WARRANTY AVAILABLE AT

DOMETIC.COM

IF YOU HAVE QUESTIONS, OR WANT TO OBTAIN A COPY OF THE LIMITED WARRANTY FREE OF CHARGE, CONTACT:

DOMETIC CORPORATION CUSTOMER SUPPORT CENTER 5155 VERDANT DRIVE ELKHART, INDIANA 46516

1-800-544-4881

customersupportcenter@dometic.com

#### 10.2 All Other Regions

The statutory warranty period applies. If the product is defective, please contact the manufacturer's branch in your region (dometic.com/dealer) or your retailer.

For repair and warranty processing, please include the following documents when you send in the device:

- A copy of the receipt with purchasing date
- · A reason for the claim or description of the fault

Note that self-repair or nonprofessional repair can have safety consequences and might void the warranty.

## 11 Disposal



Recycling products with non-replaceable batteries, rechargeable batteries, or light sources

- ➤ Dispose the product in accordance with all applicable regulations.
- ➤ The product can be disposed free of charge.

# 12 Technical data

	DM 50C D	DM50C F
Voltage:	120 V∼ <mark>,</mark> 60 Hz	
Cooling capacity:	max. 40 °C (104 °F) below ambient temperature adjustable in three steps: 4 °C, 7 °C, 12 °C (39 °F, 45 °F, 54 °F)	
Total volume:	501(52.8	US liq.qt.)
Maximum internal storage load:	31 kg (68.3 lb.)	
Intended ambient temperature use:	+16 °C to +32 °C (+61 °F to +90 °F)	
Noise emission:	60 Hz = 30.55 dB(A)	
Dimensions main drawer W x D x H:	423 x 372 x 275 mm (16.7 x 14.6 x 10.8 in.)	
Dimensions mini drawer W x D x H:	159 x 285 x 88 mm (6.3 x 11.2 x 3.5 in.)	
Dimensions W x D x H:	550 x 508 x 423 mm (21.7 x 20 x 16.7 in.)	550 x 478 x 423 mm (21.7 x 18.8 x 16.7 in.)
Weight:	22.0 kg (48.5 lb.)	22.6 kg (49.8 lb.)
Refrigerant:	R600a	
Refrigerant quantity:	17 g (0.6 oz.)	
Inspection/certification:	TÜVRhelnland c us	

Follow EPA use conditions.



YOUR LOCAL DEALER dometic.com/dealer

YOUR LOCAL SUPPORT dometic.com/contact

YOUR LOCAL SALES OFFICE dometic.com/sales-offices

A complete list of Dometic companies, which comprise the Dometic group, can be found in the public filings of: **DOMETIC GROUP AB** Hemvarnsgatan 15 SE-17154 Solan Sweden

## **Documents / Resources**



**DOMETIC DM50C D Drawer Minibar** [pdf] Instruction Manual DM50C D, DM50C D Drawer Minibar, Drawer Minibar, Minibar

## References

- Outdoor Adventure Starts Here | This Way Out | Dometic USA
- → Find a Dealer | Dometic Australia
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.