



# Dongguan Jin Wen Hua Digital Technology L16 Beat Driven Light Show 50W Bluetooth Speaker User Guide

[Home](#) » [Dongguan Jin Wen Hua Digital Technology](#) » Dongguan Jin Wen Hua Digital Technology L16 Beat Driven Light Show 50W Bluetooth Speaker User Guide 

## Contents

- [1 Dongguan Jin Wen Hua Digital Technology L16 Beat Driven Light Show 50W Bluetooth Speaker](#)
- [2 Introduction](#)
- [3 Spacification](#)
- [4 Control Buttons](#)
- [5 Using your speaker](#)
- [6 Charging your speaker](#)
- [7 Maintenance and Care](#)
- [8 One Year Warranty](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)
- [10 Related Posts](#)




# Dongguan Jin Wen Hua Digital Technology L16 Beat Driven Light Show 50W Bluetooth Speaker



## Introduction

Please fully charge the product before initial use











## What you get




## Spacification

Bluetooth NWAomrkeing Range	MV5u0sic(ACuSBro)ra >80 feet
Output Power	5(300WWs ubw oofoe +2*1DW mid/tweet er d ive s)
SLiNgRhting	3>75dB  Modes
Charging Input	T pe-CDC 5V/ 2A
Batter	y2x4000mAh 3.7V 21700
ChargYing Time	35 Hrs

## Control Buttons


Music Control		
	Short press	Play/Pause
	Short press	Volume up
	Short press	Volume down
	Short press	Next track
	Short press	Previous track
Call Control		
	Short press	Answer / End call
	Long press	Reject call
Lighting Control		
	Short press	Switch Lighting Mode
	Long press	Synchronize 2 speakers on 1 device
Bluetooth Control		
	Simultaneously Long Press	Disconnect Bluetooth device and re-enter pairing mode

## Using your speaker




## PAIRING A BLUETOOTH DEVICE

When turned on, the speaker will automatically enter pairing mode. Find “MusicAurora” and choose to connect on your device.



The \_speaker will automatically connect to the last connected device if available. If not, the speaker will enter pairing mode. 0 Having connection problems? Use your Bluetooth device’s Bluetooth settings to remove/unpair all previously paired “MusicAurora” Bluetooth speakers and ensure they are less than 1 meter away from each other. Then try pairing again 0 To get the best sound quality, make sure there is a clear line of sight between the connected device and your speaker.

## CONNECTING VIA THE AUX JACK



## PLAYING MUSIC FROM A MEMORY CARD




## PAIRING TWO MUSICAURORA SPEAKERS

Place the two MusicAurora speakers within 10 meters of each other.

1. Turn both speakers on by long-pressing C) respectively.
2. Long press Q on one of your speakers, and you will hear a prompt tone from the speaker. Then both speakers will enter TWS pairing mode.
3. On your Bluetooth device, turn on Bluetooth, tap “Musi


aurora” and pair. When the TWS pairing is successful, you will also hear a prompt tone. **Note** 1) The indicator on the primary speaker will glow solid blue , while that of the secondary speaker will flash every 5 seconds. 2) The primary speaker will be played as the left channel, while the secondary speaker will be played as the right channel.



- When you turn the speakers on the next time, they will automatically try to reconnect to your Bluetooth device.
- To disconnect your Bluetooth device, long press+ and -on the speaker at the same time



## Charging your speaker



## Maintenance and Care

- Before using your speaker, inspect the ports to make sure that they are clear of dust and debris before charging
- Use a soft cloth to clean your speaker. Never use any harsh chemicals or detergents. Make sure your speaker is dry before charging
- When your speaker is not in use, it should be stored in a cool, dry place.
- Never tug or yank on the USB charging cable while it is connected to your speaker. Connect and disconnect cables as carefully as possible
- Never expose your speaker to high temperatures or extreme cold
- Please recycle or dispose of your speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information


## One Year Warranty

- ZUCCHERO products are covered by a 12-month limited warranty, starting from the date of purchase. This warranty is not transferable and applies only to the original consumer purchaser.
  - For quality-related issues, KUCCHERO will, at its sole option, repair or replace any KUCCHERO products that malfunction due to defective parts or workmanship at no charge to you
- Not Covered Under Warranty:**
- Damage from outside sources
  - Damage from misuse of products (including, but not limited to: falls, extreme temperatures, water, operating

devices improperly, incorrect connections, incorrect battery use)

- Damage caused by accident, improper care, negligence, excessive wear, and tear, or impropo installation or assembly cont ary to any written installation instruction
- Items that have expired their warranty period
- Non-quality-related issues (after 30

## Documents / Resources

	<a href="#">Dongguan Jin Wen Hua Digital Technology L16 Beat Driven Light Show 50W Bluetooth Speaker</a> [pdf] User Guide L16, 2AFSG-L16, 2AFSGL16, L16 Beat Driven Light Show 50W Bluetooth Speaker, Beat Driven Light Show 50W Bluetooth Speaker, 50W Bluetooth Speaker, Bluetooth Speaker, Speaker
---	--

## References

-  [ERO.com](#)

Manuals+.