



Dongguan Together Electronic P303B Game Controller User Guide

[Home](#) » [Dongguan Together Electronic](#) » Dongguan Together Electronic P303B Game Controller User Guide 

Dongguan Together Electronic P303B Game Controller User Guide

Contents

- [1 PACK CONTENTS](#)
- [2 PRODUCT FEATURES](#)
- [3 HINTS](#)
- [4 2 YEARS GUARANTEE](#)
- [5 FCC STATEMENT](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

PACK CONTENTS

- 1x Control Pad Bluetooth® for PS3™.
- 1x USB Cable.
- 1x Instructions Manual.

PRODUCT FEATURES

The Control Pad Bluetooth® for PS3™ provides the most intuitive game play experience with pressure sensors in each action button and the inclusion of the highly sensitive SIXAXIS™ motion sensing technology. Each hit, crash and explosion is more realistic when the user feels the rumble right in the palm of their hand. It can even detect natural movements for real-time and high precision interactive play, acting as a natural extension of the user's body. The Control Pad utilizes Bluetooth® technology for wireless game play and the controller's USB cable to seamlessly and automatically charge the controller through the PS3™ console at anytime. By integrating all of these features into the popular PS3™ controller design, the controller with DUALSHOCK™ technology will further enhance the advanced game play experience only available on the P53™ console.

- **Pressure-sensitive buttons**

Feel the controller vibrating with each hit, crash or explosion.

- **SIXAXIS™ highly sensitive motion technology.**

Your natural movements become part of the action. And the controller becomes a natural extension of your body. The SIXAXIS™ motion-sensing system allows users to maneuver the controller itself. With this system, sensors read when a player angles, tilts, thrusts, or pulls the controller, all in real-time and with high precision.

- **Bluetooth® technology.**

No wires. With the PS3® Bluetooth® technology you can play completely untethered.

- **Multiplayer gaming.**

Connect up to seven wireless controllers at one once for serious multiplayer gaming.

- **Charging**

Charge the Control Pad Bluetooth® with the PS3™ console using the USB cable. And you can even plug it during gameplay, so you'll never miss a beat.

CONTROLLER CONNECTION AND SETUP

To use the Control Pad Bluetooth® for PS3™ you must first register or “pair” the controller with the PS3™ console and assign a number to the controller.

1. **STEP 1:** Pair the system and the controller. When using the controller for first time or when using with a different PS3™ console you must first pair the devices. If you turn on the console and connect the controller using a USB cable and press the PS button, the pairing will be completed automatically. And then you can unplug USB cable from the PS3™ console, you can enjoy the game with the controller through Bluetooth® technology.
2. **STEP 2:** Assign a controller number. Every time the console is turned on, a number must be assigned to the controller. Press the PS button, all of port indicators flash. When the controller has been assigned a number, the port indicators for the assigned number turn solid red.

You can connect up to 7 controllers at one time. The controller number is shown by the number above the port indicators. For numbers 5-7, add the numbers of the lit indicators.

HINTS

- Pairing and assigning controller numbers can only be done when the console is turned on (power indicator is lit solid green).
- When a paired controller is used with another PS3™ console, the pairing with the original system is cleared. Pair the controller with the console again if the controller has been used with another console.
- If the controller or the console is turned off, the port indicators on the controller will turn off and the assigned number will be cleared.

Attention: Not appropriate for children under 8 years old.



2 YEARS GUARANTEE

Guarantee covers material and manufacturing defects.

PlayStation, PS3, Sixaxis and DualShock are registered trademarks of SONY". This product is not licensed, sold or promoted by SONY or its agents. All the trademarks are the registered property of their respective companies. Imported by INDECA BUSINESS S.A. Madrid (Spain). **CIF:** A- 83494666. This product is alarmed and can only be deactivated at the till point.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Dongguan Together Electronic CO.,LTD


501Room,5F 1B 81# Dapantian road ,Dalingshan Town Dongguan city Guangdong Province

Wireless game controller

Model: P303B



Documents / Resources

	Dongguan Together Electronic P303B Game Controller [pdf] User Guide P303B, 2A4LP-P303B, 2A4LPP303B, P303B Game Controller, Game Controller, Controller
---	---

[Manuals+](#).