



Dongguan Wansheng Technology Q30-I Bluetooth Karaoke Microphone User Manual

[Home](#) » [Dongguan Wansheng Technology](#) » Dongguan Wansheng Technology Q30-I Bluetooth Karaoke Microphone User Manual 

Wireless Karaoke Microphone & Speaker



Read the manual carefully before using it

Contents

- [1 Structure](#)
- [2 Function Instruction](#)
- [3 Operation](#)
- [4 Charging](#)
- [5 Warranty Card](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Structure



1. Power on / Power off Long press for power on / power off
2. Mic Volume adjustment: Increasing / Decreasing the Mic volume
3. Echo Volume adjustment: Increasing / Decreasing the Echo Volume
4. Music Volume adjustment: Increasing / Decreasing the music volume
5. Previous: press to play the previous song
6. Next: Press to play the next song
7. Mode/Vocal remover: Short Press to change the mode, Long press for Vocal remover on/off
8. Play / Pause: Press to play/pause
9. Magic Sound: Press to change the special sound

Function Instruction

Use TF Card Use Earphone (When you would not want others to hear the song you sing, you can wear headphones and enjoy yourself) As Bluetooth speaker connected with the mobile phone

Accessories



Accessories

Operation

A: Bluetooth Mode (Sing with Bluetooth microphone)

1. Turn on the microphone, a blue light will be on and a sound will indicate that the Bluetooth device is ready to

pair.

2. Search bluetooth ID "K11" on mobile phone / tablet / PC and connect.

Note: It may promote a password which by default is 0000, On connecting successfully there will be a sound alert.

3. Open any Karaoke APP or select music file from your device music player, and adjust your device accordingly.
4. Adjust K11's Volume, Echo and Music.
5. Sing along

Note: If you want K11 as a Bluetooth speaker, turn off K11's echo and volume. Bluetooth has a memory function, when the mobile phone is restarted, it can be connected automatically.

Under Bluetooth mode, K11 does not support some Karaoke APP/software on apple's IOS devices.

B: Wired Mode Singing recording same time function)

1. Download any karaoke APP/software on your mobile phone
2. Turn on K11
3. Connect K11 and mobile phone with Audio cable.
4. Open karaoke APP to choose songs and sing.
5. Record the song as per the instructions on the karaoke APP.

Note: Bluetooth function must be disconnected

Problem	Reason	Solution
Power indicator is not on	Battery run out Charging cable is not plugged in properly The charging cable is faulty	Charge microphone Plug-in charging cable properly Replace the charging cable
without sound	Not powered on Volume is turned off	Power on Turn on the volume
Without echo	Echo is turned off	Turn on the echo effect
Noise when singing or recording	Environment noise Mobile phone signal interference	Choose a quiet place Make microphone and mobile phone at a proper distance
The recording is not good	Not compatible with certain mobile phones Mobile phone's sound handling chip is not good	Re-power mobile phone Charge another mobile phone

Under Bluetooth mode, music is not played continuously	The distance between the microphone and mobile phone is too long Obstacle between microphone and mobile phone	Reduce the distance Avoid obstacle
Music volume is low	Mobile phone's volume is low Choose another music file with Volume of the music file is a low high volume	Turn up mobile phone volume
Bluetooth not getting connected	The distance between the microphone and mobile phone is very long Obstacle between microphone and mobile phone Be connected by another mobile phone/tablet/pc	Reduce the distance Avoid obstacle Disconnect the devices
Music playback distortion under Bluetooth mode Microphone with low power	Volume is too high	Turn down mobile phone volume Charge microphone
APP karaoke software on Apple IOS system does not work with microphone Bluetooth mode	APP karaoke software under the IOS system does not support Bluetooth mode	Choose music player APP

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RP warning for Portable device: The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Charging

1. When the battery is too low, the product will shut down automatically
2. Charging by the USB charging cable, Red light indicates that it is undercharging.
3. In normal condition, 3-4 hours charging required, When it finished, the red light will turn off.
4. In normal conditions, Using time will be 3-4 hours

Audio Monitoring: Capacitor
Output: 5W (Speaker output)
Frequency Range: 100Hz – 10 KHz
SPL: >115db 1KHz THD<1%
Reverberation: Echo Battery: Built-in Lithium 18650
Battery Capacity: 1200mAh
Charging Supply: DC 5V
Accessories: Charging Cable

1. A One-year warranty is from the date of original retail purchase. If there is a quality problem within the following period, the customer can get a return & refund, exchange, and repair service.
Within 7 days, return & refund, exchange, or repair.
Within 15 days, exchange or repair.
Within one year, repair (but component material is charged)
2. Keep “Warranty Card” well, it is essential evidence for a warrant.
3. To obtain warranty service, call the dealers where this product was sold. The dealer will offer all services for the stand of the seller, or pass on feedback to it.
4. The following condition without one year warrant:
 - (1) Abusing use
 - (2) Change or modifications to this product not authorized by the seller
 - (3) Warranty card is modified The final explanation belongs to the seller.

Warranty Card

Model No:	
Date of purchase:	
Dealer / Agent:	
Invoice Date :	
Buyer's Tel:	
Buyer's	
Name:	
Postcode-	



Documents / Resources



[Dongguan Wansheng Technology Q30-I Bluetooth Karaoke Microphone](#) [pdf] User Manual
Q30-I, Q30I, 2A2C8Q30-I, 2A2C8Q30I, Q30-I Bluetooth Karaoke Microphone, Bluetooth Karao
ke Microphone, Karaoke Microphone