



Dongguan Wireless Keyboard and Mouse Combos User Manual

[Home](#) » [Dongguan](#) » Dongguan Wireless Keyboard and Mouse Combos User Manual 

Dongguan Wireless Keyboard and Mouse Combos User Manual



INSTRUCTIONS FOR USE

- 1. Take out the keyboard and mouse from the box, and take out the receiver from the mouse battery compartment;
- 2. Insert a 1.5V AAA dry battery into the keyboard with the correct polarity;
- 3. Insert a 1.5V AA dry battery into the mouse with the correct polarity;
- 4. Insert the receiver into the USB port of the computer;
- 5. Wait for the computer to automatically install the driver and start using it.

FN-F1	FN-F2	FN-F3	FN-F4	FN-F5	FN-F6
Multimedia player	Volume down	Volume up	Mute	Previous song	Next song
FN-F7	FN-F8	FN-F9	FN-F10	FN-F11	FN-F12
Play/pause	Stop	Home	Mail	MY computer	Favorites

Features

1. The mouse and keyboard share a common receiver, and the receiver is in the battery compartment at the bottom of the mouse.
2. Adjustable mouse DPI levels: 800-1200-1600 (default setting is 1200).
3. It has automatic Sleep mode and Wake up mode. When the mouse hasn't been used for 10 min, it will enter sleep mode, press any button to wake up the mouse.

Contents

[1 Connection Error Solution](#)

[2 Documents / Resources](#)

[3 Related Posts](#)


Connection Error Solution

Keyboard



1. Remove the battery from the keyboard and the receiver on the computer
2. Reinsert the battery into the keyboard and reinsert the receiver into the computer jack.
3. At a distance of 20 cm from the receiver, press the ESC+Q keys on the keyboard for 3-5 seconds to match the code.

Mouse:




1. Remove the battery in the mouse and the receiver on the computer
2. Reinsert the battery into the mouse and reinsert the receiver into the computer jack.
3. At a distance of 20 cm from the receiver, press the right mouse button and the scroll wheel button

simultaneously for 3 to 5 seconds to match the code. After successful pairing, it can be used normally.

The keyboard/mouse response is delayed and works abnormally, how to solve it?

1. The battery may be low, please replace the battery for the keyboard/mouse.
2. It may be caused by the computer freezing, please restart the computer and try again.
3. The maximum use distance of this product is 10M, please keep it within 10M. And there should be no metal obstacles between the keyboard/mouse and the receiver.

Documents / Resources

	Dongguan Wireless Keyboard and Mouse Combos [pdf] User Manual PC394A-R, PC394AR, 2A8YW-PC394A-R, 2A8YWPC394AR, PC394A-1, PC394A1, 2A8YW-PC394A-1, 2A8YWPC394A1, PC394A, 2A8YW-PC394A, 2A8YWPC394A, Wireless Keyboard and Mouse Combos, Wireless Mouse, Wireless Keyboard, Keyboard and Mouse Combos, Mouse, Keyboard
---	---