



DOPO T-708 Android 4.0 Tablet User Manual

[Home](#) » [DOPO](#) » DOPO T-708 Android 4.0 Tablet User Manual 

Contents

- [1 DOPO T-708 Android 4.0 Tablet](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)

DOPO

DOPO T-708 Android 4.0 Tablet



Product Information

Model	T-708
Operating System	Android 4.0
Manufacturer	DOPO

Product Usage Instructions

Getting Started

Before you begin, please read the User Manual carefully.

Connect to your computer

Connect your tablet to your computer with the supplied USB cable to transfer media files when you are running Windows 7 or Vista. For Windows XP, please install Windows Media Player 11 before you transfer media files. Earlier versions of Windows require the MTP Porting Kit. For Mac, please refer to www.android.com/filetransfer.

Turn On / Off

- To turn on your tablet, press and hold the power key at the right side of your tablet for about 5 seconds.
- To unlock the screen (sleep mode), drag the lock on the open lock icon to go to the home screen.
- To directly access the camera app, drag the lock on the camera icon.

Your Homescreen

Change wallpaper for homescreen

To change the wallpaper for your homescreen, follow the instructions in the User Manual.

Add / delete applications from the homescreen

To add or delete applications from the homescreen, follow the instructions in the User Manual.

Add widgets from the homescreen

To add widgets from the homescreen, follow the instructions in the User Manual.

Network Connection

Wi-Fi

- To turn on Wi-Fi, follow the instructions in the User Manual.
- To turn off Wi-Fi, follow the instructions in the User Manual.
- To add a Wi-Fi network manually, follow the instructions in the User Manual.

3G Network

To connect to a 3G network, follow the instructions in the User Manual.

Internet Browsing

To browse the internet, follow the instructions in the User Manual.

Install and Manage Apps

- To install apps, follow the instructions in the User Manual.
- To manage apps, follow the instructions in the User Manual.
- To access the market, follow the instructions in the User Manual.

Multi-media Functions

Music

To listen to music, follow the instructions in the User Manual.

Video

- To play videos, follow the instructions in the User Manual.
- To use the video player, follow the instructions in the User Manual.
- To output video via HDMI, follow the instructions in the User Manual.

Gallery

To view photos in the gallery, follow the instructions in the User Manual.

Camera

To use the camera, follow the instructions in the User Manual.

E-book Reader

To read e-books, follow the instructions in the User Manual.

E-mail

To set up and use e-mail, follow the instructions in the User Manual.

Settings

- To access wireless and network settings, follow the instructions in the User Manual.
- To access device settings, follow the instructions in the User Manual.
- To access personal settings, follow the instructions in the User Manual.
- To access system settings, follow the instructions in the User Manual.

Explorer

To explore files and folders, follow the instructions in the User Manual.


Battery

To learn about battery usage, follow the instructions in the User Manual.


Troubleshooting

If you encounter any issues, refer to the troubleshooting section in the User Manual for solutions.



Front view





Side view








Backside view












X Remove












 Account setup

Email account


You can set up email for most accounts in just a few steps.

Email address

Manual setup

Password

Next

 Account setup

Account type


What type of account is this?

Previous

POP3

IMAP

Exchange

 Account setup

Incoming server settings

Username

Password

Previous


POP3 server

Security type

Next

Port

Delete email from server

 Account setup

Outgoing server settings

SMTP server


Security type

Previous

Port

Next

☐ Require sign-in.

 Account settings

Account options

Inbox checking frequency Every 15 minutes


☐ Send email from this account by default.

☒ Notify me when email arrives.

☒ Sync email from this account.

Previous

Next


 Account setup

Your account is set up and email is on its way!

Give this account a name (optional)



Next





Your name (displayed on outgoing messages)

 Email

Waiting for sync

Your email will appear soon.





Low battery	Full battery	Battery charging



Documents / Resources

<div><div>User Manual</div><div>Model T-708</div><div>Android 4.0</div><div></div></div>	<div>DOPO T-708 Android 4.0 Tablet [pdf] User Manual</div> <div>T-708, T-708 Android 4.0 Tablet, Android 4.0 Tablet, Tablet</div>
---	---

References

- 

[Android File Transfer](#)
- 

[Search - Manual-Hub.com](#)