





## dormakaba E450 Smart Home Controller User Guide

[Home](#) » [dormakaba](#) » dormakaba E450 Smart Home Controller User Guide 



Oracode e450  
Setup Guide



PK519260 – 03/2023  
Original document  
Setup Instructions

### Contents

- [1 Wired Connection Setup](#)
- [2 Wi-Fi Connection Setup](#)
- [3 Documents / Resources](#)
- [3.1 References](#)

### Wired Connection Setup

If you are not using Wi-Fi,

1. Connect the AC power adapter to controller.
2. Connect controller to your internet gateway using an Ethernet cable.
3. The controller LED must be bright blue. When the indicator blinks once the connection will start.

Skip to Step 14 to continue setup.

## Wi-Fi Connection Setup

1. Scan the QR code using your mobile phone camera to access the app.




<http://ezlo.com/app>


2. Select Apple App Store or Google Play to download the app:




3. Once the VeraMobile app is downloaded, you will have the option to "Open" the app.




4. Once you open the app, you will see the following page. Click on "New to Vera?"



5. Choose "EZLO Plus".



6. Choose "Wireless setup".



7. Connect the power cable to the Oracode e450 Smart Home Controller.




8. You will then see the instruction page to connect to Wi-Fi.



9. Look under your Oracode e450 Controller to locate information you will need during setup.


- SSID
- WiFi
- MAC

10. Go to your mobile phone Settings and choose Wi-Fi.




11. Choose the Wi-Fi option that matches your specific SSID number. It will then ask you to enter the password which is the Wi-Fi number from the back of your controller.

In our example, the SSID is wifi\_90006750 and the password is 1260219f




12. Go back to the Vera app. You will be asked to select your Home Wi-Fi network. Select the home network that you will use with the e450 Smart Controller. The network must be password protected, or it will not work with the device.



13. If the password is properly entered, you will see the following page. You may see an error message saying that the connection is lost, this is okay.

Check that the Oracode e450 Controller is flashing.

After a couple of minutes, a steady blue light means that everything is ready to be used on the Oracode website. <https://www.kabaecodewireless.com/>



14. Go to <https://www.kabaecodewireless.com/> and use your login.

## Please Login

Forgot Your Password >

Login >

Toll free: 1.888.217.5654

[Terms of Use](#)

Technical Support - [oracode@dormakaba.com](mailto:oracode@dormakaba.com)

Customer Service - [oracode.customerservice@dormakaba.com](mailto:oracode.customerservice@dormakaba.com)

15. Go to "Doors" tab



16. Go to "Door Monitoring" Option



17. Click on "CREATE"



18. In the Create Door section:

1. Enter a Door Name.
  2. Select a Door Profile.
  3. Select an Unlock Delay of 5 seconds or longer.
- Then click Apply.

**Create Door**

Enter Door Name:

Door profile:

Select Unlock Delay:

Description (optional):

19. In Door Monitoring section, enter the door name in the search box to locate your door. Then select your door and click “ACTIVATE AS WIRELESS”.

Door created successfully - Door A1120

**Door Monitoring**

Filter Door by characters that the door name can contain:

Door Name	
Door A1120	

Displaying items 1 - 1 of 1

20. Go to Network section and choose the Time Zone and click on “Save Changes”.

1) Please select the time zone of the door Or 2) Select an existing Oraclecode Network

**Door A1120 Wireless Settings**

**Network**

Your current Oraclecode Network is Door A1120\_Network and you need to set the time zone of the door


Time Zone:

Network Name:

Or Select an existing Oraclecode Network:

Network Name	Gateway Type	MAC address	Time Zone	Gateway Status	Nbr of Devices
ChucksDoor1_PensacolaNetwork	SAM7x	000E2A7F0515	(UTC-05:00) Eastern Time (US & Canada)	OFFLINE	1
101_Network	SAM7x	000E2A7F0568	(UTC-05:00) Eastern Time (US & Canada)	OFFLINE	0
ChucksDoor2_PensacolaNetwork	SAM7x	000E2A7F0563	(UTC-05:00) Eastern Time (US & Canada)	OFFLINE	1

21. Type the MAC code located on the back of the controller, without any colon signs.  
i.e. In our example code the MAC code is 02:42:8F:B8:C0:C2 and should be typed as 02428FB8C0C2.



Network Settings saved

### Door A1120 Wireless Settings

Clear log events

**Network** [Change](#)

Your current Oracode Network is Door A1120\_Network and is located in (UTC-06:00) Central Time (US & Canada)

**PUT YOUR NETWORK IN DISCOVERY MODE** MAC address:  [Enable Discovery Mode](#)

**Door** [Change](#)

Your lock is pending activation as a wireless lock. Your Activation number is: **## 67 25 77 30** [Generate New Activation number](#)  
You will need to enter the Activation number on your lock to connect it to the Oracode Network. [Email me this Activation number](#)  
NOTE: Wireless locks must be connected to an Oracode Gateway network device.

**Lock Clones**

Door Name	Actions
No records to display.	

[Create](#) [Delete](#)

[Print](#)

Finally, click on “Enable Discovery Mode”. You will see the blue light on the Smart Home Controller will start flashing.

22. As soon as the LED light starts flashing on your Oracode e450 Smart Home Controller, it means the lock can be activated. Follow these instructions:

1. First enter ###0 on the lock
  2. Then enter the activation number provided to join the lock \*# \*# xx xx xx xx
- In the example below, the activation number is \*# \*# 67 25 77 30.

Network Settings saved

### Door A1120 Wireless Settings

Clear log events

**Network** [Change](#)

Your current Oracode Network is Door A1120\_Network and is located in (UTC-06:00) Central Time (US & Canada)

**PUT YOUR NETWORK IN DISCOVERY MODE** MAC address:  [Discovery Mode Configured](#)  
[Discovery Mode Enabled](#)

**Lock**

You will need to enter the configuration code **###0** on your lock to pair it with your gateway. When command is successful, the lock will flash green during 1 or 2 seconds.

**Door** [Change](#)

Your lock is pending activation as a wireless lock. Your Activation number is: **## 67 25 77 30** [Generate New Activation number](#)  
You will need to enter the Activation number on your lock to connect it to the Oracode Network. [Email me this Activation number](#)  
NOTE: Wireless locks must be connected to an Oracode Gateway network device.


**Lock Clones**

Door Name	Actions
No records to display.	

[Create](#) [Delete](#)

[Print](#)

23. Your lock should flash green to confirm that the lock is activated. Your lock is now ready to use.  
Repeat Steps 15 to 22 for additional locks.



**Think tomorrow**

We are committed to championing sustainability in everything we do, from producing more sustainable solutions to help our customers lessen their environmental footprint to being a fair and responsible employer and neighbor.




[dormakaba.com](https://dormakaba.com)

dormakaba USA Inc.  
6161 E. 75th Street  
Indianapolis, IN 46250  
T: 1 888 217 5654




[dormakaba.us](https://dormakaba.us)

PK 5 1 9 2 6 0 0 3 \_ 2 0 2 3

**Documents / Resources**

	<p><a href="#">dormakaba E450 Smart Home Controller</a> [pdf] User Guide E450 Smart Home Controller, E450, Smart Home Controller, Controller</p>
---	--

**References**

-  [dormakaba USA | For every place that matters](#)
-  [dormakaba USA | For every place that matters](#)
-  [Oracode Live](#)
- [User Manual](#)