

DORMAN 742-507 Front Driver Side Power Window Motor



DORMAN 742-507 Front Driver Side Power Window Motor Instruction Manual

[Home](#) » [DORMAN](#) » DORMAN 742-507 Front Driver Side Power Window Motor Instruction Manual 

Contents

- [1 DORMAN 742-507 Front Driver Side Power Window Motor](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 CABLE TYPE REGULATORS](#)
- [5 SCISSOR STYLE REGULATORS](#)
- [6 ELECTRICAL CONNECTORS](#)
- [7 Disclaimer](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



DORMAN 742-507 Front Driver Side Power Window Motor



Product Information

Specifications

- **Product:** Window Lift Motor
- **Design:** Cable Type Regulators
- **Installation:** Requires shop manual for specific service procedures

Product Usage Instructions

Installation Steps

1. Refer to the appropriate shop manual for your vehicle for specific service procedures.
2. If you lack the skill, it is recommended to seek the services of a qualified technician.
3. Pay special attention to all cautions and warnings in the shop manual.
4. Obtain a shop manual for the safe removal, installation, and handling of window regulators.
5. Handle regulator cable spools with care to prevent unraveling.

Important Notes

- Apply heat to the shrink-type connector to prevent water entry and corrosion.
- Cable-style regulators require special handling for successful motor removal and installation.

Frequently Asked Questions (FAQ)

- **Q: Can I install the Window Lift Motor without a shop manual?**

A: It is recommended to refer to the shop manual for specific service procedures to ensure proper installation.

- **Q: What should I do if the regulator cable spool unravels?**

A: Refer to the Service Manual for proper removal of the Motor from the cable spool to prevent further damage.

ATTENTION:

Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

IMPORTANT**WINDOW LIFT MOTOR INSTALLATION INSTRUCTIONS**

Window regulators may vary in design. It will be necessary to obtain a shop manual for the safe removal, installation, and handling of window regulators.

CABLE TYPE REGULATORS**IMPORTANT:**

Some regulator cable spools will unravel if not handled properly. Refer to the Service Manual for proper removal of the Motor from the cable spool. Cable-style regulators require special handling for the successful removal and installation of the window lift motor. These instructions will help prevent the spool from coming apart and result in the complete replacement of the motor/regulator assembly.

- Remove the regulator according to the shop manual. Make sure to support the window glass safely.
- Unbolt or remove the retaining rivets holding the motor to the regulator.
- CAREFULLY lift the motor out of the spool since some spools will come out of the housing with the motor. HINT: use a long thin screwdriver to help separate the motor from the spool.
- Remove the motor.
- Reverse the procedure to install.

SCISSOR STYLE REGULATORS

Scissors-style regulators have an assist spring to help move the window glass. This spring is under pressure at all times. The regulator must be secured BEFORE removing the motor.

- Remove the regulator according to the shop manual. Make sure to support the window glass safely.
- BEFORE removing the motor from the regulator it will be necessary to secure the sector gear of the regulator by installing a bolt through the regulator body and the sector gear.
- Drill out any rivets or remove any bolts retaining the motor to the regulator.
- Reverse the procedure to install.

ELECTRICAL CONNECTORS

One of the three types of electrical connections will be supplied with each motor depending upon application.

- Adapters to lengthen the wires. Plug into existing wiring connector.
- Adapters to change the connector type. Plug into existing wiring connector.
- Butt type connectors. Strip the wires and crimp, then apply heat to seal the connector. NOTE: Do not leave out this step. Failure to apply heat to the shrink-type connector will allow water to enter and corrosion to form. This will result in premature failure of the wiring.


Disclaimer

Even though every attempt is made to ensure this information is complete and accurate, it is impossible to account for all possible circumstances or situations. Please consult with a qualified auto technician before attempting to perform any work you are not qualified to do. Automobiles can be hazardous to work on; be sure to take all necessary safety precautions. Failure to do so may result in property damage or personal injury. Certain motor vehicle standards and performance requirements may apply to your motor vehicle (such as Federal Motor Vehicle Safety Standards by the National Highway Traffic Safety Administration). Be sure that your work is performed by such standards and that you do not disable any motor vehicle safety features.

©2011 Dorman Products, Inc.

No reproductions in whole or in part without prior written approval.

Documents / Resources

	<p>DORMAN 742-507 Front Driver Side Power Window Motor [pdf] Instruction Manual 742-507 Front Driver Side Power Window Motor, 742-507, Front Driver Side Power Window Motor, Driver Side Power Window Motor, Side Power Window Motor, Power Window Motor, Window Motor</p>
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.