



DOUBLEEAGLE C61042W-06 Remote Control Instructions

[Home](#) » [DOUBLEEAGLE](#) » DOUBLEEAGLE C61042W-06 Remote Control Instructions 




Contents

- [1 DOUBLE EAGLE C61042W-06 Remote Control](#)
- [2 REMOTE CONTROL](#)
- [3 FCCID:2AAFASY-C61042W-06](#)
- [4 BATTERY CASE](#)
- [5 2.4GHz AUTOMATICAL CODE DESCRIPTION](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

DOUBLE EAGLE C61042W-06 Remote Control



REMOTE CONTROL



FCCIO:2AAFASY-C61042W-06

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CHARGER



charging output: 5V-2A (not recommended to use a higher power charger)



The main parts of the toy have an overload protection function. When connected to overload or faulty components, it will automatically power off (it can't work), and need to charge for more than 2 seconds to recover.



BATTERY CASE



ATTENTION

1. You must charge the product when using it for the first time. The charger output current and charging line has an effect on the charging time.
2. When charging, the blue light flashes to indicate that the charging is normal; the blue light does not flash when the charging has been completed; charge for more than 3 hours to play.
3. The output port can only be used with the matching plug of the product.
4. The output port can not touch the metal (conductive) surface. Please pay attention when placing and avoid damaging the product.
5. This toy contains batteries that are non-replaceable.

2.4GHz AUTOMATICAL CODE DESCRIPTION


1. When the remote control is equipped with the battery, press the power switch of it, and the indicator light of the remote control flashes slowly and starts to match the code; Press the power switch of the battery box again, and the indicator light of the battery box will change from flashing to long bright. In the meanwhile, the indicator light of the remote control will flash twice and then goes out, indicating the success of the code.
2. Each remote control can only pair with one battery box. When the pairing code is successful, each battery box

does not interfere with the other.

3. If the remote control or the battery box doesn't get the 2.4G signal from the corresponding battery box or remote control after 2 minutes or does not have any button operation after about 4 minutes in a successful code state, it will automatically shut down. Need to press its power switch again to continue to use it.
4. Turn off the power to re-pair the code with the other remote control or battery box.

The instruction manual must be retained since it contains important information.

Documents / Resources

	<p>DOUBLEEAGLE C61042W-06 Remote Control [pdf] Instructions SY-C61042W-06, 2AAFASY-C61042W-06, 2AAFASYC61042W06, C61042W-06 Remote Contr ol, C61042W-06, Remote Control</p>
---	--

Manuals+.