

# Douxe USB-C Hub - 3 in 1 Instruction Manual

Home » DOUXE » Douxe USB-C Hub – 3 in 1 Instruction Manual



#### Contents [ hide

- 1 USB-C Hub 3 in 1
- 1.1 Instruction Manual
- 2 1. Introduction
- 3 2. Warnings and Safety

#### **Instructions**

- 4 3. Receiving Your Shipment
- 5 4. Contents of Package
- 6 5. Product Features
- 7 6. Technical Data
- 8 7. Product Features
- 9 8. Operating Instructions
- 10 9. Maintenance and Cleaning
- **11 10. Storage**
- 12 11. Disposal Recycle
- 13 12. Service and Warranty
- 14 13. Disclaimer
- 15 Documents / Resources
- **16 Related Posts**

USB-C Hub - 3 in 1



**Instruction Manual** 

#### 1. Introduction

Thank you for choosing our Douxe product! Please always follow the instructions for safe usage.

Are you also short of ports? That is a thing of the past with this 3 in 1 USB-C Hub from Douxe. The USB-C Hub supports a USB-C 3.0, HDMI and USB-A 3.0 input. Make sure to connect your mobile or other extern device and transfer data or stream your favorite movies.

# 2. Warnings and Safety Instructions

- A Please ensure that the packaging is kept out of the reach of children! Risk of suffocation!
- Make sure to keep this user manual. Read the manual carefully before using your Douxe USB-C Hub!
- Be aware of the risks and consequences resulting from misuse of the USB-C Hub. Misuse of the USB-C Hub can result in personal injury, or destruction of the device and of the installations.
- Use the USB-C Hub only for purposes described in this user manual.
- If the USB-C Hub malfunctions, is dropped or (appears to be) damaged in any manner, do NOT use the USB-C Hub and contact Customer Service.
- The USB-C Hub is designed and intended for private, non-commercial use only.

1

- Do not put objects in the slots on the exterior of the device, by doing this you can hit parts that are carrying live voltage. This can cause a fire or an electric shock.
- This device should NOT be used by persons (including children) with physical, sensory, or mental disabilities, or persons (including children) with lack of experience with and knowledge of the device, unless they are supervised or have been given instruction concerning the use by a person responsible for their safety.
- Keep the USB-C Hub away from children when using and storing.
- Do NOT reconstruct, repair, or disassemble the USB-C Hub. This can damage the device. For safety reasons, these parts may only be replaced by authorized service personnel. In order to prevent hazards, always send the USB-C Hub to the service centre for repairs.
- Make sure your outlet supplies the correct power voltage to avoid damage to the USB-C Hub.
- Always check the device for signs of damage before using the USB-C Hub. Do NOT operate the USB-C Hub if

the device is damaged. A damaged device must be repaired by a qualified person in order to avoid damages and personal injuries.

- Do NOT use the USB-C Hub in or near a bath, shower, swimming pool, or over a basin filled with water.
- Make sure to prevent any contact with water. Do NOT submerge the USB-C Hub in water. If water does get
  inside the casing, turn the USB-C Hub off immediately and contact our customer service.
- Do NOT operate the device with damp or wet hands.

2

- Place the USB-C Hub in such a way that the cables connected to it cannot be damaged.
- Keep the USB-C Hub away from moisture, heat and in or close to areas where the surrounding temperature is relatively hot (e.g., stoves or other sources of heat).
- Do NOT cover the USB-C Hub when it is switched on.
- Never put blankets or cushions on top of or against the USB-C Hub. This poses a risk of fire, electric shock, or injury.

# 3. Receiving Your Shipment

When receiving your shipment, make sure that the contents are consistent with the packing list. Notify your distributor of any missing items. If the equipment appears to be damaged, file a claim immediately with the carrier and notify your distributor at once, giving a detailed description of any damage. Save the damaged packing container to substantiate your claim.

## 4. Contents of Package

- 1. Douxe USB-C Hub 3 in 1
- 2. 1x Manual

3

## 5. Product Features



Size	15 x 6 x 1.5 cm
Weight	45 gr
Colour	Grey
Material	Aluminum
Cable Length	12 cm
Power Supply USB 3.0 port	Up to 7.5W (5V/1.5A)
Max charging speed power delivery port	87W, 20V, 3A
Power Supply USB-C Female Port	Up to 87W (20V/5A)
Input Port	USB-C 3.0, HDMI & USB-A 3.0
Output Port	USB-C
USB transmission speed	5 GBps
HDMI video resolution	3840×2160 4K with 30Hz, 1920×1200/ 1920×1080/ 1280× 1024 and lower with 60Hz

HDMI transmission	18 GBps
Operating temperature	0°C to +45°C
Operating humidity	10% to 85% R (no condensation)
Storage temperature	-10°C to +70°C
Storage humidity	5% to 90% RH (no condensation)
Compatible with	MacBook Pro 2016, 2017, 2018 and 2019/ New MacBook Air 2018, 2019/ MacBook 12, New iMac/ Pro Surface Book 2, Go, Chromebook, Pixelbook, Dell, HP, Huawei matebook 20/ P20 Samsung S8, S8 Plus, S9, S9 Plus, S10, and mo re fully functional Type C devices

## 7. Product Features

- Supports accessing an external memory for the host computers;
- The USB-C female port can charge a MacBook or a Google new Chromebook Pixel and other USB-C supported devices and supplies power for the hub simultaneously;
- USB-C interface supports plug and play;
- Use the HDMI input with a HDMI cable to stream your screen;
- Easy to use and carry.

6

# 8. Operating Instructions

- 1. Connect the USB-C male port to your Mac- or Chromebook.
- 2. Connect the USB 3.0 output to a USB 3.0 / USB 2.0 device.

- 3. Connect the HDMI output to HDTV with a HDMI cable.
- 4. Connect the USB-C charging port. It can charge the host computer and supplies power for the Hub simultaneously.

# 9. Maintenance and Cleaning

Clean the USB-C Hub with a clean, dry cloth. Do not use detergents and make sure that the USB-C Hub does not get wet.

### 10. Storage

Store the USB-C Hub in a clean and dry place. Do not store the device in extremely high or extremely low temperatures.

## 11. Disposal - Recycle

Contribute to a cleaner living environment! Do not dispose of the USB-C Hub with the household waste. For proper recycling, please contact your local authority or your household waste disposal service for further details on your nearest designated collection point.

7

## 12. Service and Warranty

Douxe provides a 1-year warranty on its products. To get service during the warranty period, the product needs to be returned with a proof of purchase. Product defects must be reported within 1 years from the date of purchase. This warranty does not cover: damages caused by misuse or incorrect repair; parts subject to wear; defects that the customer was aware of at the time of purchase; damages or defects caused by customer neglect; damages or defects caused by third parties.

#### 13. Disclaimer

Changes reserved; specifications are subject to change without stating grounds for doing so.

8

## **Documents / Resources**



<u>Douxe USB-C Hub - 3 in 1</u> [pdf] Instruction Manual USB-C Hub - 3 in 1

Instruction Manual

Manuals+, home privacy