



Home » DOWAY » DOWAY RECZXA2 AI Voice Recorder User Manual 🯗


Contents [hide]

- 1 DOWAY RECZXA2 AI Voice Recorder
- 2 Package Content
- 3 Product Overview
- 4 Download DOWAV APP
- 5 Create an account
- 6 Activate device
- 7 APP operation instructions
- 8 Recording transcription
- 9 Maintance
- 10 FCC Warning
- 11 Documents / Resources
 - 11.1 References


DOWAY RECZXA2 AI Voice Recorder



Package Content



Product Overview



- 1. Display
- 2. Power key
- 3. Record button
- 4. Mic hole

- 5. Mic hole
- 6. Magnetic Interface

Download DOWAV APP

Download the DOWAY APP to activate A8 ?n fln.t use.

• Seen the OR code below to download and Install DOWAY,




 You can also search the keyword "DOWAY" on IOS app store or Google Play j Find the app to install.





Create an account


Follow the Interface prompts to register and create on account.



Activate device

Open the device and open the OOWAY APP, Follow the ste!'.15 below to connect the device.






APP operation instructions


Start recording/Save recording

- 1. Click on the recording icon at the bottom of the interface.
- 2. Click on the start recording icon at the bottom of the interface.
- 3. Click on the "Save" button at the bottom of the interface.




Play the recording

Click on the play recording icon at the top of the interface.




Recording transcription

- 1. Click on the recording file.
- 2. Click the transfer button at the bottom of the interface.
- 3. Click the start transcription button at the bottom of the interface.




Recording summary generation

- 1. Click on the recording file.
- 2. Click on the summary icon at the top of the interface.
- 3. Click the generate button at the bottom of the interface.



Mind map

- 1. Click on the recording file.
- 2. Click on the mind map icon at the top of the interface.



Attention: Mind maps are automatically generated based on summaries.


Operation instruction

• Power off status

Press and hold the power button for 3 seconds to turn on the device.

· Power on status

Press and hold the power button for 3 seconds to turn off the device.




Standby status

When the screen is off, short-press the power button to light the screen.




Start recording

Push the recording button up and the recorder vibrates once, indicating that recording has started.



Pause recording

Short-press the power button to pause while recording.



End/Save Recording

Push the recording button down, the recorder vibrates twice, and the word "save" appears on the display, which means saving and ending the recording.




CALL Mode(Phone call recording mode)

- 1. When the screen is on and not recording, double-click to switch to Call mode.
- 2. When the screen is on and recording, double-click to switch modes and restart recording.

NOTE Mode (Normal recording mode)

- 1. When the screen is on and not recording, Double-click to switch to NOTE mode.
- 2. When the screen is on and recording. Double click switch modes and restart recording.



Matters needing attention

Legal restrictions

Please strictly abide by relevant laws and do not use this product illegally. The company does not assume any commitment or responsibility for the consequences of illegal behavior.

Privacy Protection

All data is stored only on the recording device, unless you sync the recording file with the app. In this case, the file will be stored on the smartphone.

Data Security

The company is not responsible for loss or damage of personal data caused by hardware, software, product maintenance, battery replacement or other unexpected circumstances

Product setting

Due to firmware upgrades, the actual settings and usage of this product may be different from this manual. If product performance and functions change, please refer to the latest product.

Security

Keep the device and accessories out of the reach of children to avoid choking or other injuries. Do not expose the battery(battery pack or installed batteries) to fire or excessive heat (such as sunlight, etc.).

Maintance

Do not use chemicals or reagents to clean the recorder, as this will damage the surface of the recorder and corrode it.

Battery

If the product is not used for a long time, please charge and discharge it once every three months to prevent battery damage.

Memory storage capacity

The system software estimates a small amount of storage space. The actual available capacity will be slightly less than what is shown in the specifications. The Management of Low-Power Radio

Frequency Radiation Motors

For low-power radio frequency equipment that has obtained a password certificate, companies, businesses, or users are not allowed to change the frequency, increase the power, or change the original design characteristics and functions without approval. The use of low-power radio frequency equipment shall not affect flight safety and interfere

with legal communications: if interference is found, it should be immediately stopped and can only be used again after improvement to no interference. The legal communication in the preceding paragraph refers to radio communications operating in accordance with the provisions of the Telecommunications Management Act. Low-power radio frequency equipment must withstand interference from legal communications or industrial, scientific, and medical radio wave radiating electrical equipment.

Radio frequency exposure

This device has been evaluated to comply with the general RF exposure requirements. This device may be used without restriction in portable exposure conditions.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must

accept any interference received, including interference that may cause undesired operation.

A1 VOICE RECORDER 500mA



FCC ID:2BH9P-RECZXA2

Documents / Resources

DOWAY RECZXA2 AI Voice Recorder [pdf] User Manual
2BH9P-RECZXA2, 2BH9PRECZXA2, RECZXA2 AI Voice Recorder, RECZ
XA2, AI Voice Recorder, Voice Recorder, Recorder

References

- User Manual
- DOWAY
- ▶ 2BH9P-RECZXA2, 2BH9PRECZXA2, AI Voice Recorder, DOWAY, Recorder, RECZXA2, RECZXA2 AI Voice Recorder, Voice Recorder

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name		
Email		
<u> </u>		
Website		
☐ Save my name, email, and website in this browser for the next time I com	ment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.