



DPR Label Rewinder User Manual

[Home](#) » [DPR](#) » DPR Label Rewinder User Manual 

Contents

- [1 DPR Label Rewinder](#)
- [2 INSTALLATION](#)
- [3 SMART SOLUTIONS FOR THE LABELING INDUSTRY](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)




DPR Label Rewinder




INSTALLATION



1. Set the included printer plate beside the rewinder's base and screw both plates with the two knobs



2. Load the empty cardboard core, let pass the printed media underneath the tension arm and stick it on the core. Slide in the outer disk onto the core holder and keep it close to the media edge. Once the media is loaded on the rewinder, slide left and right the rewinder to find the correct alignment with the printer.




1. Adjustable core holder
2. 3" Fixed core holder




SMART SOLUTIONS FOR THE LABELING INDUSTRY

Label rewinder/unwinder, electronic label dispenser, finishing systems and more...



SCORPIO SERIES: DIGITAL LABEL FINISHING SYSTEMS
GEMINI: DIGITAL DIE CUTTER FOR SHEETS
MOTORIZED CORE HOLDER
VIRGO: DESKTOP DIGITAL FINISHING SYSTEM UNWINDER/REWINDER

Documents / Resources

	<p>DPR Label Rewinder [pdf] User Manual Label Rewinder</p>
---	--