



# DRACOOL B09NVWRVQ7 Multi Device Wireless Keyboard with Touchpad User Manual

[Home](#) » [DRACOOL](#) » DRACOOL B09NVWRVQ7 Multi Device Wireless Keyboard with Touchpad User Manual 

## Contents

- [1 DRACOOL B09NVWRVQ7 Multi Device Wireless Keyboard with Touchpad](#)
- [2 Power ON/OFF](#)
- [3 Pair with a Surface Pro](#)
- [4 Troubleshooting in Bluetooth Pairing](#)
- [5 Keyboard Backlight](#)
- [6 Function Keys](#)
- [7 Product Specification](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

# DRACOOL

**DRACOOL B09NVWRVQ7 Multi Device Wireless Keyboard with Touchpad**



## Power ON/OFF

- **Power ON:** Toggle switch to ON.
- **Power OFF:** Toggle the switch to OFF.

## Pair with a Surface Pro

- **Step 1:** For the first time you pair with a Surface Pro, you just need to toggle the switch to “ON” position and the keyboard will enter Bluetooth pairing mode automatically. To enter this mode, you can also hold the



simultaneously for 3 seconds and then the blue indicator will flash to indicate that the keyboard is under pairing mode.

- **Step 2:** On the Surface Pro, select All Settings – Devices – Add Bluetooth or Other Device – Bluetooth and then “Wireless Keyboard” will show up as an available device.
- **Step 3:** Select “Wireless Keyboard” on Surface Pro.
- **Step 4:** When the blue indicator stays on, it means that the keyboard is paired with the Surface Pro successfully.

**Note:** If the keyboard doesn't work even though the blue indicator stays on, it might have been paired with other nearby computer. In this case, please follow steps in ! “Troubleshooting in Bluetooth Pairing” to resolve the issue.

## Troubleshooting in Bluetooth Pairing



- **Step 1:** Delete all the Bluetooth pairing records related to the keyboard on the Surface Pro.





- **Step 2:** Hold simultaneously for 5 seconds. The 3 indicators will flash 3 times simultaneously. All connection records related to the keyboard will be deleted and the keyboard has been



restored to factory settings.

## LED Indicator

| Indicator  | Status             | Meaning                      |
|--|--------------------|------------------------------|
|  : Red  | Flash              | Battery volume $\leq 3.3V$   |
|  | Always on          | Being charged                |
| <b>A</b> : Green   | Always on          | Caps Lock On                 |
|  | Off                | Caps Lock Off                |
|  : Blue | On for 3s then off | Bluetooth Connected          |
|  | Flash              | Bluetooth Pairing/re-pairing |

## Keyboard Backlight

1. Press  +  Enter simultaneously to adjust the color of the backlight. There are 7 colors available in total.



2. Press  +  Shift simultaneously to adjust the brightness of the backlight. There are 3 levels of brightness to choose from.

## Note



- When the battery level is lower than 3.3V, the backlight turns off automatically.
- The backlight will go off automatically if the keyboard is left idle for 30 seconds. 'You can wake it up by pressing any key.

## Function Keys

### • How to Use F1-F12

You may press the  +  keys to enable/disable the Fn lock. A repeated operation can unlock the Fn key. (The keyboard disables the Fn key lock by default.)

### • When the Fn lock is enabled

Press can trigger the functionality owned by F1 key; Press the combination of  +  dim the brightness of the screen; This method applies to all F Keys (F1-F12) .

### • When the lock is disabled(Default Status)



Press the key to dim the brightness of the screen. Press the



+



simultaneously to use the functionality owned by F1 key.

### Check Battery

Level Press  +  is not being charged. simultaneously to check the battery level when the keyboard

| Flashing Red Light | Battery Level |
|--------------------|---------------|
| Once               | 2.7V-3.3V     |
| Twice              | 3.3V-3.6V     |
| 3 times            | 3.6V-3.9V     |
| 4 times            | >3.9V         |

### Charging

When the battery level is  $\leq 3.3V$ , the red indicator will flash. Please recharge the key board in time. To charge it, you can connect the USB cable to the charger of a cellphone or the USB port of a computer. The keyboard will be fully charged after 5-6 hours.

### Sleeping Mode

1. When the keyboard is left idle for 30 seconds, its backlight becomes off.
2. When the keyboard is left idle for 30 minutes, it goes into deep sleep mode.

The Bluetooth connection will be disrupted and it will recover by pressing any key. Tapping the trackpad cannot wake it up.


### Product Specification

|   |            |
|---|------------|
| Bluetooth Version                           | V5.2       |
| Effective Range                             | 10m        |
| Charging Time                               | 5~6h       |
| Charging Current                            | 163mA      |
| Standby Time                                | 300h       |
| Working Time with Brightest White Backlight | About 7h   |
| Working Time without Backlight              | About 300h |
| Battery Capacity                            | 750mAh     |

### Packing list

- Wireless Keyboard \*1
- Type-C Charging Cable \*1
- User Manual \*1

Documents / Resources



[DRACOOOL B09NVWRVQ7 Multi Device Wireless Keyboard with Touchpad](#) [pdf] User Manual

B09NVWRVQ7 Multi Device Wireless Keyboard with Touchpad, B09NVWRVQ7, Multi Device Wireless Keyboard with Touchpad, Device Wireless Keyboard with Touchpad, Wireless Keyboard with Touchpad, Keyboard with Touchpad, Touchpad, Wireless Keyboard, Keyboard

References

- [User Manual](#)