



dyras ALCL-002B Alarm Clock Instruction Manual

[Home](#) » [dyras](#) » dyras ALCL-002B Alarm Clock Instruction Manual 

Contents

- 1 dyras ALCL-002B Alarm Clock
- 2 INFORMATION
- 3 IMPORTANT SAFETY
- 4 FUNCTION INTRODUCTION
- 5 OPERATING INSTRUCTION
- 6 SPECIFICATIONS
- 7 WASTE MANAGEMENT
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts

dyras

dyras ALCL-002B Alarm Clock



INFORMATION

Alarm Clock Model: ALCL-002B

Before using this device, please read the instruction manual carefully.

IMPORTANT SAFETY

Please read the user manual thoroughly before using your new appliance. You must obey the safety instructions that follow when using the appliance.

- This device is not supposed to be used by physically or mentally handicapped people, or persons without experience or knowledge (including children), unless their use of the device is supervised or guided by someone who is at the same time responsible for their safety. As for children, supervision is recommended to make sure that they do not play with the device. This device is not supposed to be used by children under the age of 14, not even with supervision!
- Never use an appliance or accessory that the manufacturer did not supply with, or propose for use with, the appliance. The use of such appliances or accessories might lead to accidents or irregular function.
- Do not place the appliance near hot objects (e.g., electric or gas cooker, hob, radiator, etc.) or on a hot surface and do not use the appliance on an unstable surface, or a high surface, or any surface where it is unstable and can be knocked down in an accident.
- Do not use the appliance in the presence of explosive or inflammable gases, vapors or liquids.
- This device is intended only for household use. Do not use for industrial or retail purposes.
- Do not immerse the appliance in water or any other liquid! If humidity gets into the appliance, it can cause defects, so do not use it in the bathroom or any other room where there is high humidity.
- Always remove the battery when it stops working. Never leave a dead ("flat") battery in the appliance.

FUNCTION INTRODUCTION

- 4-digit LED display, 2 display modes:
 - o Dp-1: time/date/temperature rotation display
 - o Dp-2: fixed time display

- Time display function
- Date function
- Temperature function
- Sound control mode: In the normal display state, press the DOWN button to set, “–SD” means turn off the voice control, and the display is always on; “ON SD” means turn on the voice control. After turning on the voice control mode for a few seconds, the display will automatically turn off
- and enter the energy-saving mode. When the close distance is greater than 60 decibels clap your hands or tap the product to wake up the display.
- Alarm clock function
- Brightness adjustment: Under the normal display state of the clock, the long press UP key enters the brightness setting for three seconds, and the short press up key (UP) key / down key (DOWN) adjusts the brightness (from L0 to L3).

OPERATING INSTRUCTION

Long press the set key (until the digital flashing screen appears) to enter the setting item. The setting sequence is as follows:

Setting the date

After entering setting mode, set year – month – day according to the position of digital flash, adjust up (UP)/down (DOWN) in turn.

Setting the time system

After setting the date, press the set key to enter the 12/24-hour setting and press up/down to switch. In the 12-hour system, the PM light is on.

Setting the time

After setting the time system, press the set key to enter the time setting. When the number is flashing, press up/down to adjust and long press fast forward/fast backward.

Setting the alarm

After setting the time, press the set key to enter the alarm setting. Press up/down to set the alarm on or off. “–:A1” is off for group 1 alarm; “on:A1 is on for group 1 alarm. Press the set key again to set the alarm time. When the number is flashing, press up/down to adjust, long press fast forward or fast backward. According to this step, the second group (A2) and the third group (A3) alarm are set.

ATTENTION

- Avoid dropping or hitting the clock.
- Wipe clock surface with a clean dry cloth if need clean.
- Do not wash the clock with water, the clock mechanism can be damaged if immersed in water.

SPECIFICATIONS

Model: ALCL-002B

- Voltage: DC 5V
- Battery: 4xAAA

WASTE MANAGEMENT



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Manufacturer



The CE mark is intended to indicate that the product complies with the relevant European Union standards and can be freely marketed in the European Union.


www.dyras.hu

Copyright © 2023 The dyras www.factory LLC U.S.A.

No parts of the content (including logos, design, photos, text, colour scheme arrangements, etc.) may be reproduced, reused or redistributed for any purpose whatsoever, or distributed to a thirdparty for such purposes, without the written permission of The dyras www.factory LLC.

®= registered trademark of Dyras Europe Kft.

Documents / Resources

	dyras ALCL-002B Alarm Clock [pdf] Instruction Manual ALCL-002B, ALCL-002B Alarm Clock, ALCL-002B, Alarm Clock, Clock
---	---

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.