



SP-F25B Bluetooth Speaker With Microphone Dyras User Guide

[Home](#) » [dyras](#) » SP-F25B Bluetooth Speaker With Microphone Dyras User Guide 

SP-F25B Bluetooth Speaker With Microphone Dyras



Please carefully read the instructions before using!

Contents

- [1 CONTENT OF THE BOX](#)
- [2 SPECIFICATION](#)
- [3 PARTS DESCRIPTION](#)
- [4 USING THE DEVICE](#)
- [5 SAFETY](#)
- [INSTRUCTIONS](#)
- [6 WASTE MANAGEMENT](#)
- [7 Customer Support](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

CONTENT OF THE BOX

- SP-F25B speaker
- Micro USB cable
- Audio cable 3.5 jack
- Removable strap
- User manual
- External microphone


SPECIFICATION

Bluetooth version	5.0
Output Power	2x5W
Frequency response	2.40GHz – 2.480GHz
Noise L=dB	> 90dB
Charging standard	Micro USB/DCV5V-1A
Charging time	3-4Hours
Transmission distance	10 meter
Built in battery	1500mAh
Size	2 x 57 mm

PARTS DESCRIPTION

1. Volume +/-Next
2. Mode switch
3. Volume -/Previous
4. AUX input
5. Micro TF card slot
6. LED indicator
7. On/Off switch

8. Charging port
9. USB flash drive slot
10. External microphone slot



USING THE DEVICE

Before using for the first time, we recommended to charge fully. To charge, use the included Micro USB cable, which need to be connected to a charger adapter to the electrical network.

The Led display shows the status of the speaker.

For a stable Bluetooth connection, keep distance no more than 10 meters between the speaker and the connected device.

Press and hold the Power button for 5 seconds, the speaker switches top airing mode in turn with blue-red light. Open the Phone's Bluetooth search mode and search for the model number SP-F25B model and pair the device.

- Play/Pause button to press this button you can start or stop music playback during a Bluetooth connection
- |<< / >>| buttons – next/ previous /volume control. Short press: next track, long press: Volume increase
- Memory card – please put the memory card into the TF card slot, the BT Speaker will automatically start playing the contents of the memory cards
- Mode switch key – you can choose between FM/BT/AUX/USB/TF card mode. Short Press: Pause/ Play / Handsfree call.
- USB port – USB flash drive connection

SAFETY INSTRUCTIONS

- Do not disassemble the product yourself. This speaker does not include any units that can be replaced or repaired by the user.
- Always contact a professional service in case of any fault.
- Replacement and maintenance may only be carried out by a professional service.
- Do not place the product near heat sources, e.g. stove or fireplace.
- Please do not place the product near water, into water or in a humid place!
- Babies and small children are not allowed to use the product!
- Please do not use the product for other purposes than its intended use
- Do not use liquids or abrasive cleaners for cleaning
- Use only soft, slightly wet towel for cleaning

WASTE MANAGEMENT

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Manufacturer/Importer: Vorosko Kft., 8200 Veszprem, Papai út 36.

CE SYMBOL



The mark is intended to indicate that the product complies with the relevant European Union standards and can be freely marketed in the European Union.

Customer Support

No parts of the content (including logos, design, photos, text, colour scheme arrangements, etc.) may be reproduced, reused or redistributed for any purpose whatsoever, or distributed to a third party for such purposes, without the written permission of Dyras Europe Kft.

“dyras” is a registered trademark of Dyras Europe Kft.

www.dyras.eu

dyras

Documents / Resources

dyras

SP-F25B



[dyras SP-F25B Bluetooth Speaker With Microphone Dyras](#) [pdf] User Guide

SP-F25B Bluetooth Speaker With Microphone Dyras, SP-F25B, Bluetooth Speaker With Microphone Dyras, Speaker With Microphone Dyras, Microphone Dyras, Dyras

References

- [Dyras | Fedezze fel a különbséget!](#)
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.