

# dyras SP-S65B Bluetooth Speaker Instruction Manual

Home » dyras » dyras SP-S65B Bluetooth Speaker Instruction Manual



### **Contents**

- 1 dyras SP-S65B Bluetooth **Speaker**
- 2 FAQ
- **3 PRODUCT PARTS**
- **4 USING THE APPLIANCE**
- **5 TECHNICAL DETAILS**
- **6 WASTE MANAGEMENT**
- 7 Documents / Resources
  - 7.1 References



dyras SP-S65B Bluetooth Speaker



# **FAQ**

# What do I do if the pairing is unsuccessful?


If pairing is unsuccessful, ensure both devices are within range and try again. Restart both devices if needed.

# How can I extend the battery life of the speaker?

To extend battery life, avoid keeping the speaker at maximum volume for extended periods. Charge the speaker fully before each use.

Please read the instructions before using!

# **PRODUCT PARTS**



- 1. On/Off/Play/Pause/Calling
- 2. Volume + /Next song
- 3. Indicator light
- 4. Disconnect wireless connection
- 5. Volume /Previous song
- 6. Charging port/TF card
- 7. Microphone
- 8. Light switch

# **USING THE APPLIANCE**

# Power on, pairing

Long press the On/Off button to turn on or turn off the speaker.

# **Pairing**

Turn on the device, the indicator flashes blue. Search the speaker on your phone then pair it. When the blue indicator stopped flashing, the pairing was successful.

# Music playing

- Play/Pause: Short press the Play button.
- Previous song: Long press the Volume /Previous button.
- Next song: Long press the Volume + /Next button.
- Volume + or -: Short press the Volume + or button to choose the desired volume.

# **Answering incoming call**

Short press the Calling button to answer incoming calls or end the call.

## Reject incoming call

Long press the Calling button to reject incoming call.

## Charging

Fully charge the product before the first use. The red light of the charging indicator is always on when charging, and the charging indicator turns off when the battery is fully charged.

### **ATTENTION**

- Please do not disassemble the product!
- Please do not place the product near heat sources!
- Please do not place the product near water, in water or in a wet place!
- · Keep away from children!
- The cable is for charging. Please do not use for other purposes!
- To protect your hearing and prolong the life of the speaker, it is not recommended to keep the volume at maximum for long periods of time!

### **TECHNICAL DETAILS**

• Battery: 1200mAh

• Power: 5W

• Frequency: 100Hz-20kHz

Play time: 7-8 hours (70% vol.)
Input voltage/current: DC 5V/1A

Charging time: 3 hoursCharging port: Type-C

#### WASTE MANAGEMENT

## **Correct Disposal of this product**

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

## **CE SYMBOL**

The mark is intended to indicate that the product complies with the relevant European Union standards and can be freely marketed in the European Union.

#### **Documents / Resources**



dyras SP-S65B Bluetooth Speaker [pdf] Instruction Manual SP-S65B Bluetooth Speaker, SP-S65B, Bluetooth Speaker, Speaker

## References

- O Dyras | Fedezze fel a különbséget!
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.