

Eagle EG740L Chain Secure



EG740L Eagle Chain Secure Instruction Manual

[Home](#) » [EAGLE](#) » EG740L Eagle Chain Secure Instruction Manual 

Contents

- 1 Eagle EG740L Chain Secure
- 2 Choose the Eagle Chain Secure Position (Left or Right)
- 3 Chain Tightness
- 4 Installation
- 5 Documents / Resources
 - 5.1 References




Eagle EG740L Chain Secure



The EG740 Eagle Chain Secure is designed to quickly tighten the chain on a slide gate. Over time, a slide gate's operating chain will need to be tightened. The EG740 Eagle Chain Secure allows this operation to be performed quickly and easily by merely cranking the chain-tightening wrench provided. A properly tightened chain will perform much better than a neglected chain that naturally "stretches out" over time. The stretched-out chain can cause damage and performance problems to the slide gate system.

Choose the Eagle Chain Secure Position (Left or Right)




- ONLY ONE Eagle Chain Secure is needed per slide gate.
- Eagle Chain Secure is typically installed on the SAME END of the gate as the gate operator when the gate is in the CLOSED position.

Chain Tightness

After the chain connection, turn the chain tightening wrench to tighten the chain.

IMPORTANT: The chain can ONLY be tightened when Eagle Chain Secure is far away from the gate operator (in the OPEN position). The chain should sag no more than one (1) inch per 10 feet of travel. The chain can be easily tightened over time as it naturally stretches out. Do not over-tighten the chain.


Installation



- The chain locking gear **MUST** be mounted facing **OUTWARD**.
- The chain tightening wrench will **ONLY** fit in the chain locking gear opening.

Eagle Access Control Systems, Inc.
12953 Foothill Blvd.
Sylmar, CA 91342
Toll Free: 1-[800-708-8848](tel:800-708-8848)
Phone: [818-837-7900](tel:818-837-7900)
Fax: [818-837-7911](tel:818-837-7911)

Documents / Resources



[EAGLE EG740L Eagle Chain Secure \[pdf\]](#) Instruction Manual
EG740L Eagle Chain Secure, EG740L, Eagle Chain Secure, Chain Secure, Secure

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.