

easy home GM-02-US Portable Sound Machine User Manual

Home » EASY HOME » easy home GM-02-US Portable Sound Machine User Manual



Contents


- 1 easy home GM-02-US Portable Sound
- **Machine**
- **2 BUTTON INDICATION**
- **3 QUICK TIPS**
- **4 Features**
- **5 Product Specifications**
- **6 ATTENTION**
- 7 Documents / Resources




easy home GM-02-US Portable Sound Machine



BUTTON INDICATION






- Connect the power cable to the power port and a USB adapter(not included), the power indicator lights up red when charging, and turns green to indicate that the product is fully charged.
- Press the power button to tum the unit ON.
- A green light will illuminate when ON.
- Press the power button a second time to turn the unit OFF.

The green light will be OFF.

when the unit is OFF.



(30 60 90) Press to Pause/Play music



Press rep avidly to cycle through the different sounds.

NOTE: When the sound machine is turned on, it will always default to the last sound used.

Press to increase or decrease the volume

Using the Auto-Timer: When you are listening to a sound you may set a timer 30,60,90 minutes as your desire. So the machine will automatically turn off at the time you set. Press the timer button once for 30 minutes, a second time for 60 minutes, a third time for 90 minutes and a fourth time to turn the timer OFF. An indicator light will show the timer setting. If the timer indicator is OFF, the timer is OFF. The timer can only be set when the sound is playing. Light button. The first press for lighting up, the second press makes the light brighter, third press turns the light off.

Features

Night Light

- 16 sound:4 white noises, 4 fan sounds, and 8 natural sounds (ocean, lullaby, running water, bonfire, bird calls, thunderstorm, train, heartbeat)
- Timer: 30, 60, 90 minutes
- Memory Function

Product Specifications

• Model: GM -02

Speaker:28mm,4O3W

• Input Power: DC5V=1A

• Battery Model/Capacity: 103048-1500mAh Use time: 7h-20h

• Product size: 3.15X3.15X 1.14inch (LXWXH)

PACKAGE INCLUDED

- 1x White Noise Machine
- 1x USB cable
- 1 x Instruction
- 1x Hook

ATTENTION

- Please don't disassemble or repair the product by yourself to avoid damaging the product;
- Keep it away from the water source to avoid product damage caused by the influent;
- Keep it away from the high temperature and fire source
- Don't use corrosive washing aid for cleaning;
- Please use a soft wet cloth towel to wipe the surface
- Unplug the power adapter I from the outlet when the unit is unused for long periods

Documents / Resources



<u>easy home GM-02-US Portable Sound Machine</u> [pdf] User Manual GM-02-US Portable Sound Machine, GM-02-US, Portable Sound Machine, Sound Machine

Manuals+,