

# **EasyLog EL-IOT Wireless Cloud-Connected Data Logger User Guide**

Home » EasyLog » EasyLog EL-IOT Wireless Cloud-Connected Data Logger User Guide Tale



EasyLog EL-IOT Wireless Cloud-Connected Data Logger User Guide

#### **Contents**

- 1 Set up a Cloud Account
- 2 Remove the mounting bracket
- 3 Remove the back cover
- 4 Install the batteries
- 5 Connect to and configure in the Cloud
- **6 Button Functions**
- 7 Getting to know your EL-IOT data

logger

- **8 Indicators and Sounder**
- **9 Important Safety Information** 
  - 9.1 Repairing or modifying
  - 9.2 Power supply
  - 9.3 Disposal and recycling
- **10 Technical Support**
- 11 Documents / Resources
- **12 Related Posts**

## Set up a Cloud Account

To begin setting up your EL-IOT, you first need an EasyLog Cloud account.





- Visit easylogcloud.com and click Sign Up Now
- Download the EasyLog Cloud App onto your phone or table

## Remove the mounting bracket

• Slide the mounting bracket upwards to detach it from the EI-IOT device.



## Remove the back cover

- Use a cross-head screwdriver to unscrew the 4 screws that secure the back cover of the device.
- Once the screws are removed, lift the back cover to reveal the battery compartment.



## Install the batteries

Insert 4 x AA batteries into the battery compartment, taking care to place the batteries in the correct orientation. The sounder will beep when the batteries are first inserted.



# Connect to and configure in the Cloud




Sign in to the EasyLog Cloud App on your mobile device. Select "Setup Device" from the burger menu and follow the on-screen instructions to configure your EL-IOT.

Once your EL-IOT is connected to your WiFi network and EasyLog account, replace the battery cover and wall mount bracket. Setup is now complete. Install your device in the location you wish to monitor.

You can now view the EL-IOT's data and change settings either in the EasyLog Cloud App or by visiting your account at: <a href="https://www.easylogcloud.com">www.easylogcloud.com</a>

## **Button Functions**


The main button is used to control the EL-IOT's functions, some of which also create an audit event that can be viewed using the EasyLog Cloud App or website.




Button Press	Short Press < 1s	Long Press Between 1s and 10s	Press & Hold > 10s
Function	Mutes the alarm sou nder	Acknowledges an alarm, creates a n audit event in the record, forces data synchronisation with the Clou	Activates Configuration mode to reconnect with the App

A long press also indicates the current WiFi signal with the sounder and WiFi indicator from 1 = weak to 5 = stro ng.

# Getting to know your EL-IOT data logger





- 1. Data logger functioning indicator
- 2. Alarm indicator
- 3. Battery low indicator
- 4. WiFi functioning indicator
- 5. Main button
- 6. Mains power socket\*
- 7. Smart probe socket
- 8. Battery compartment

- 9. Reset button
- Mains power supply sold separately

## **Indicators and Sounder**



The EL-IOT has four indicators and a sounder to clearly show its current status. The sounder is active whenever there is an alarm.

Indicator	Flashing	Flashing			Flashing
Status	Device in operat ion, no alarms or warnings	Alarm / Memory Full / Calibration Expired	Battery Low	WiFi Active	WiFi set up mod e / not set up yet

# **Important Safety Information**

WARNING: Failure to follow these safety instructions could result in fire, electrical shock, other injury or damage.

## Repairing or modifying

Never attempt to repair or modify this product. Dismantling, may cause damage that is not covered under the warranty. Servicing should only be provided by an approved supplier. If the product has been punctured, or seriously damaged do not use it and return it to an approved supplier.

### **Power supply**

Only use 1.5V AA alkaline batteries or a genuine EL-IOT power supply to power your EL-IOT data logger. Power supply sold separately.

### Disposal and recycling

You must dispose of this product and batteries according to relevant laws and regulations. This product contains electronic components and therefore must be disposed of separately from household waste.

Caution: Do not leave product in direct sunlight. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

## **Technical Support**

**Lascar Electronics UK** 

Telephone: +44 (0) 1794 884 567 Email: sales@lascar.co.uk

**Lascar Electronics US** 

Telephone: +1 (814) 835-0621

Email: us-sales@lascarelectronics.com

Lascar Electronics HK
Telephone: +852 2389 6502
Email: saleshk@lascar.com.hk

www.lascarelectronics/data-loggers

### **Documents / Resources**



<u>EasyLog EL-IOT Wireless Cloud-Connected Data Logger</u> [pdf] User Guide EasyLog, EL-IOT, Wireless, Cloud-Connected, Data Logger

Manuals+,