



EATON DIULM7 Reversing Contactor Instructions

[Home](#) » [EATON](#) » EATON DIULM7 Reversing Contactor Instructions 

Contents

- [1 EATON DIULM7 Reversing Contactor](#)
- [2 Electric current! Danger to life!](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)



EATON DIULM7 Reversing Contactor



Electric current! Danger to life!


Only skilled or instructed persons may carry out the following operations.

DIULM7


DIULM32 (DIULM40 DIULM150)

XTCR007B

XTCR032B (XTCR040DXTCR150G)



Q11 Mains contactor, clockwise
Q12 Mains contactor, anti-clockwise




SDAINLM12-SDAINLM55


(SDAINLM70-SDAINLM260)

XTSD012B10...-XTSD055C10...

(XTSD070D11...-XTSD260G11...)




Q11 Mains contactor
Q15 Delta contactor
Q13 Star contactor
K1 Timing relay



53115 Bonn, Germany Eaton.com/contacts Eaton.com/aftersales Eaton.com/documentation USA:
Eaton.com/eatoncare
08/21 IL03407030Z
UK: Eaton Electric Ltd., P.O. Box 554, Abbey Park,
Southampton Road, Titchfield, PO14 4QA, United Kingdom Eaton.com/recycling

Documents / Resources

	<p>EATON DIULM7 Reversing Contactor [pdf] Instructions DIULM7, DIULM32, DIULM40, DIULM150, Reversing Contactor</p>
---	--

[Manuals+](#)