



## **ECHOMASTER BUA-97C Backup Alarm Instruction Manual**

[Home](#) » [Echomaster](#) » **ECHOMASTER BUA-97C Backup Alarm Instruction Manual** 

### **ECHOMASTER BUA-97C Backup Alarm**




## Contents

- 1 [Box Contents:](#)
- 2 [Wiring Diagram](#)
- 3 [Dimensions:](#)
- 4 [ox Contents:](#)
- 5 [Wiring Diagram](#)
- 6 [Dimensions:](#)
- 7 [Customer Support](#)
- 8 [Documents / Resources](#)
  - 8.1 [References](#)
- 9 [Related Posts](#)




## Box Contents:

- [Back Up Alarm](#)
- [Screws](#)
- [Manual](#)

## Wiring Diagram



## Dimensions:




<b>Part Number:</b>	<b>BUA-97C</b>
Power:	15W
Voltage:	DC12-24V
Current:	300mA
dB/M:	97dB
Material:	Nylon
Color	Black
Frequency:	3375Hz
Cycle:	8 0 5/minute
Operating Temp:	-40 – +85
Waterproof:	IP67




#### **Box Contents:**

- **Back Up Alarm**
- **Screws**
- **Manual**

#### **Wiring Diagram**



**Dimensions:**



<b>Part Number:</b>	<b>BUA-97C</b>
Power:	15W
Voltage:	DC12-24V
Current:	300mA
dB/M:	97dB
Material:	Nylon
Color	Black
Frequency:	3375Hz
Cycle:	8 0 5/minute
Operating Temp:	-40 – +85
Waterproof:	IP67

Echo Master backup alarms are designed to improve safety during backing up by providing loud tones in the vicinity of the vehicle.

Please ensure you read and understand all aspects of this manual before fitting or using your Echo Master backup alarm. Choose a suitable mounting place dependent on the application. Ensure that there are no wiring harnesses or hoses/pipes located behind the panel before drilling.

## Customer Support

email – [support@aampglobal.com](mailto:support@aampglobal.com)  
phone – 866-931-8021  
15500 Lightwave Drive, Suite 202  
Clearwater, Florida 33760  
**Echo Master is a Power Brand of AAMP Global**  
[EchoMaster.com](http://EchoMaster.com)



## Documents / Resources

<p>Echomaster backup alarms are designed to improve safety during backing up by providing loud tones in the vicinity of the vehicle.</p> <p>Please ensure you read and understand all aspects of this manual before fitting or using your Echomaster backup alarm. Choose a suitable mounting place dependent on the application. Ensure that there are no wiring harnesses or hoses/pipes located behind the panel before drilling.</p> <p>email: <a href="mailto:sales@echomaster.com">sales@echomaster.com</a> phone: +353-91-822111</p> <p>10001 Lifford Road, Suite 202 Clonsilla, Finglas D17, Ireland</p> <p><b>Echomaster</b> is a Power Brand of <b>AMP Global</b> Echomaster.com</p>	<p><a href="#">ECHOMASTER BUA-97C Backup Alarm</a> [pdf] Instruction Manual BUA-97C Backup Alarm, BUA-97C, Backup Alarm, Alarm</p>
--	--

## References

- [Echomaster – Aftermarket Vehicle Safety Products for Consumer and Commercial Drivers](#)

**Manuals+**