

ecler ePHS30Ti Public Address Loudspeaker User Manual

Home » ecler ePHS30Ti Public Address Loudspeaker User Manual

Contents

- 1 ecler ePHS30Ti Public Address
- Loudspeaker
- **2 Technical Specifications**
- 3 Connecting
- 4 Maintenance
- **5 Caution**
- 6 FAQs
 - 6.1 Documents / Resources
 - 6.1.1 References
 - **6.2 Related Posts**



ecler ePHS30Ti Public Address Loudspeaker





Technical Specifications

ePHS30Ti	
Power	30WRMS @ 8Ω
Power options @ 100V	30W / 15W / 7,5W / 3,75W / OFF & 8Ω
Power options @ 70V	15W / 7,5W / 3,75W / 1,9W & 8Ω
Frequency response (-10dB) 1	300 Hz-10 kHz
Coverage angle2	107°x107° (HxV)
Sensitivity 1W/1m3	104 dB
IP rating	IP66 (IEC60529 Certified)
Finished color	Light grey (RAL 7035)
Material	ABS Horn
Operating and storage conditions	Min -20°C (-4°F); Max +60°C (+140°F)
Cord length	350mm / 13.8"
Dimensions (Ø x L)	Ø 246 x 292mm / Ø 9.7" x 11.5"
Weight	2,4 kg. / 5.3 lb. (including accessories)

- 10dB below the sound pressure level at specified sensitivity
- 6dB below the sound pressure level than that at the direction of maximum level. Max. angle between 1 kHz and 4 kHz.
- Measured on-axis, far field and referenced to 1 meter by inverse square law. Average from 100 Hz to 10 kHz.

MAIN SPECIFICATIONS

- Water-resistant ABS horn loudspeaker
- 30 W RMS @ 8 Ω
- Power selector:
 - 100V: 30W / 15W / 7,5W / 3,75W70V: 15W / 7,5W / 3,75W / 1,9W
- OFF (turn off) and 8 Ω positions
- · IP66 certification
- · Connection by bare wire
- Finished in light grey (RAL 7035)

Product Usage Instructions

INTRODUCTION

ePHS30Ti is a 30W horn loudspeaker, carefully selected for the most widespread 70/100V applications: paging and background Music. They offer durability and an optimal voice and music reproduction. Made of reinforced ABS and IP66 certified, ideal for high performance outdoors.

Connecting

The ePHS30Ti loudspeaker can operate in high or low impedance modes. It comes pre-configured for operation with a 70/100V 30W line. Use the power selector located on the rear panel to adjust the power options accordingly.

Location and Installation

When installing the ePHS30Ti loudspeaker, ensure that it is placed in a location that allows for optimal sound projection and coverage. Avoid blocking any ventilation openings and keep the speaker away from heat sources. Remember that high frequencies are directional, so position the speaker carefully to avoid any obstacles that may affect sound quality.

Maintenance

For optimal performance, it is recommended to carry out all maintenance tasks on the ePHS30Ti loudspeaker by authorized technical personnel. Regular maintenance will ensure the longevity and effectiveness of the product.

Caution

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: To prevent fire or shock hazard, do not expose this equipment to rain or moisture.

WARNING: An apparatus with Class I construction shall be connected to a mains socket-outlet with a protective earthing connection.

IMPORTANT SAFETY INSTRUCTIONS

- · Read these instructions.
- Keep these instructions.
- · Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- · Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with
 one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or
 the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an
 electrician for replacement of the obsolete outlet.
- · Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and

at the point where they exit from the apparatus.

- Only use attachments/accessories specified by the manufacturer.
- Unplug the apparatus during lightening sorts or when unused for long periods of time.
- Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any
 way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the
 apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been
 dropped.
- Disconnecting from mains: Switching off the POWER switch all the functions and light indicators of the amplifier will be stopped, but fully disconnecting the device from mains is done unplugging the power cord from the mains input socket. For this reason, it always shall remain readily operable.
- Equipment is connected to a socket-outlet with earthing connection by means of a power cord.
- The marking information is located at the bottom of apparatus.
- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.

CONNECTING

ePHS30Ti operates into high or low impedance. For this reason, it incorporates a power selector located on the rear panel. As supplied, this connector can be used pre-configured for operation with a 70/100V 30 W line.




Figure 1: rear panel's power selector

Note: If the loudspeaker is used in 70V installations, the corresponding powers for the 100V position will be reduced to half those indicated on the switch. To one quarter for 50V installations.

The low-impedance connection will allow the loudspeakers to be configured for operating under these conditions with a maximum power of 250 W. If this setup is adopted, consideration must be given to amplifier limits when several loudspeakers are connected to its output, especially if the overall impedance is below 4 Ω . Furthermore, it is important that the cable connecting the amplifier outputs to the loudspeakers is of good quality and as short as possible; this is of special significance when long distances have to be covered and loudspeaker impedance is low.

Note: The loudspeaker distribution along a 70/100V line historically arises from the technical requirement to mix loudspeakers of different impedances and/or powers on the same amplification line or channel, but without any need to worry about the total impedance of the full assembly. Moreover, this solution enables long cable runs with significantly smaller sections that those usually employed in low-impedance installations, but with minimum power losses.

WARNING! If the system is accidentally connected with the switch in the 100 V/60 W position to a low-impedance amplifier, no damage will be caused to the loudspeaker, but its performance will be well below its specifications. If the loudspeaker is accidentally connected to a 70/100 V line, in the 8Ω , it will be seriously damaged.

CONTENTS OF THE PACKAGE

- ePHS30Ti
- · User's quick guide
- · Warranty card

LOCATION AND INSTALLATION

In general, the following rules will be followed:

- The unit must always be installed on firm, solid surfaces.
- Ensure that the surface on which the loudspeaker is to be installed can withstand its weight.
- Always use a safety cable to secure the loudspeaker installation.
- For good sound reproduction, there must not be any obstacles between the loudspeaker and the audience.

High frequencies, unlike bass frequencies, are extremely directional and any obstacle will involve attenuation in their response.

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



WARNING: This product must not be discarded, under any circumstance, as unsorted urban waste. Take to the nearest electrical and electronic waste treatment centre.

NEEC AUDIO BARCELONA, S.L. accepts no liability for any damage that may be caused to people, animal or objects due to failure to comply with the warnings above.

IMPORTANT NOTE

Congratulations. You now possess the result of careful design and meticulous manufacturing. We are very grateful for your trust in purchasing our horn loudspeaker ePHS30Ti.

In order to obtain maximum effectiveness and performance, it is VERY IMPORTANT, prior to connection, to carefully read and to take into account the instructions given in this manual. To guarantee optimum operation, we recommend that all maintenance be carried out by our authorised Technical.

Contact

All product characteristics are subject to variation due to production tolerances. NEEC AUDIO BARCELONA S.L. reserves the right to make changes or improvements in the design or manufacturing that may affect these product specifications.

For technical queries contact your supplier, distributor or complete the contact form on our website, in Support / Technical requests.

Motors, 166-168 | 08038 Barcelona, Spain | Tel. (+34) 932238403 | information@ecler.com | www.ecler.com

_

FAQs

Q: Can the ePHS30Ti loudspeaker be used outdoors?

Yes, the ePHS30Ti loudspeaker is IP66 certified, making it ideal for outdoor use due to its high durability and weather resistance.

Q: How do I adjust the power options on the ePHS30Ti loudspeaker?

The power selector located on the rear panel of the speaker allows you to switch between high and low impedance modes, ensuring compatibility with different setups.

Documents / Resources



<u>ecler ePHS30Ti Public Address Loudspeaker</u> [pdf] User Manual 50-0338-0102, ePHS30Ti Public Address Loudspeaker, ePHS30Ti, Public Address Loudspeaker, Address Loudspeaker, Loudspeaker

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.