


ECOLAB PLUS-0617631A Advanced Main Station User Guide

[Home](#) » [ECOLAB](#) » ECOLAB PLUS-0617631A Advanced Main Station User Guide 

ECOLAB PLUS-0617631A Advanced Main Station



Contents



- 1 Operation Instructions
 - 1.1 Start/Preparing: Rinsing
 - 1.2 Preparing: Foaming
 - 1.3 Change cleaning agent
 - 1.4 Disinfection using P3-User Pack
 - 1.5 Stop Procedure
- 2 Documents / Resources
 - 2.1 References
- 3 Related Posts



Operation Instructions

1. The machine must only be operated by instructed personnel.
2. Follow the instructions from the supplier of detergents.
3. Always wear suitable clothing and footwear.
4. Never direct the water jet towards people, pets or electric installations.
5. Never block the release of the spray handle.
6. Always activate any locking device on the spray handle when replacing nozzles.
7. Only use the water from the system for cleaning purposes.


Note: As an illustration of a spray handle, an Atlantic 450 is shown.



Start/Preparing: Rinsing







Preparing: Foaming







Change cleaning agent








>20 sec.











Disinfection using P3-User Pack









Stop Procedure












Ecolab GmbH & Co. OHG
P.O. Box 13 04 06
D-40554 Düsseldorf
www.ecolab.com
Tel.: +49 211 98 93 203 – Fax: +49 211 98 93 223



Documents / Resources

	<p>ECOLAB PLUS-0617631A Advanced Main Station [pdf] User Guide PLUS-0617631A Advanced Main Station, PLUS-0617631A, Advanced Main Station</p>
---	--

References

- [ECOLAB Water, Hygiene and Infection Prevention Solutions and Services | Ecolab](#)

Manuals+.