



# EDIFIER G33BT Hecate Wireless Low Latency Gaming Headset User Manual

[Home](#) » [Edifier](#) » EDIFIER G33BT Hecate Wireless Low Latency Gaming Headset User Manual 

## EDIFIER<sup>®</sup>


### Contents

- [1 EDIFIER G33BT Hecate Wireless Low Latency Gaming Headset](#)
- [2 Product description](#)
- [3 Power on/off](#)
- [4 Bluetooth connection](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

## EDIFIER G33BT Hecate Wireless Low Latency Gaming Headset



### Product description



## Power on/off

- When the headset is powered off, press and hold the "fi" button for 3 seconds, then the headset will power on.
- When the headset is powered on, press and hold the "a" button for 6 seconds, then the headset will power off.

## Bluetooth connection

- When the headset is powered off, press and hold the "G" button for 3 seconds to let it enter Bluetooth pairing state (the red and blue lights flashing). Bluetooth device to search for and connect to "HECATE G33BT", after pairing is successful, the blue light will flash slowly.
- When the headset is powered on and not connected with any devices, press and hold the "fi" button for 3 seconds to let it enter Bluetooth pairing state.
- It enters Bluetooth pairing state by default when the headset is powered on for the first time, and it will auto-connect to the Bluetooth device connected last time when powered on again.

## Documents / Resources



[EDIFIER G33BT Hecate Wireless Low Latency Gaming Headset](#) [pdf] User Manual  
G33BT, Bluetooth Gaming Headset, G33BT Bluetooth Gaming Headset, EDF700011, G33BT H  
ecate Wireless Low Latency Gaming Headset, Hecate Wireless Low Latency Gaming Headset