




EDIFIER MR3 Studio Monitor User Manual

[Home](#) » [Edifier](#) » **EDIFIER MR3 Studio Monitor User Manual** 

EDIFIER MR3 Studio Monitor User Manual



Contents

- 1 EDIFIER ConneX app
- 2 What's in the box?
- 3 Cable connection
- 4 Mode switch
- 5 Control
- 6 Indicator status
- 7 Bluetooth connection
- 8 Multipoint connection
- 9 Acoustic tuning
- 10 Specifications
- 11 Troubleshooting
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts

EDIFIER ConneX app

With this app, you can

- control play from the Bluetooth source device,
- control the master volume,
- select sound effects or customize EQs,
- perform acoustic tuning,
- upgrade the firmware, and
- more functions.

EDIFIER ConneX app




Download EDIFIER ConneX app

1. With your smart device, scan the QR code on the quick start guide or the packaging.
 - You can also search for “EDIFIER ConneX” in Apple App Store (iOS devices) or Google Play (Android devices).
2. Download and install the app.


How to use this app

1. Connect your smart device with the speaker via Bluetooth.
2. In Bluetooth mode, open EDIFIER ConneX App on your smart device.
3. Tap the menu for settings and playback control.


What's in the box?




Passive speaker



Active speaker



Speaker connecting cable



3.5mm to RCA audio cable



3.5mm to 3.5mm audio cable



Power cable



Quick start guide





Important safety instructions

Note:

- Images are for illustrative purpose only and may differ from the actual product.
- For the need of technical improvement and system upgrade, information and specifications contained herein may be slightly different from actual product. If any difference is found, the actual product prevails.

Cable connection






Note:






- Power input: 100-240V~ 50/60Hz 300mA
- This plug type is meant for illustrative purpose only.
- All audio inputs including Bluetooth connection can be used in parallel.
- The speaker will be muted when you connect your headphone to the " " port.
You can control the headphone volume with the volume knob on the speaker.

Mode switch



Press and hold the “” knob to switch the speaker between work mode and standby mode.

Control


Button/Knob	Mode	Action
	Work mode	Press to switch sound effects.
	Work mode	Rotate clockwise to increase volume.
	Work mode	Rotate counterclockwise to decrease volume.
	Bluetooth device connected	Press and hold to disconnect the current Bluetooth device and switch the speaker to Bluetooth pairing mode.
	Bluetooth hiddenmode	Press to exit Bluetooth hidden mode and enter Bluetooth pairing mode.

Note: Volume sync is not supported. To adjust the volume, adjust on the speaker and your device separately.



Indicator status


Indicator status	Speaker status
Solid red	Monitor sound effect
Solid green	Music sound effect
Solid white	Customized sound effect
Blinking	Bluetooth pairing mode
Blinking and then in solid	Bluetooth device connected
Blinking in red and green	Upgrading the firmware


Bluetooth connection

1. Press the "  " button on the speaker. The indicator will blink.
2. On your device, select "EDIFIER MR3" in its Bluetooth device list to connect.


The indicator will be steadily lit when the connection is established.

- The speaker will automatically reconnect to the last-connected Bluetooth device after it is switched to work mode. If not, press the "  " button on the speaker to activate the re-connection.
- To disconnect from the current Bluetooth device, press and hold the "  " button on the speaker for 1.5 seconds.







Note:

- Pin code for connection is “0000” if needed.
- To enjoy all Bluetooth functions of this product, make sure that your audio source device supports A2DP and AVRCP profiles.
- If no device is connected in 3 minutes, the speaker will switch to Bluetooth hidden mode. In this mode, (1) new devices cannot find the speaker, but (2) for a device that exists in the pairing record of this speaker, you can select “EDIFIER MR3” from its Bluetooth device list to reconnect. To exit from Bluetooth hidden mode, press the “” button on the speaker.

Multipoint connection



This speaker supports the simultaneous connection of two Bluetooth devices.


1. Connect the first Bluetooth device to the speaker.
2. Press and hold the “” button on the speaker for 1.5 seconds.
3. On the second Bluetooth device, select “EDIFIER MR3” in its Bluetooth device list to connect.
4. On the first Bluetooth device, select “EDIFIER MR3” in its Bluetooth device list to reconnect.
 - Pause or stop playback on the current Bluetooth device before streaming audio from the second one.

Acoustic tuning

By the speaker knobs

“High” knob: Turn the knob to boost or cut high frequencies above 10kHz by $\pm 6\text{dB}$.

“Low” knob: Turn the knob to boost or cut low frequencies around 125Hz by $\pm 6\text{dB}$.




By the EDIFIER ConneX App

Low cutoff: Attenuate frequencies lower than the specified frequency (20-100Hz) at a selected slope (6, 12, 18, or 24dB/octave).

Acoustic space: Select a gain level to compensate for the bass boost, which varies with speaker placement, 0dB for being in the middle of the room and -4dB for being in the corner. The closer the speaker is to a wall or corner, the smaller the value is to be set.

Desktop control: When the speaker is placed on a desktop or an object is placed in front of it, there may be an apparent increase in the decibel level at certain frequencies. Enable the feature to mitigate this effect.



Specifications

Total output power (RMS): 18W+18W (DRC on)

Frequency response: 52Hz-40kHz

Declaration for EU

Frequency Band: 2.402GHz ~ 2.480GHz

RF Power Output: ≤13 dBm (EIRP) There is no restriction of use.

Troubleshooting

Cannot connect to your Bluetooth device

- Make sure that the distance between this product and your Bluetooth device is less than 10 meters and there are no obstacles between them.
- Make sure that no device is connected to this product via Bluetooth.
- Make sure that this product is in Bluetooth pairing mode. If not, manually switch it to this mode.
- Restart this product, enable Bluetooth function on your Bluetooth device, and then try again.
- Reset this product to factory settings and try again.

No power

- Make sure that the power cable is properly connected.
- Make sure that the power supply is not disconnected.

No sound

- Make sure that this product and your device is properly connected.
- Make sure that the correct audio input source is selected.
- Make sure that the playback is not paused.
- Increase the volume of this product and your device.

Noise coming from speakers

EDIFIER speakers generate little noise, while the background noise of some audio devices are too high. Please unplug audio cables and turn the volume up. If no sound can be heard at 1 meter away from the speaker, there is no problem with this product.

To learn more about EDIFIER, please visit www.edifier.com For EDIFIER warranty queries, please visit the relevant country page on www.edifier.com and review the section titled Warranty Terms.

USA and Canada: service@edifier.ca

South America: Please visit www.edifier.com (English) or www.edifierla.com (Spanish/Portuguese) for local contact information.

EDIFIER®

Documents / Resources





— Manual —

EN 1. EDIFIER Connect app

With this app, you can:

- control play from the Bluetooth device directly
- control the master volume
- select sound effect or customize EQ
- adjust the equalizing
- upgrade the firmware, and
- more functions

Download EDIFIER Connect app



Download EDIFIER Connect app

1. On your smart device, use the QR code on the back of the speaker to get the app
2. Download and install the app


How to use the app

1. Connect your smart device with the speaker via Bluetooth
2. If Bluetooth mode, open EDIFIER Connect App on your smart device
3. Use the icons for settings and playback controls

2. What's in the box?




Front speaker Back speaker




Note:
• The speaker is for Bluetooth connection only and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.

3. Cable connection



Note:
• The speaker is for Bluetooth connection only and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.

4. Mode switch



Press and hold the "Q" key to switch the speaker between music mode and standby mode.

5. Control

Buttons	Mode	Action
BT	BT mode	Press to switch between BT and FM
FM	FM mode	Press to switch between BT and FM
BT	BT mode	Press to switch between BT and FM
BT	BT mode	Press to switch between BT and FM
BT	BT mode	Press to switch between BT and FM
BT	BT mode	Press to switch between BT and FM
BT	BT mode	Press to switch between BT and FM
BT	BT mode	Press to switch between BT and FM
BT	BT mode	Press to switch between BT and FM
BT	BT mode	Press to switch between BT and FM


Note: Volume level is not adjustable. To adjust the volume, adjust on the speaker and your device separately.

6. Indicator status

Indicator status	Speaker status
Red and green	Speaker power on
Red and green	Speaker power on
Red and green	Speaker power on
Red and green	Speaker power on
Red and green	Speaker power on
Red and green	Speaker power on
Red and green	Speaker power on
Red and green	Speaker power on
Red and green	Speaker power on
Red and green	Speaker power on


7. Bluetooth connection

1. Press the "BT" button on the speaker. The indicator will blink.
2. On your device, select "EDIFIER MR3" in the Bluetooth device list to connect.
3. The speaker will automatically connect to the device. The speaker will automatically connect to the device.



Note:
• The speaker is for Bluetooth connection only and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.
• The speaker is not a portable device and may differ from the actual product.

8. HiPoint connection



EDIFIER MR3 Studio Monitor [pdf] User Manual

MR3 Studio Monitor, MR3, Studio Monitor, Monitor

[illegible]

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.