

EDIFIER S350DB Active Speaker User Manual

Home » Edifier » EDIFIER S350DB Active Speaker User Manual Ta





S350DB Active Speaker User manual

Contents

- 1 Important safety instruction
- 2 Important safety instruction
- 3 What's In The Box
- **4 Speaker Controls**
- **5 Remote Control**
- **6 Connections**
- 7 Optical and Coaxial Input
- 8 PC/AUX Input
- 9 Bluetooth Input
- 10 Specifications
- 11 Troubleshooting
- 12 Documents / Resources
- 13 Related Posts

Important safety instruction

- 1. Please read the instructions carefully. Keep it in safe place for future reference.
- 2. Use only accessories approved by the manufacturer.
- 3. Install the instrument properly by following the instructions in the device connection section.
- 4. Using the product in a 0-35¥ environment is recommended.
- 5. To reduce the risk of fire and electric shock, do not expose the product to rain or moisture.

- 6. Do not use this product near water. Do not immerge the product into any liquid or have it exposed to dripping or splashing.
- 7. Do not install or use this product near any heat source (e.g. radiator, heater, stove, or other devices that generate heat).
- 8. Do not place any object filled with liquids, such as vases on the product; neither should any open fire, such as lighted candles be placed on the product.
- 9. Do not block any ventilation openings. Do not insert any object into ventilation openings or slots. It may cause fire or electric shock.
- 10. Keep sufficient clearance around the product to maintain good ventilation (minimum 5cm is recommended).
- 11. Do not force a plug into the jack. Before connection, check for blockage in the jack and whether the plug matches the jack and is oriented to the right direction.
- 12. Keep the provided accessories and parts (such as screws) away from children to prevent from being swallowed by mistake.
- 13. Do not open or remove the housing yourself. It may expose you to dangerous voltage or other hazardous risks. Regardless the cause of damage (such as damaged wire or plug, exposure to liquid splash or foreign object falling in, exposure to rain or moisture, product not working or being dropped, etc.), the repair has to be performed by an authorized service professional immediately.
- 14. Before cleaning the product with dry cloth, always turn off the product and disconnect the power plug first.
- 15. Never use strong acid, alkali, gasoline, alcohol, or other chemical solvents to clean the product surface. Use only neutral solvent or clear water for cleaning.



Excessively loud music may lead to hearing loss. Please keep the volume in a safe range.



Correct Disposal of this product. This marking indicates that this product should not be disposed with ot her household wastes throughout the EU. To prevent possible harm to the environment or human healt h from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material r esources. To return your used device, please use the return and collection systems or contact the retail er where the product was purchased. They can take this product for environmental safe recycling.



Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the ap paratus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury f rom tip-over.

Important safety instruction

Power warning:

- 1. Place the product near the power outlet.
- 2. Before use, make sure that the operating voltage is the same as your local power supply. Correct operating voltage can be found on the product plate.
- 3. For safety purpose, unplug the product during lightning storms or when unused for extended periods of time.
- 4. Under normal conditions, the power supply may get hot. Please keep good ventilation in the area and exercise caution.
- 5. Safety warning labels on the housing or bottom of the product or power adaptor.

A	This symbol is to alert the user to the presence of un-insulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.
	This symbol is to warn the user not to disassemble the enclosure of the product and there is no user-replaceable part inside. Take the product to an authorized service center for repair.
	This symbol indicates that the product is for indoor use only.
	This symbol indicates that the product is a CLASS II or double insulated electrical device with no eart h requirement.

The MAINS plug is used as the disconnect device, the disconnect device shall remain readily operable.

For wireless product:

- 1. Wireless product may generate shortwave radio frequencies and interfere with the normal use of other electronic devices or medical equipment.
- 2. Turn off the product when it's disallowed. Do not use the product in medical facilities, on airplane, at gas stations, near automatic gates, automatic fire alarm system or other automated devices.
- 3. Do not use the product in the vicinity of a pacemaker within a 20cm range. The radio waves may affect the normal operation of the pacemaker or other medical devices.


What's In The Box


Passive Satellite speaker Passive Satellite speaker Active satellite speaker Power cable 3.5mm-RCA audio cable Speaker connecting cable


Fiber optic input cable


User manual

Speaker Controls









- 1. Power switch
- 2. Power cable connector
- 3. PC input
- 4. AUX input
- 5. Optical input
- 6. Coaxial input
- 7. Connect to satellite speaker(R)
- 8. Connect to satellite speaker(L)
- 9. Connect to subwoofer

- 10. Display screen
- 11. Treble volume dial
- 12. Bass volume dial
- 13. Master volume dial/input selection

Press it to navigate between audio inputs:


PC>AUX->Optical->Coaxial->Bluetooth.

Press and hold to enable and disable the standby

function 14. Power indicator

Remote Control

Remote control




- 1. ON/OFF
- 2. Optical input
- 3. Coaxial input
- 4. Bluetooth input
- 5. PC input
- 6. AUX input

- 7. Previous track
- 8. Volume increase
- 9. Volume decrease
- 10. Play/pause
- 11. Next track

Installation and replacement of controller battery:

As the illustration, please insert a coin into the slot and rotate anticlockwise to the "O" position to open battery cover, then place the CR2025 battery and rotate clockwise to the "O" position to close the cover.






- 1. Don't swallow the battery; danger of chemical burn.
- 2. The product includes a wafer battery. Swallowing this battery may lead to injury or death. Do not place the new or old battery in where children can get to it.
- 3. Don't use the product if the battery cover is missing or not closed, and keep the remote inaccessible to children.
- 4. Please go to the hospital immediately if the battery is swallowed.

Note:

- 1. Do not place the remote control in places that are hot and humid.
- 2. Do not charge the batteries.
- 3. Remove the batteries when unused for a long period of time.
- 4. The battery should not be exposed to excessive heat such as direct sun, fire or similar.
- 5. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

Connections



Optical and Coaxial Input

- 1. Press the master volume control on the active satellite speaker or press the "OPT/COX" button on the remote control to select optical/coaxial input.
- 2. Using optical or coaxial cable (optical cable included) to connect audio sources to your speaker.
- 3. Play from your devices and adjust the volume accordingly.

Note: In optical and coaxial modes, only PCM signal with 44.1KHz/48KHz can be decoded.

PC/AUX Input



- 1. Press the master volume control on the active satellite speaker or press the "PC/AUX" button on the remote control to select PC/AUX input.
- 2. Use the audio cable to connect audio sources (mobile phones, tablets etc) to your speaker.
- 3. Play from your device and adjust the volume accordingly.

Bluetooth Input



Pairing

- 1. Turn on speaker and switch to Bluetooth mode by pressing the Bluetooth button on the remote control or press the master volume control on the active satellite speaker until Bluetooth icon comes on.
- 2. Go to setup on your source devices (mobile phones, tablets, etc.) and search for nearby Bluetooth devices, you will find "EDIFIER S350DB" in the list.
- 3. Pair your device with "EDIFIER S350DB".
- 4. Play audio tracks on your device and adjust the volume to a desired level.
- 5. To disconnect Bluetooth, press and hold the Bluetooth button on the remote control.

Note:

- 1. Bluetooth on the product can be searched and connected only when speaker is ON and switch to the Bluetooth input. When the speaker is switch to other audio inputs, the Bluetooth connection will be disconnected. When switched to Bluetooth input, the speaker will try to connect the last connected Bluetooth source device.
- 2. Bluetooth connectivity and compatibility may be different among different source devices, depending on the software version of source devices.
- 3. To enjoy the full Bluetooth functions of this product, please ensure your mobile device supports A2DP and AVRCP profile.
- 4. PIN code for connection is "0000" if needed.
- 5. The built-in Qualcomm® aptXTM decoder in the product helps to achieve better wireless transmission sound quality, therefore please use the device supporting Qualcomm® aptXTM as the audio source.

Specifications

Power output:

R/L (treble): 15W+15W

R/L (mid-range and bass): 25W + 25W

SW: 70W 25dB(A)

Noise level:

≤25dB(A)

Frequency response range:

SW: 40Hz~160Hz R/L: 160Hz~20KHz

Audio inputs:

PC/Auxiliary/Optical/Coaxial/Bluetooth

Note: the rated test frequency is as follows: the treble test is 10KHz, mid-range and bass test is 500Hz, the bass test is 80Hz.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by EDIFIER is under license. Other trademarks and trade names are those of their respective owners.



Qualcomm® aptX™

Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries, used with permission. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries, used with permission. aptX is a product of Qualcomm Technologies International, Ltd.

Troubleshooting

Problem	Solution
	Check if the power indicator light is ON
No sound	Try to turn up the volume using either the master volume control or remote c ontrol.
TVO Sound	Ensure the audio cables are firmly connected and the input is set correctly o n the speakers.
	Check if there is a signal output from the audio source.
	Make sure the speaker is switched to Bluetooth input. If it is in other audio in put modes, Bluetooth will not conned. Disconnect from any Bluetooth device by pressing and holding the volume dial in Bluetooth mode, then try again.
Cannot connect via Bluetooth	Effective Bluetooth transmission range is 10 meters; please ensure that ope ration is within the range.
	Try another Bluetooth device for connection.
The S350DB does not turn on	Check if main power is connected, or if the wall outlet is switched on.

To learn more about EDIFIER, please visit www.edifier.com

For Edifier warranty queries, please visit the relevant country page on www.edifier.com and review the section titled Warranty Terms. USA and Canada: service@edifier.ca South America: Please visit www.edifier.com for local contact information.

Manual Edition 1.0, Oct. 2021 IB-200-S0350D-03







@Edifierglobal

@Edifier_Global

@Edifier_Global

Hereby, Edifier International Limited declares that the radio equipment type EDF100040 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet

address: https://www.edifier.com/int/eu-doc.html

Model: EDF100040 FCC ID: Z9G-EDF161 IC: 10004A-EDF161

Declaration for EU Frequency Band: 2.402GHz~2.480GHz

RF Power output: ≤20 dBm (EIRP)

There is no restriction of use.

Edifier International Limited

P.O. Box 6264 General Post Office Hong Kong

Tel: +852 2522 6989 Fax: +852 2522 1989 www.edifier.com

© 2021 Edifier International Limited. All rights reserved. Printed in China

NOTICE: For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice. Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

Documents / Resources



EDIFIER S350DB Active Speaker [pdf] User Manual

EDF161, Z9G-EDF161, Z9GEDF161, S350DB Active Speaker, Active Speaker, Speaker

Manuals+,