



Eigen Code 1111 Key Box with Combination Lock Instruction Manual

[Home](#) » [Eigen Code](#) » Eigen Code 1111 Key Box with Combination Lock Instruction Manual 

Eigen Code 1111 Key Box with Combination Lock



Contents

[1 SET YOUR OWN CODE](#)

[2 Installation Methods](#)

[3 Documents /
Resources](#)

[3.1 References](#)

[4 Related Posts](#)

SET YOUR OWN CODE


1. Enter code 0000




2. Move lever down and open




3. Slide lever from A to B




4. Enter your own new code and remember!



5. Slide lever from B to A




6. New code is set!




Installation Methods

Method 1: Install on wall


1. Mark the holes on the wall




2. Drill holes



3. Nail plugs in holes




4. Screw safe on wall




Method 2: Install on peephole


1. Dismantle peephole




2. Attach backplate




3. Attach safe by long screw



4. Ready to use!



Documents / Resources

	<p>Eigen Code 1111 Key Box with Combination Lock [pdf] Instruction Manual 1111 Key Box with Combination Lock, 1111, Key Box with Combination Lock, Box with Combination Lock, Combination Lock, Lock</p>
---	--

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.