EIKI V1700 Series 3LCD Laser Projector





EIKI V1700 Series 3LCD Laser Projector User Guide

Home » EIKI » EIKI V1700 Series 3LCD Laser Projector User Guide 🖺



Contents

- 1 EIKI V1700 Series 3LCD Laser
- **Projector**
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Installation
- **5 Frequently Asked Questions (FAQ)**
- 6 Documents / Resources
 - **6.1 References**
- 7 Related Posts



EIKI V1700 Series 3LCD Laser Projector



Product Information

Specifications

- Model: V1700 series
- Inputs: LASER, HDMI1, HDMI2, VGA, DVI, HDBASET, NETWORK, USB-A, USB-B
- Features: FOCUS, LENS SHIFT, ZOOM, PATTERN FREEZE, SCREEN, IMAGE KEYSTONE, D.ZOOM+,
 D.ZOOM-
- Connectivity: RS232, LAN, HDMI, USB-A, USB-B

Product Usage Instructions

Setup and Connectivity

Connect the appropriate input sources (LASER, HDMI, VGA, etc.) to the corresponding ports on the device.

Adjusting Settings

Use the remote or on-device controls to adjust settings such as FOCUS, LENS SHIFT, ZOOM, and PATTERN FREEZE for optimal display.


Image Control


Utilize features like IMAGE KEYSTONE to correct image distortion and D.ZOOM+/- to adjust digital zoom levels.

Additional Functions

Explore functions like TIMER and INFO to enhance your viewing experience.

Installation





Frequently Asked Questions (FAQ)

Q: How do I change the input source?

A: Use the input selection button on the remote control or the device itself to switch between different input sources.

Q: Can I adjust the focus manually?

A: Yes, you can manually adjust the focus using the FOCUS control feature on the device.

Q: What is the purpose of the PATTERN FREEZE function?

A: The PATTERN FREEZE function allows you to freeze a specific pattern or image on the screen for detailed analysis or comparison.

Documents / Resources



EIKI V1700 Series 3LCD Laser Projector [pdf] User Guide

V1700 Series, V1700 Series 3LCD Laser Projector, 3LCD Laser Projector, Laser Projector, Projector

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.