

# **Einhell SPK1 Tire Pressure Gauge Tire Inflator Instruction Manual**

Home » Einhell » Einhell SPK1 Tire Pressure Gauge Tire Inflator Instruction Manual





Art.-№: 41.370.00 I.-№: 01059



When using the equipment, a few safety precautions must be observed to avoid injuries and damage. Please read the complete operating instructions and safety regulations with due care. Keep this manual in a safe place, so that the information is available at all times. If you give the equipment to any other person, hand over these operating instructions and safety regulations as well. We cannot accept any liability for damage or accidents which arise due to a failure to follow these instructions and the safety instructions.

### Scope of use

Please note that our equipment has not been designed for use in commercial, trade or industrial applications. Our warranty will be voided if the machine is used in commercial, trade or industrial businesses or for equivalent purposes.

The machine is to be used only for its prescribed purpose. Any other use is deemed to be a case of misuse. The user / operator and not the manufacturer will be liable for any damage or injuries of any kind caused as a result of this.

#### **Contents**


- 1 Safety instructions
- 2 Items supplied
- 3 Quick-release coupling
- 4 Operation
- 5 Cleaning and maintenance
- 6 Ordering replacement parts
- 7 Disposal and recycling
- 8 Documents / Resources 8.1 References

## Safety instructions

#### 1.1 Safety instructions for working with copressed air and blasting guns

- Compressors and lines reach high temperatures during operation. Avoid contact! Risk of burns!
- Gases or vapours drawn in by the compressor have to be kept free of constituents that may cause fire or explosions inside the compressor.
- When you disconnect the hose coupling, hold the coupling element in your hand to prevent injury from the whiplashing hose.
- Wear goggles when working with the blow-out gun. Injuries may easily result from foreign bodies and blasted parts.
- Never point the blow-out gun at other persons and never use it to clean clothes that are still being worn.

Keep these safety instructions in a safe place.



## Items supplied

• Tire pressure gauge

## **Quick-release coupling**

#### Connect

Push the nipple on your compressed air hose into the quick-release coupling, the sleeve will automatically spring forwards.

#### **Disconnect**

Pull back the sleeve and remove the hose.

**Important.** As you release the hose coupling, hold the hose coupling part in your hand to prevent injuries caused by the hose being thrown

## Operation

• Tire pressure gauge

Working pressure in bar: 0-8 Range of applications:

The tire pressure gauge allows you to inflate tires easily and exactly. Use the pressure gauge to check the tire pressure. If the tire pressure is too high, you can reduce the pressure with the integrated relief valve ().

#### Cleaning and maintenance

#### 5.1 Cleaning

- We recommend that you clean the appliance immediately after you use it.
- Clean the accessories after use with a suitable cleaning agent (observe the instructions on the working materials).

## Ordering replacement parts

Please quote the following data when ordering replacement parts:

- Type of machine
- · Article number of the machine
- Identification number of the machine
- Replacement part number of the part required

For our latest prices and information please go to <a href="https://www.isc-gmbh.info">www.isc-gmbh.info</a>

## Disposal and recycling

The unit is supplied in packaging to prevent its being damaged in transit. This packaging is raw material and can therefore be reused or can be returned to the raw material system.

The unit and its accessories are made of various types of material, such as metal and plastic. Defective components must be disposed of as special waste. Ask your dealer or your local council.

The reprinting or reproduction by any other means, in whole or in part, of documentation and papers accompanying products is permitted only with the express consent of ISC GmbH. Technical changes subject to change

#### **GUARANTEE CERTIFICATE**

#### Dear Customer,

All of our products undergo strict quality checks to ensure that they reach you in perfect condition. In the unlikely event that your device develops a fault, please contact our service department at the address shown on this guarantee card. Of course, if you would prefer to call us then we are also happy to offer our assistance under the service number printed below. Please note the following terms under which guarantee claims can be made:

- 1. These guarantee terms cover additional guarantee rights and do not affect your statutory warranty rights. We do not charge you for this guarantee.
- 2. Our guarantee only covers problems caused by material or manufacturing defects, and it is restricted to the rectification of these defects or replacement of the device. Please note that our devices have not been designed for use in commercial, trade or industrial applications. Consequently, the guarantee is invalidated if the equipment is used in commercial, trade or industrial applications or for other equivalent activities. The following are also excluded from our guarantee: compensation for transport damage, damage caused by failure to comply with the installation/assembly instructions or damage caused by unprofessional installation, failure to

comply with the operating instructions (e.g. connection to the wrong mains voltage or current type), misuse or inappropriate use (such as overloading of the device or use of non-approved tools or accessories), failure to comply with the maintenance and safety regulations, ingress of foreign bodies into the device (e.g. sand, stones or dust), effects of force or external influences (e.g. damage caused by the device being dropped) and normal wear resulting from proper operation of the device. The guarantee is rendered null and void if any attempt is made to tamper with the device.

- 3. The guarantee is valid for a period of 2 years starting from the purchase date of the device. Guarantee claims should be submitted before the end of the guarantee period within two weeks of the defect being noticed. No guarantee claims will be accepted after the end of the guarantee period. The original guarantee period remains applicable to the device even if repairs are carried out or parts are replaced. In such cases, the work performed or parts fitted will not result in an extension of the guarantee period, and no new guarantee will become active for the work performed or parts fitted. This also applies when an on-site service is used.
- 4. In order to assert your guarantee claim, please send your defective device postage-free to the address shown below. Please enclose either the original or a copy of your sales receipt or another dated proof of purchase. Please keep your sales receipt in a safe place, as it is your proof of purchase. It would help us if you could describe the nature of the problem in as much detail as possible. If the defect is covered by our guarantee then your device will either be repaired immediately and returned to you, or we will send you a new device.

Of course, we are also happy offer a chargeable repair service for any defects which are not covered by the scope of this guarantee or for units which are no longer covered. To take advantage of this service, please send the device to our service address.

0	Service Hotline: 01805 120 509 · www.isc-gmbh.info		
Name:			Retouren-Nr. iSC:
Straße / Nr.:			Telefon:
LZ	Ort		Mobil:
Velcher Fehle ③	r ist aufgetreten (genaue Angabe):	ArtNr.:	L-Nr.:
bitte beschreibe für Sie Ihre Rek		chneller helfen. Eine zu ungenaue Besch	eanstandung möglichst genau. Dadurch können wir reibung mit Begriffen wie "Gerät funktioniert nicht"
Garantie:	JA	atum:	
	ontaktieren oder bei ISC-Webadresse anmelder, angeben I @ Garantiefall JA/NEIN ankreuz		etellt I ❷ Ihre Anschrift eintragen I ❷ Fehlerbeschreib und eine Kopie des Kaufbeleges bellegen

www.isc-gmbh.info



<u>Einhell SPK1 Tire Pressure Gauge Tire Inflator</u> [pdf] Instruction Manual SPK1 Tire Pressure Gauge Tire Inflator, SPK1, Tire Pressure Gauge Tire Inflator, Pressure Gauge Tire Inflator, Tire Inflator

## References

• ISC GmbH Spareparts for Tools and Gardenequipment

Manuals+,