



# eklectik TWKB100 Wireless Backlit Keyboard User Manual

[Home](#) » [eklectik](#) » eklectik TWKB100 Wireless Backlit Keyboard User Manual 

eklectik TWKB100 Wireless Backlit Keyboard




## Contents



- [1 Overview](#)
- [2 Charging Your Screenwriter Keyboard](#)
- [3 Connecting The Keyboard To Your Device](#)
- [4 Using The Screenwriter Keyboard](#)
- [5 Specifications](#)
- [6 Safety Statement](#)
- [7 FCC Statement](#)
- [8 Eklectik One Year Limited Warranty](#)
- [9 Customer Support](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)

## Overview

## Top View



## Back View




Type-C charging cable

1. Light Mode Switch
2. 24. Left/Right knob
3. Function keys
4. Escape key
5. Numeric keys
6. Tab key
7. Caps Lock key
8. Alphabetical keys
9. 17. Shift keys
10. Ctrl key
11. Windows key
12. 15. Alt keys

13. Spacebar
14. Symbol keys
15. Fn key
16. Enter key
17. Arrow keys
18. Navigation keys
19. Backspace Key
20. Delete key
21. Scroll Lock key
22. Status LED Indicators
23. Scroll Lock key
24. Status LED Indicators
  - A. Bluetooth / USB Indicator
  - B. Windows Lock indicator
  - C. Caps Lock Indicator
  - D. Battery Indicator
25. Print Screen key
26. Phone/ Tablet stand
27. Bluetooth/USB Mode Switch
28. Operating System Switch
29. Type-C Charging Port

## Charging Your Screenwriter Keyboard

To charge your Screenwriter Keyboard, connect one end of the charging cable to the Type-C charging port of the keyboard, and connect the other end to a USB power source. When the keyboard is charging, the Battery indicator will glow blue. When it is fully charged, the Battery indicator will turn off.



**NOTE:** When the battery power is low, the battery indicator will rapidly flash blue.


## Connecting The Keyboard To Your Device

The Screenwriter Keyboard supports most display devices, including Smartphones, Tablets, and Computers.

### A: Bluetooth Mode


#### Connect to your mobile Bluetooth device

1. Slide the Mode Switch at the back of keyboard to the “BT” position, and the keyboard will enter Bluetooth pairing mode. Make sure the Operating System Switch is sided to set to the right position (depending on the operating system of your device.).



2. Press and hold the “Fn” key, and press and hold any of the pairing keys “Q”, “W” and “E”, until the Bluetooth indicator rapidly flashes blue.
3. Turn on Bluetooth in your device’s settings and search for “TWKB100”. Tap “TWKB100” to connect.

## Bluetooth connection with your tablet



### What your blue light means:

LED Indicator is flashing blue	Bluetooth is turned on ( In Bluetooth pairing mode)
LED Indicator is flashing faster	Pairing Key (Q, W, & E) has been activated
LED Indicator is solid blue	Device connected successfully

To connect multiple devices to the keyboard at the same time (the keyboard can be paired with up to three devices simultaneously), repeat Steps 1-3, but press and hold Fn with a different Pairing Key. For example, if you use the Q key for your phone, use the W key for pairing your tablet.

### TIPS:


- When connecting to more than one device, if you use the same pairing key on the second device, the keyboard will automatically disconnect with the currently connected device, and will be connected with the second device.
- To switch between multiple connected devices, press and hold “**Fn**” key, and press the corresponding pairing key.
- The keyboard will automatically be paired with your last paired device next time it is turned on.

### B: USB Mode

#### Wired connection with Your Computer

To connect the keyboard with your device via the wired (charging) cable, slide the **Mode Switch** to the “**USB**” position, and slide the **Operating System Switch** to the correct position (your device’s operating system). Connect the included USB-Type C cable to the Type C port of the keyboard, and to the USB port of your

computer. When the keyboard is successfully connected with your computer, the USB indicator will glow red .



**NOTE:** In USB mode, when your PC goes into sleep, your keyboard will as well.

## Using The Screenwriter Keyboard

### NOTES:

### Keyboard Shortcuts

Fn + F1 (Method: Press and Hold “ <b>Fn</b> ” key, then press “ <b>F1</b> ” key.)	My Computer	F1	Decrease Screen Brightness
Fn+F2	Search	F2	Increase Screen Brightness
Fn+F3	Calculator	F3	Show all open windows
Fn+F4	Media	F4	See all apps / programs
Fn+F S	Previous track	FS	Decrease Keyboard Brightness
Fn+ F6	Next track	F6	Increase Keyboard Brightness
Fn+F7	Play / Pause	F7	Previous track
Fn+FS	Stop	FS	Play/ Pause
Fn+F9	Mute	F9	Next track
Fn+F10	Volume up	F10	Mute
Fn+F11	Volume down	F12	Decrease Volume
Fn+F12	Lock Whole Keys	F12	Increase Volume
Fn+Win	Lock “ <b>Windows</b> ” Key	Fn+ Win	Lock “ <b>Windows</b> ” Key (for Mac)
Caps Lock	Caps Lock	Caps Lock	Caps Lock

### NOTES:





- You can also turn the **Right knob** clockwise to increase the volume, or counter-clockwise to decrease the volume.
- When the “**Windows**” Key is locked, the Win Key indicator will glow blue. When it is unlocked, the indicator will turn off.
- When the “**Caps Lock**” Key is locked, the Caps Lock indicator will glow blue. When it is unlocked, the indicator will turn off.
- Make sure the Operating System Switch is set to the right position. Some keyboard shortcuts may become invalid if the switch is on the wrong position.

## RGB Light Mode

In Bluetooth or USB mode, you can use the **Light Mode Switch** to set RGB **light for keyboard**. Pull the Light Mode Switch downwards to toggle between the 14 different light modes.

To adjust the brightness of the light effect, turn the Left knob clockwise (decrease the brightness) or counter-clockwise (increase the brightness).

## Keyboard Shortcuts for Light Adjustment

Switch Light Mode	Fn+Home (method: press and hold “ <b>Fn</b> ” key, and press the “ <b>Home</b> ” key.)
Light Effect On/ Off	Fn+Del
Increase Brightness	FN+ 
Decrease Brightness	FN+ 
Increase Light Speed	FN+ 
Decrease Light Speed	FN+ 
Restore Light Effect to Factory Setting under USB Mode	Fn+Esc

## NOTES

- Under constant light mode, the light speed cannot be adjusted; and under breathing light mode, the light

brightness cannot be adjusted.

- The light effects have 4 levels of speed and brightness.
- The keyboard will display the last used light effect the next time it is turned on.

## Specifications

Model NO./ Name	TWKBIOO / Wireless Backlit Screenwriter Keyboard
Compatible Devices	Phone/ Tablet/ PC
Operating System	iOS / Mac OS/ Windows / Android
Connectivity Technology	Bluetooth
Battery Type	Li-ion Polymer
Power Input	5V / 1 A
Power Consumption	1W
Battery Capacity	2000mAh
Charging Time	About 4.5 Hours
Working Time	8hours
Number of Keys	83 Keys
Bluetooth Range	33ft(10M)
Material	ABS
<b>Dimension</b>	13.1 x 7.0 x 1.9 " (332x 777 x 48mm)
Weight	25.4oz (720g)

## Safety Statement

### Safety Precautions

1. Avoid dropping and shocking.
2. Do not disassemble this device.
3. Do not expose this device to rain or moisture or submerge in water.
4. Ideal temperatures are 0°C to 35°C. Avoid extreme temperatures.
5. Keep the device away from excessive heat, such as sunshine, fire or the like.
6. Do not use the device outdoors during thunderstorms.
7. Use original or certified cables.
8. Keep out of reach of children. It contains small parts which may be a choking hazard.
9. Avoid environments subject to vibration, excessive dust, cold or moisture.
10. To prevent damage to your device's parts or internal circuits, do not use it in dusty, smoky, damp or dirty



environments.

11. Do not use, store or transport the device where flammables or explosives are stored. Using your device in these environments increases the risk of explosion or fire.

## FCC Statement

### FCC ID: 2AJVKTWKB100

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/ TV technician for help.

### FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

### Disclaimer

All information, design and specifications contained in this manual were correct at the time of this publication. As the product goes under continuous upgrades and changes, however, the final device may have slight differences. The contents of this manual are subject to change without prior notice, and Eklectik will not be liable for any errors contained herein or for incidental or consequential damages in connection with the furnishing performance or use of this manual.

Eklectik COPYRIGHT© 2022 ALL RIGHTS RESERVED.

## Eklectik One Year Limited Warranty

**WARRANTY** Eklectik LIMITED WARRANTY ("Warranty") – For product Categories Listed in Chart Below (as applicable, "Product") Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully. If you are still having trouble with your Product, please contact Technical Support at [support@EklectikTech.com](mailto:support@EklectikTech.com).

**Warning:** Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children.

Subject to the terms and conditions herein, Eklectik warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period for one year, to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, Eklectik will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable) either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/ or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping

charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and Eklectik's sole liability for breach of the limited warranty contained herein.

This Warranty specifically excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the product, any other Customer-induced damage, or the alteration or removal of any product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than Eklectik or a party authorized in writing by Eklectik; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection 17 to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions; or (g) any acts of God. Product is sold to Customer for personal, noncommercial use only. Product is not warranted for Customer's commercial or rental use.

In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. Eklectik disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product and agrees to indemnify Eklectik for any damages claimed against Eklectik for such uses. EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS", AND SUMMIT ELECTRONICS LLC DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY(I) OF MERCHANTABILITY, (II) OF FITNESS FOR A PARTICULAR PURPOSE, OR (III) OF NON-INFRINGEMENT OF THIRD-PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL EKLEKTIK BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF EKLEKTIK HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, EKLEKTIK'S AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCT CAUSING THE DAMAGES, IF ANY. This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. To obtain Warranty service, Customer must email Eklectik Technical Support prior to making a Product return. Customer must include with Product return the following items (failure to enclose any of these items may result in a delay in the processing of your Warranty claim): (i) a dated sales receipt that indicates the place of purchase, model number of Product, and amount paid; (ii) a detailed description of Customer's problem with Product; (iii) Customer's full name, phone number, and return address, and; (iv) a money order made out to Eklectik to cover return shipping charges to US destinations only Eklectik will not make return shipments to a P.O. Box. For shipping to international addresses, actual freight will be charged to Customer. Return your Product freight-prepaid in its original packaging, or packaging that affords an equal measure of protection. Please allow 4 to 6 weeks for the processing of your claim (6 to 8 weeks from November to February).



## Customer Support

Where to ship product  
Eklectik® Returns Department  
1 Rewe Street  
2nd floor  
New York, NY 11211

If you have any questions, please contact Eklectik® at [support@EklectikTech.com](mailto:support@EklectikTech.com) or visit <https://www.eklectiksound.com>.



## Documents / Resources

 <b>The Screenwriter</b> Wireless Backlit Keyboard (TWKB100) <small>Tastatur mit Hintergrundbeleuchtung (TWKB100)</small>  User Manual / Manual de usuario	<p><a href="#">eklectik TWKB100 Wireless Backlit Keyboard</a> [pdf] User Manual TWKB100 Wireless Backlit Keyboard, TWKB100, Wireless Backlit Keyboard, Backlit Keyboard, Keyboard</p>
---	---

## References

- [User Manual](#)