

## electriQ eiQ-M455DVA Atmos Google Android TV User Manual

Home » ElectriQ » electriQ eiQ-M455DVA Atmos Google Android TV User Manual

#### **Contents**

- 1 electriQ eiQ-M455DVA Atmos Google Android
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Documents / Resources



electriQ eiQ-M455DVA Atmos Google Android TV




The eiQ-M455DVA is a TV set that comes with a remote control. It is designed to provide an immersive entertainment experience with its high-quality display and advanced features.


#### **Product Usage Instructions**


Follow the instructions below to properly use the eiQ-M455DVA TV


- 1. **Installation of Legs:** Before using the TV, install the legs according to the provided installation instructions.
- 2. **Input / Output Terminals:** Familiarize yourself with the input and output terminals of the TV for connecting to external devices.
- 3. **Connecting to External Devices:** Connect the TV to external devices, such as gaming consoles or DVD players, using the appropriate cables and ports.
- 4. **Remote Control:** Use the provided remote control to navigate and control the TV's functions. Ensure that the remote control has two AAA batteries inserted.
- 5. Initial Setup: Follow the initial setup process as described in the user manual to configure network settings, create an account/sign in, set up channels, device preferences, date and time, timer, language, inputs, storage, home screen, retail mode, Chromecast, screen saver, energy saver, location, user and diagnostics, accessibility, about, Google Assistant, keyboard, remote and accessories, power, and Google Play.
- 6. **Picture and Sound Settings:** Adjust the picture and sound settings according to your preferences using the TV's menu options.
- 7. **Technical Specifications:** Refer to the technical specifications section in the user manual for detailed information about the TV's specifications.
- 8. **Troubleshooting:** If you encounter any issues with the TV, refer to the troubleshooting section in the user manual for possible solutions.
- 9. **Support:** In case you need further assistance or have any questions, contact the manufacturer's support team using the provided contact information.

Follow all safety information mentioned in the user manual to ensure safe usage of the TV. Take precautions to prevent damage to the TV, such as avoiding exposure to moisture, not removing the cover or back, and not placing heavy items on the cable. Properly position the TV to prevent it from falling and handle it with care when moving or lifting.










USB	N/A
Optical	Audio Receiver
RJ45	







 $\nabla/\Delta/\blacktriangleleft/\triangleright$ 


# Quickly set up your TV with your Android phone?


You can easily transfer your Android phone's Wi-Fi network and Google Account to your TV Continue


Skip




















































































Standard	The default mode, to make users experience high- quality images under normal light.		
Dynamic	Enhances the contrast, colour and clarity of the		
	screen to balance the colour.		
Vivid	Image colours more beautiful, more vivid picture.		
Energy Saving	Reduce screen brightness, improved contrast for		
	energy saving.		
	User-defined picture settings.		
	Contrast	Adjust image contrast.	
User	Brightness	Adjust image brightness.	
	Colour	Adjust image colour density.	
	Sharpness	Adjust the image edge sharpness.	



Cool	Produces a gentle blue-hued image.	
Normal	Produces a vivid image.	
Warm	Produces a red-hued image.	
User	Adjust choices individually	

Standard	Produces a balanced sound in all environments.		
Music	Preserves the original sound. Good for musical		
	programs.		
Movie	Enhances treble and bass for a rich sound experience.		
News	Enhanced voice.		
User	Select to customize picture settings.		
	Bass	Adjust the bass.	
	Treble	Adjust the treble.	
	Balance	Adjust the left and right channel output	
		balance.	







### electriQ eiQ-M455DVA Atmos Google Android TV [pdf] User Manual

eiQ-M455DVA Atmos Google Android TV, eiQ-M455DVA, Atmos Google Android TV, Google Android TV, Android TV, TV

Manuals+,