



electro-harmonix EHX Expression Pedal User Manual

[Home](#) » [electro-harmonix](#) » electro-harmonix EHX Expression Pedal User Manual 



Congratulations on your purchase of the EHX Expression pedal! Built to be both versatile and affordable, the EHX Expression pedal can control expression parameters on a wide array of products from various manufacturers as long as the product includes an expression jack. The TRS polarity switch provides the ability to change the connections to the TRS jack while a Reverse button and a Range knob allow the musician dial in the perfect expression sweep for their application.

Contents

1 CONTROLS, I/O JACKS

**2 WARRANTY
INFORMATION**

3 Documents / Resources

4 Related Posts

CONTROLS, I/O JACKS

TRS OUT Jack – Plug a 1/4" TRS cable into this jack. The other end of the cable should be connected to an expression input on the device you want to control. The EHX Expression pedal ships from the factory with a 1/4" TRS cable. Under most circumstances, a standard 1/4" TS instrument cable will not work. The cable must be TRS.

REV Button – Reverses the sweep direction of the expression pedal. The standard sweep direction is achieved when the REV button is set to its OUT position: as you move from heel to toe the expression pedal sweeps from minimum to maximum. Push the REV button to its IN position to reverse this behavior: sweep from maximum to minimum as you move from heel to toe.

RANGE Knob – Adjusts the minimum setting of the expression pedal. As you turn RANGE towards 0, the minimum sweep setting moves towards the fixed maximum setting. For the full range, set this knob to 10.

Internal Potentiometer Impedance: 10k Ω

If you should need to return your unit for service within the warranty period, please contact the appropriate office listed below. Customers outside the regions listed below, please contact EHX Customer Service for information on warranty repairs at info@ehx.com or +1-718-937-8300. USA and Canadian customers: please obtain a Return Authorization Number (RA#) from EHX Customer Service before returning your product. Include with your returned unit a written description of the problem as well as your name, address, telephone number, e-mail address, RA#, and a copy of your receipt clearly showing the purchase date.

Email: electroharmonixuk@virginmedia.com

