



electro-harmonix Memory Toy Analog Delay with Modulation User Manual

[Home](#) » [electro-harmonix](#) » electro-harmonix Memory Toy Analog Delay with Modulation User Manual 

Contents

- [1 electro-harmonix Memory Toy Analog Delay with Modulation](#)
- [2 Product Information](#)
- [3 Product Operating Instructions and Controls](#)
- [4 Product Warranty Information](#)
- [5 OPERATING INSTRUCTION and CONTROLS](#)
 - [5.1 WARRANTY INFORMATION](#)
- [6 FCC STATEMENT](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



electro-harmonix

electro-harmonix Memory Toy Analog Delay with Modulation



Product Information

MEMORY TOY

The Electro-Harmonix MEMORY TOY is a compact analog delay pedal that draws inspiration from the iconic 1970's Memory Man and Deluxe Memory Man. It is designed based on the Deluxe Memory Man analog circuit and features a modulation switch, allowing easy access to lush analog chorus effects. The MEMORY TOY is perfect for guitarists looking to add warm and vintage delay tones to their sound.

Power

The MEMORY TOY can be powered using a standard 9V DC power adapter (not included). Ensure the power adapter meets the required specifications (e.g., correct voltage, polarity, and current rating) mentioned in the user manual to avoid any damage to the pedal.

Product Operating Instructions and Controls

1. Connect your guitar to the INPUT jack of the MEMORY TOY.
2. Connect the AMP jack of the MEMORY TOY to your amplifier.
3. The MEMORY TOY can be used in combination with other effects devices. Feel free to experiment with different combinations to create your own unique sound.
4. Use the footswitch to toggle between effect and true bypass modes. In effect mode, the MEMORY TOY will

apply the analog delay and modulation effects to your signal. In true bypass mode, the pedal will pass your guitar signal without any alteration.

Product Warranty Information

For customers in the United States and Canada, Electro-Harmonix provides customer service through NEW SENSOR CORP. Contact them at:

- Electro-Harmonix c/o NEW SENSOR CORP.
- 47-50 33RD STREET LONG ISLAND CITY, NY 11101
- **Tel:** 718-937-8300
- **Email:** info@ehx.com

For customers in Europe, the warranty service is provided by JOHN WILLIAMS ELECTRO-HARMONIX UK. Reach out to them at:

- Electro-Harmonix UK
- 13 CWMDONKIN TERRACE
- SWANSEA SA2 0RQ UNITED KINGDOM
- **Tel:** +44 179 247 3258
- **Email:** electroharmonixuk@virginmedia.com

Please note that the warranty rights may vary depending on the laws of the jurisdiction in which the product was purchased.

+Congratulations on your purchase of the Electro-Harmonix MEMORY TOY...a compact analog delay that takes its heritage from our 1970's Memory Man and the legendary Deluxe Memory Man. Like the Memory Boy, the MEMORY TOY is based on the Deluxe Memory Man analog circuit. A modulation switch allows quick access to lush analog chorus.

OPERATING INSTRUCTION and CONTROLS

Connect your guitar to the INPUT jack of the MEMORY TOY and the AMP jack to your amplifier. The MEMORY TOY can be used in combination with other effects devices. Experiment with any combination to develop your own unique sound. The footswitch toggles between effect and true bypass modes.

- **DELAY:** Controls the delay time of your MEMORY TOY. The range of delay time is from 30ms to 550ms. Turn the delay time clockwise to increase the delay amount.
- **BLEND:** The BLEND control allows you to vary the mix of direct and delayed signals from 100% dry when set counter-clockwise to 100% wet at full clockwise.
- **FEEDBACK:** The FEEDBACK control increases the number of delay repeats or multiple echoes. At high settings the unit will begin to self-oscillate. Fairly high feedback with short delay settings produces a reverb type of effect.
- **MOD Switch:** When set to the ON position, the MOD switch will enable a slow modulation on the delay time similar to the chorus modulation of the Deluxe Memory Man. Set the MOD switch to the OFF position to disable all modulation.
- **INPUT JACK:** Connect the output of your instrument or another effects pedal to this jack. The input impedance

presented at the INPUT jack is 1 M .

- **AMP JACK:** Connect the AMP jack to your amplifier input or the input of another effects pedal.
- **STATUS LED and FOOTSWITCH:** When the STATUS LED is lit, the Memory Toy is in effect mode. When the LED is off, the Memory Toy is in true bypass mode. Use the FOOTSWITCH to toggle between the two modes.

WARRANTY INFORMATION

Please register online at <http://www.ehx.com/product-registration> or complete and return the enclosed warranty card within 10 days of purchase. Electro-Harmonix will repair or replace, at its discretion, a product that fails to operate due to defects in materials or workmanship for a period of one year from date of purchase. This applies only to original purchasers who have bought their product from an authorized Electro-Harmonix retailer. Repaired or replaced units will then be warranted for the unexpired portion of the original warranty term.

If you should need to return your unit for service within the warranty period, please contact the appropriate office listed below. For customers outside the regions listed below, please contact EHX Customer Service for information on warranty repairs at info@ehx.com or +1-718-937-8300. USA and Canadian customers: please obtain a Return Authorization Number (RA#) from EHX Customer Service before returning your product. Include with your returned unit: a written description of the problem as well as your name, address, telephone number, e-mail address, and RA#; and a copy of your receipt clearly showing the purchase date.

United States & Canada

- EHX CUSTOMER SERVICE
- ELECTRO-HARMONIX
- c/o NEW SENSOR CORP.
- 47-50 33RD STREET LONG ISLAND CITY, NY 11101
- **Tel:** 718-937-8300
- **Email:** info@ehx.com

Europe

- JOHN WILLIAMS
- ELECTRO-HARMONIX UK
- 13 CWMDONKIN TERRACE
- SWANSEA SA2 0RQ UNITED KINGDOM
- **Tel:** +44 179 247 3258
- **Email:** electroharmonixuk@virginmedia.com

This warranty gives a purchaser specific legal rights. A purchaser may have even greater rights depending upon the laws of the jurisdiction within which the product was purchased.

To hear demos on all EHX pedals visit us on the web at www.ehx.com

Email us at: info@ehx.com

FCC STATEMENT


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void the user’s authority to operate the equipment under FCC rules.

Documents / Resources

	electro-harmonix Memory Toy Analog Delay with Modulation [pdf] User Manual Memory Toy Analog Delay with Modulation, Memory Toy, Analog Delay with Modulation, Analog Delay, Delay
---	--

References

- [EH Electro-Harmonix](#)
- [EH Support - Electro-Harmonix](#)