



Electromate UR30 Universal Robots Robot Arm Owner's Manual

[Home](#) » [Electromate](#) » Electromate UR30 Universal Robots Robot Arm Owner's Manual 

Electromate UR30 Universal Robots Robot Arm Owner's Manual



Contents

- 1 Intro Promotion
- 2 Heavy Payload
- 3 More torque
- 4 Small footprint
- 5 Documents / Resources
 - 5.1 References
- 6 Related Posts

Intro Promotion

Get 3,000 \$/€ discount and 2x Core Training*

Pre-order the UR30 and get the training you need to succeed. Our 2-day instructor-led basic training will give you hands-on experience and teach you the basics you need to get started with our robots.

30-month UR warranty included

We are confident in the quality of our product and are committed to provide the best product experience possible. Therefore, we include a 30-month UR warranty as a part of the Intro Promotion.

Scan to read more and pre-order today.



*Intro Promotion is valid until December 31, 2023



Heavy Payload

Smaller. Faster. Stronger

Avoid injury or accidents caused by lifting heavy items and add speed to your process by automating with UR's newest collaborative robot.

More torque

Fast screw driving

The UR30's high torque joints and force torque sensor allow for straight, consistent screw driving even in areas difficult for humans to reach.

Small footprint

Consistent fit and finish

The UR30 takes up the same space as a human and can easily handle the repetitive speed required for sanding or deburring without the associated health risks.



Payload: 30 kg



Reach: 1300 mm



Footprint: Ø 245 mm



Weight: 63,5 kg



ELECTROMATE

Documents / Resources



[Electromate UR30 Universal Robots Robot Arm \[pdf\] Owner's Manual](#)

UR30 Universal Robots Robot Arm, UR30, Universal Robots Robot Arm, Robots Robot Arm, Robot Arm, Arm

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)