





# Electronics 91WsrRCHODL Wireless Foldable Portable Keyboard Mouse Combo User Manual

[Home](#) » [Electronics](#) » Electronics 91WsrRCHODL Wireless Foldable Portable Keyboard Mouse Combo User Manual 

Electronics 91WsrRCHODL Wireless Foldable Portable Keyboard Mouse Combo



## Contents

- [1 Package content](#)
- [2 System](#)
- [3 suggestions for Charging](#)
- [4 KF10 Keyboard](#)
- [5 User Instruction](#)
- [6 MF10 Mouse](#)
- [7 User Instruction](#)
- [8 Leather case holder](#)
- [9 THANKS](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)

## Package content



x 1



x 1



x 1



x 1



x 1


## System

Compatible with Win8, Win 10, Win 11, Mac OS, Android (no driver).

## suggestions for Charging

Considering the safety and battery life, please charge the mouse via the USB charging port, but not via the adaptor.

## KF10 Keyboard



### Details

1. Type-c charging port
2. BT pairing button
3. BT pairing indicator/charging indicator/ low battery indicator
4. BT1
5. BT2
6. BT3

## User Instruction

### 1. Connection Method

1. Unfold the keyboard and it will automatically turn on.
2. Short press Fn+A/S/D, correspondingly select BT channel 1 /2/3, the indicator light flashes blue twice.
3. Press and hold the " " connect button in the upper left corner for 3 seconds to enter the BT pairing state, the indicator light will flash in blue light slowly.
4. Turn on the BT of the device to search, the BT device name of keyboard is "Delux 5.1 ", then click to connect, and the indicator light will turn off after the connection is successful.
5. The factory default uses BT 1 channel.

### 2. Reconnection Method

Short press FN+A/S/D to switch to the corresponding BT device, and the indicator light flashes blue twice, indicating that the reconnection is successful.

### 3. Indicator Functions

1. Charging indicator: When charging, the indicator light in the upper left corner of keyboard is on red light,

and the light goes off when fully charged.

2. Low battery warning: When the battery is lower than 20%, the indicator light in the upper left corner of keyboard keeps flashing in blue light; when the battery is 0%, the keyboard will be turned off.
3. BT pairing indicator: When pairing with BT, the indicator light in the upper left corner of keyboard flashes in blue light slowly.
4. **Battery:**  
Built -in 90mAh rechargeable Li-ion battery, which can be fully charged in about 1.5 hour.
5. **Energy -saving Function:**  
Fold the keyboard, it can automatically power off; unfold the keyboard, it can automatically power on.
6. **Working Distance: <10 m**
7. **The functions of the FN key combination:**


10 S/ Android		Windows		Windows	
Fn +	Function	Fn + shift +	Function	Fn +	Function
~	Home Screen	~	Home	~	ESC
1	Search	1	Search	1	F1
2	Select All	2	Select All	2	F2
3	Copy	3	Copy	3	F3
4	Paste	4	Paste	4	F4
5	Cut	5	Cut	5	FS
6	Previous	6	Previous	6	F6
7	Pause/ Play	7	Pause/Play	7	F7
8	Next	8	Next	8	F8
9	Mute	9	Mute	9	F9
0	Volume –	0	Volume –	0	F10
–	Volume+	–	Volume+	–	FI 1
=	Lock Screen	=	Shutdown	=	FI 2

## MF10 Mouse

### Details

1. Left Button
2. Right Button

3. Touchpad
4. Side Button
5. Laser pointer
6. Indicator



There are two toggle switches at the bottom.

The left one is mode switch, in which the top one is presenter mode, and the bottom one is the mouse mode. The right one is the power switch, in which the top one is power on, and the bottom one is power off.

## User Instruction

### 1. Connection Method

BT Mode: Turn on the mouse and switch to the MOUSE MODE, hold down the side button for more than 35, the indicator beside the charging port will flash rapidly. Then search for the BT device to connect, when the indicator light stops flashing, the connection is complete and the mouse can be used normally.

**Note:** BT name: DELUX 5.0. Please use it in Windows Band above systems (Windows 7 does not support BT 5.0). If the device does not have BT function, you can buy a BT receiver to connect.

### 2. Reconnection Method

Turn on the mouse and switch to the MOUSE MODE, short press the side button to switch the 3 BT modes cyclically.

Channel 1 : the indicator light flashes red.

Channel 2: the indicator light flashes green.

Channel 3; the indicator light flashes blue.

The factory default is BT channel 1.

### 3. Low battery warning

When the battery is lower than 20%, the side indicator light of the mouse will keep flashing; when the battery is 0%, the mouse will be turned off.

### 4. Working distance <10m


### 5. Fixed DPI is 1600 in the MOUSE MODE,

### 6. Note

The laser of this product complies with Class II laser detection. When using the laser, should avoid laser

exposure to the eyes. Normally, it's safe, the human eye's b link reflex can protect the eyes from injury.

Function Introduction




Leather case holder

The Leather case holder support two angles: forward( 70°) and backward (52°) .

THANKS

Dear customer, thank you for purchasing DELUX : product. To better understand the product, please read this user manual carefully before using. Hope the product can bring enjoyable experience for you all.

Documents / Resources

	<a href="#">Electronics 91WsrRCHODL Wireless Foldable Portable Keyboard Mouse Combo</a> [pdf] User Manual 91WsrRCHODL Wireless Foldable Portable Keyboard Mouse Combo, 91WsrRCHODL, Wirele ss Foldable Portable Keyboard Mouse Combo, Foldable Portable Keyboard Mouse Combo, Po rtable Keyboard Mouse Combo, Keyboard Mouse Combo, Mouse Combo, Combo
---	--

References

- [User Manual](#)

Manuals+.