



ELEVOC Link Plus Headset User Manual

[Home](#) » [ELEVOC](#) » ELEVOC Link Plus Headset User Manual 



ELEVOC Link Plus Headset User Manua

Contents

1

Product Overview

2

What's in the box

3

How to use

4

How to connect

5

How to charge

6

Specifications

7

FAQ

8


FCC Compliance

9

Documents / Resources

10

Related Posts










1. Headband
2. Volume up
3. Volume down
4. Status LED
5. Mute / unmute
6. Multi-function button
7. Microphone
8. Type-C charging port
9. Charging Base
10. Dongle

What's in the box


- 1x Elevoc Link headset
- 1x Charging Base
- 1x User manual
- 1x Dongle
- 1x Type-C cable

How to use

Button	Action	Function
	 Press	Play / pause music
	 Press and hold (2sec)	Power on
	Press and hold (3sec)	Power off
	 Press	Answer call
	Press and hold (2sec)	Reject call
	Press	End call
	Press	End current call and answer incoming call
	Press twice	1. Put the current call on hold and answer an incoming call 2. Switch between two calls 3. Dial the most recent call you make
	Press and hold(2 sec)	Reject incoming coll, when on a coll
	Press	Volume up
	Press and hold (2sec)	Next track
	Press	Volume down
	Press and hold (2sec)	Previous track
	Press	Mute / unmute microphone

How to connect

1. Press and hold (2 sec) the multi-function button to turn on Elevoc Link.




2. Connect it to the computer through Elevoc Audio Adapter Dongle.



How to charge

1. Plug the supplied Type-C cable into an available USB port on your computer. The status LED on the headset will turn red to indicate the headset is charging.



2. Connect the base to a USB power adapter and charge the headset via the base.



Warning: charger output 5V 1A.

Specifications

- **Input:** 5V1A
- **Output:** 5V1A
- **Battery capacity:** 350mA
- **Operating range:** 10m
- **Bluetooth version:** 5.0
- **Frequency range:** 20hz-20Khz
- **Talk time:** 35hrs
- **Charging time:** 2hrs

FAQ

What devices are Elevoc Link headsets compatible with?

The Elevoc Link headset works with most Bluetooth enabled devices including phones, tablets, PCs, and more.

How do I connect the headset to my cellphone?

1. Make sure the headset is within 33 ft of your device with no obstacles in the way.
2. Long press the multi-function button until the indicator flashes red and blue (approx. 5 seconds).
3. Locate and select 'Elevoc Link' from the Bluetooth list of your device to complete the pairing.
4. When your headset is turned on and the Bluetooth is enabled on your device, there will be an automatic connection. If you have not used the headset with your device for more than 10 minutes, the headset will turn off automatically to conserve power. When you're ready to use the headset again, just switch it back on.

Tip: Make sure your Bluetooth driver has been updated prior to connecting. Should your headset fail to connect, we recommend using the Bluetooth adapter on your computer.

How do I connect the headset to my computer?

1. Press and hold the power button for about 5 seconds to turn on the headset. (When the headset has turned on, the blue light will flash once)
2. The red and blue lights will flash alternately, indicating that the headset is in pairing mode.
3. Open the Settings on your computer and select Devices (Bluetooth, printers, mouse)
4. Turn on Bluetooth on your computer and then click 'Add Bluetooth or other devices'
5. Select 'Bluetooth' and locate the device 'Elevoc Link'. Click 'Elevoc Link' to connect.
6. Go back to 'Settings', click 'System', click 'Sound' and then select Elevoc Link as the output and input device.
7. Confirm that the headset is connected by double checking whether 'Elevoc Link' appears in the computer's Bluetooth list

How do I reconnect the headset?

When 'Elevoc Link' is connected to your phone/device successfully, it will automatically reconnect to your phone/device every time you turn it on. If it cannot reconnect, double check the Bluetooth settings on your device.

How do I reset the headset/ clear any pairing records?

While the headset is powered on, long-press the volume + and the volume – button together for 5 seconds to clear any pairing records.

The indicator will flash blue and red alternately to confirm that the pairing records have been cleared. The 'Elevoc Link' will not reconnect to the previously connected devices again.

If you are experiencing any connection problems with the headset, we recommend following the above steps.

Is the microphone effective at cutting out background noise?

Absolutely! Customers who have had phone conversations while on a noisy train reported that 99.96% of the background noise was removed. No bells, passenger chatter, or station calls were heard during their conversation.

How do I mute the microphone?

Click the mute button to immediately disable sound. To un-mute yourself, press the mute button again. The mute function is only available when you are in a phone call. You may encounter some compatibility issues if you are using third-party PC applications.

Tip: If you have any issues with your headset, check the User Guide or contact the seller to get professional technical support and lifetime after sales service. (Go to Your Order—> Find the order ID in the list—> Click 'Connect with us')

How is the phone call sound quality?

For best sound quality, make sure your cellphone or other device has a strong signal, sufficient battery life, and is

in close proximity to the headset. Elevoc Link may be not compatible with some third-party applications. Get in touch with us to learn more.

How is the headset charged?

Elevoc Link is charged by a USB-C cable. The charging cable has been included in your package for your convenience. For optimal charge, ensure the cable is connected to a DC voltage of 5V and current of more than 1A. The headset indicator will turn red while it is charging and will turn off once it is fully charged.

What if the Elevoc Link is defective or it just doesn't meet my expectations?

We know you're going to love this product, but if you have any issues, or just have changed your mind, let us know! Your device is protected by a 12 month warranty and our support team is always available if you are unsatisfied for any reason.

Need more support, please contact us: brand@elevoc.com

FCC Compliance

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2A2EV-ELINK

IC ID

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.


IC: 27399-ELINK

The Bluetooth^ word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc.and any use of such marks by Elevoc Technology Co.,Ltd is under license. Other trademarks and trade names are those of their respective owners.

Elevoc Technology Co.,Ltd.
5 / F, Block 12B, Shenzhen Boy Tech-Eco Park, Nanshan Dist.,
Shenzhen, Guangdong, China
Elevoc Technology Co., Ltd. All rights reserved.



Documents / Resources

	<p>ELEVOC Link Plus Headset [pdf] User Manual Link Plus Headset, Link Plus, Headset</p>
---	---

Manuals+.