

Elgato MK2 Stream Deck Studio Controller User Guide

Home » elgato » Elgato MK2 Stream Deck Studio Controller User Guide 🖺



Contents

- 1 Elgato MK2 Stream Deck Studio Controller
- **2 Frequently Asked Questions**
- 3 Documents / Resources
 - 3.1 References
- **4 Related Posts**

elgato

Elgato MK2 Stream Deck Studio Controller



Product Specifications:

• Product Name: Stream Deck

Manufacturer: Elgato

· Compatibility: Windows, macOS

• Dimensions: [Insert dimensions here]

• Weight: [Insert weight here]

Step 1 – Connect Stream Deck

Download and install the Stream Deck app from here.

Step 2 - Launch and Customize

Launch the app to customize Stream Deck. Drag actions from the right panel and drop them onto your desired keys on the left.

Step 3 - Use Custom Icons

Configure your actions and personalize keys with custom icons. Use 72 x 72 pixels .jpg or .png files for best results.

Step 4 - Create Folders

Drag and hold one key over another to create a folder. Tap the back key to exit a folder and return to your main configuration.

Step 5 – Modify Keys

Right-click keys to Copy, Delete, or Reset them.

Step 6 - Use Stream Deck's Stand

Prop Stream Deck on the included stand and adjust the legs for optimum access.

Step 7 - Use Social Media Accounts

Instructions on how to use social media accounts with the Stream Deck

Step 1 – Connect Stream Deck

Connect Stream Deck directly to a USB port on your PC or Mac – do not use a USB hub.



Connect Stream Deck directly to a USB port on your PC or Mac – do not use a USB hub.

Step 2 - Download Stream Deck app

Download and install the Stream Deck app.




Download and install the Stream Deck app:

https://www.elgato.com/gaming/download

Step 3 – Launch and Customize Stream Deck


Launch the app to customize Stream Deck. Drag actions from the right panel and drop them onto your desired keys on the left.



- Launch the app to customize Stream Deck.
- Drag action from the right panel and drop them onto your desired keys on the left.

Step 4 – Use Custom Icons

Configure your actions and personalize keys with custom icons. Use 72 x 72 pixels jpg or png files to achieve best results.



- Configure your actions and personalize keys with custom icons.
- Use 72 x 72 pixels .jpg or .png files to achieve best results.


Step 5 – Create Folders

Drag and hold one key over another to create a folder.



Drag and hold one key over another to create a folder.


Tap the back key to exit a folder and return to your main configuration.



• Tap the back key to exit a folder and return to your main configuration.

Step 6 – Right-Click Keys to Modify

Right-click keys to copy, delete or reset them.



• Right-click keys to Copy, Delete, or Reset them.

Step 7 – Use Stream Deck's Stand

Prop Stream Deck on the included stand and adjust the leas for optimum access.



• Prop Stream Deck on the included stand and adjust the legs for optimum access.

Step 8 - Use Social Media Accounts

Enter your social media accounts to connect with your fans.



Frequently Asked Questions

Q: Can I use Stream Deck with Linux?

A: Stream Deck is compatible with Windows and macOS only. Linux is not officially supported.

Q: How do I reset Stream Deck to its default settings?

A: You can reset Stream Deck by right-clicking on the keys youwant to reset and selecting the 'Reset' option.

Q: What file formats are supported for custom icons?

A: Custom icons should be in .jpg or .png format and have dimensions of 72 x 72 pixels for best results.

Documents / Resources



Elgato MK2 Stream Deck Studio Controller [pdf] User Guide

10GBA99, Stream Deck MK2 Studio Controller, MK2 Studio Controller, MK2 Stream Deck Studio Controller, MK2, Stream Deck Studio Controller, Deck Studio Controller, Studio Controller, Controller

References

- © Downloads | Elgato
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.