



EloPOS Z30 Touch Screen and Computer Installation Guide

[Home](#) » [elo](#) » EloPOS Z30 Touch Screen and Computer Installation Guide 

Contents

- [1 EloPOS Z30 Touch Screen and Computer](#)
- [2 Contents](#)
- [3 I/O Connections](#)
- [4 Installation](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



EloPOS Z30 Touch Screen and Computer




Contents

- EloPOS Z30 (1)
- 150W DC Power Adapter and cables
- M3x5mm I/O cover security screw (1)
- Stand Mounting bracket and screw (1)
- Tie-wraps (2)


I/O Connections

I/O Connections




Installation


1. Remove the cable cover door to access the I/O connections.



2. Route the DC power cable through the hole in the bottom of the stand and connect it as shown. Connect other I/O cables as needed (see back page) Make sure all cables route through the plastic clip at the bottom.



3. Mount the system to a table (optional). Skip to Step 6 if not mounting to a table.




Secure the mounting bracket to the table using the appropriate screw type and length. Elo suggests M4 or #10 screw diameter.

4. Lower the system onto the bracket and slide it back ensuring the bracket engages the screws on the bottom side.



Documents / Resources



[elo EloPOS Z30 Touch Screen and Computer](#) [pdf] Installation Guide

EloPOS Z30, Touch Screen and Computer, EloPOS Z30 Touch Screen and Computer, Screen and Computer, Computer, Touch Screen

References

- [elo Touchscreens for Retail, Self-Order & POS | Elo® Official Website](#)
- [elo Touchscreens for Retail, Self-Order & POS | Elo® Official Website](#)