ember Mug 2 Temperature Control Smart User Guide

ember Mug 2 Temperature Control Smart

Contents

Let's get started

 To set up your Ember, download the latest version of the app.

Download on the App Store

GET IT ON Google Play

135°F
(57°C) Out of the box, Ember will keep your drink at 135°F (57°C).

Portable battery life varies by product. Enjoy all-day battery life by regularly placing mug on its included charging coaster.
Visit **ember.com/battery** for more information.

⏻ **Power button**

Power button

On – Press once

Off – Press and hold 2 seconds

Pair – Press and hold 5 seconds, light will blink blue.

Reset – Press and hold 7 seconds, light will blink yellow.

Indicator light

Indicator light

Reaching target temperature

Target temperature reached

Fully charged

Charging

Flat battery

Use caution when consuming hot beverages. Let them cool down before consuming.

Do not microwave Ember! Ember is an electronic device, which should never go in a microwave.

Ember is hand wash only. Please do not put Ember in the dishwasher.

Keep Ember out of reach of children when filled with hot beverages.

Dry it well. Water can cause damage to the charging coaster, so dry your mug before placing it there.

Contact with metal may cause damage to ceramic coating.

Customer Support

Questions? We're happy to help.

ember.com/help

support@ember.com

ember

Documents / Resources

	ember Mug 2 Temperature Control Smart [pdf] User Guide Mug 2 Temperature Control Smart, Mug 2, Temperature Control Smart, Control Smart

References

- **User Manual**