



Enabling Devices 1810 Busy Box Traffic Light User Guide


[Home](#) » [enabling devices](#) » Enabling Devices 1810 Busy Box Traffic Light User Guide 

Contents

- [1 Enabling Devices 1810 Busy Box Traffic Light](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Operation](#)
- [5 Troubleshooting](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



Enabling Devices 1810 Busy Box Traffic Light



Product Information

- **Product Name:** Busy Box Traffic Light #1810
- **Manufacturer:** Enabling Devices
- **Technical Support Contact:** 1-800-832-8697 (Monday through Friday, 9 a.m. to 5 p.m. EST)
- **Email:** customer_support@enablingdevices.com
- **Address:** 50 Broadway Hawthorne, NY 10532
- **Phone:** 914.747.3070
- **Fax:** 914.747.3480
- **Toll-Free:** 800.832.8697
- **Website:** www.enablingdevices.com

Product Usage Instructions

1. Ensure the Busy Box Traffic Light is properly connected to a power source.
2. Press the power button to turn on the traffic light.
3. The traffic light will cycle through the standard sequence of red, yellow, and green lights.
4. To change the sequence or timing of the lights, refer to the advanced settings in the user manual.
5. The Busy Box Traffic Light can be used as a visual cue for various activities or as a teaching tool for traffic safety.
6. To turn off the traffic light, press and hold the power button until the lights go off.
7. If you encounter any technical issues or need assistance, contact our Technical Support Department using the provided contact information.

Note: Please refer to the user manual for detailed instructions on advanced settings and troubleshooting.

Teach crossing skills! Teach crossing skills!

- This unique toy teaches the idea of stop, pause and go while providing a stimulating sensory experience. Touch the red light and music plays, the yellow light and the toy vibrates, and the green light and it makes a buzzing sound. Comes with wall-mounting accessories. It also provides a tactile and auditory experience and teaches color recognition. Wall-mounting accessories included.
- **Size:** 26"L x 10½"W.
- **Requires** 2 C Batteries.
- **Weight:** 4 lbs.

Operation

- The battery holder is located under the blue cover at the bottom of the unit. Remove this cover by turning the screws counterclockwise with a screwdriver. Next, remove the small Phillip's screw from the battery compartment and slide the cover off. Observing polarity, install two C batteries into the battery compartment. Alkaline batteries are required (Duracell or Energizer brands etc.). Do not use rechargeable or heavy-duty batteries because they supply lower voltage and the unit may not perform as well.
- Set the ON/OFF slide switch located on the back battery compartment to ON. Replace both the battery case cover and the blue cover. Snug down the screws, but do not over-tighten.

Troubleshooting

- **Problem:** The unit fails to operate, or operates inc correctly.
- **Action:** Make sure there are no obstacles or dirt tween the colored plates and the housing of the unit.

Care of Unit:

- The Busy Box Traffic Light can be wiped clean with any household multi-purpose cleaner and disinfectant.
- Do not submerge the unit, as it will damage the ele Do not submerge electrical components.
- Do not use abrasive cleaners, as they will scratch Do not use abrasive cleaners the surface of the unit.

For Technical Support:

- Call our Technical Service Department
- Monday through Friday, 9 a.m. to 5 p.m. (EST)
- 1-800-832-8697
- customer_support@enablingdevices.com
- 50 broadway
- Hawthorne, NY 10532
- Tel. 914.747.3070 / Fax 914.747.3480
- Toll-Free 800.832.8697
- www.enablingdevices.com

Documents / Resources

	<p>Enabling Devices 1810 Busy Box Traffic Light [pdf] User Guide 1810 Busy Box Traffic Light, 1810, Busy Box Traffic Light, Box Traffic Light, Traffic Light, Light</p>
---	---

References

- [enabing Products For People With Special Needs | Enabling Devices](#)

Manuals+,