

energeeks

**EG-CIP006 WiFi
Rotary IP Camera**



energeeks EG-CIP006 WiFi Rotary IP Camera Installation Guide

[Home](#) » [energeeks](#) » energeeks EG-CIP006 WiFi Rotary IP Camera Installation Guide 

Contents

- [1 energeeks EG-CIP006 WiFi Rotary IP Camera](#)
- [2 Introduction](#)
- [3 Warranty](#)
- [4 Expiration](#)
- [5 Specifications](#)
- [6 Box contents](#)
- [7 Descarga Nuestra App](#)
- [8 Additional information and documentation](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

energeeks

energies EG-CIP006 WiFi Rotary IP Camera



Introduction

Thank you for choosing Energeeks. We do everything possible to ensure that our devices meet the expectations of our customers and we hope that this is the case in your case... However, if you have any questions, suggestions, or opinions that you would like to send us, please contact us at support@energeeks.com and we will be happy to assist you. This is a quick installation guide. Please read this entire guide carefully before using our products. You can consult our entire range of products at www.energeeks.com We hope you enjoy your new device!

Warranty

Duration: The warranty period is 36 months, for users who do not carry out a professional or commercial activity with the product, in any other case the warranty period is 6 months.

Coverage: The warranty obliges the manufacturer ENERGEEKS IBERIA to repair or replace free of charge all components subject to verified manufacturing defects. It will be the responsibility of the ENERGEEKS IBERIA Assistance Service to carry out the repair or replacement in the shortest possible time, compatible with the internal commitments of the service.

The following are excluded from the warranty:

- Consumption materials.
- Damage to people, other living beings, and things caused by improper use, incorrect installation, modifications not approved by the manufacturer, incompetence or failure to comply with the rules contained in these instructions for use and operation.

Expiration

The guarantee will be extinguished if:

- The warranty period of 36/6 months counted from the date of sale is fulfilled.
- The instructions contained in this manual have not been observed.
- Improper or improper use of the product has been confirmed
- The equipment has been used outside the parameters defined in the product specifications and the order.
- The characteristics of the equipment have been manipulated or altered by unauthorized persons.

Environmental Protection

By the provisions of the European Directive 2012/19/EU on waste electrical and electronic equipment (WEEE) and its transposition into national legislation, this product should not be disposed of with household waste. If it is time to replace the product or any of its accessories or components, be sure to dispose of them through the collection system established in your area for this type of product. Separating waste from used products and packaging allows materials to be recycled and reused. The reuse of recycled materials helps avoid environmental pollution and reduces the demand for raw materials.

Specifications

- Power: USB-C 5v – 2A
- Wifi: Dual 2.4/5 Ghz
- Working temperature and humidity: 10°C – 40°C
- Resolution 4 Megapixels
- Viewing angle 100°
- Motion detection with AI human filter
- sound detection
- Recording to SD card: 128GB max.
- Night Vision: Color + IR LED, 10m Max.
- Two-way audio
- Certification: CE, RoHS

Box contents

- 1 x Ranger III Camera
- 1 x Power Cable
- 1 x 5v 2A Power Adapter
- 1 x Ceiling support
- 1 x Hardware Kit
- 1 x Installation Guide

Safety information

IMPORTANT: Carefully read and follow the instructions and warnings provided in this manual before using the product. Improper use may cause incorrect operation and/or damage to the product

Descarga Nuestra App

Download our Energeeks 3.0 app, available in the Apple Store and Google Play.



Sign up with your email and a password. Install your devices and enjoy!

Quick installation guide

Before starting...

Download the “Energeeks 3.0” application on your mobile phone, it is available on Google Play, the APP Store, and the APP Gallery. The application will request the necessary permissions for its proper functioning or for the devices to be installed. It is necessary to grant the requested permissions, otherwise the device may not work correctly or may not even complete the installation. Location permission is necessary when installing a device since the phone requests it to share data on the Wi-Fi network with the application. It is also used to set the date and time of the device.

Once the device is installed, you can disable location permission, although this will lead to the loss of location-based smart functions. Connect the phone to the Wi-Fi network where you want to install the camera.

- Open the Energeeks 3.0 app, tap the + sign at the top, and select “add device.”
- The application detects the camera automatically via Bluetooth, then press add.
- Enter the password for the Wi-Fi network and press next.
- The installation completes automatically, and the installed camera will be displayed. Click “Finish” and enjoy your new Energeeks camera.
- If the application does not detect the camera, make sure you have Bluetooth activated, press and hold the reset button on the camera for a few seconds, and start the installation again.

Additional information and documentation



Download the complete manual, technical sheet, or declaration of conformity using this QR code and select your device, or visit our website. Don't forget to visit our YouTube channel 'Energeeks Iberia' to discover our products, their operation, installation... and many ideas for use!



For any queries/get technical support:



More information: www.energeeks.com

Documents / Resources

References

- [!\[\]\(b1b781be830eb908d845c527ab08d5f8_img.jpg\) Tienda Domotica Online - Energeeks](#)
- [!\[\]\(2176a4ba510fa27404d783166e891577_img.jpg\) Tienda Domotica Online - Energeeks](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.