

ENFORCER SS-075CQ Emergency Push To Exit Buttons Installation Guide

Home » ENFORCER » ENFORCER SS-075CQ Emergency Push To Exit Buttons Installation Guide 🖺



Contents

- 1 ENFORCER SS-075CQ Emergency Push To Exit
- **Buttons**
- **2 Product Usage Instructions**
- 3 FAQs
- **4 PRODUCT INFORMATION**
- **5 Features**
- **6 CONTACT INFORMATION**
- 7 Documents / Resources
 - 7.1 References



ENFORCER SS-075CQ Emergency Push To Exit Buttons



Product Usage Instructions

Installation:

- 1. Visit the SECO-LARM website www.seco-larm.com for complete installation instructions.
- 2. Read the manual provided before beginning the installation process.
- 3. Identify the appropriate button model based on your requirements.
- 4. Connect the button to the power source using the screw terminals.
- 5. Mount the button securely in the desired location.

Operation:

To trigger the emergency or push-to-exit function, press the button firmly. The selected contact type (NO or NC) will be activated momentarily, depending on the model chosen.

Maintenance:

Regularly check the button for any signs of damage or wear. Clean the button surface as needed to ensure clear visibility of the labels.

FAQs

- Q: Can I change the label on the button?
 - A: Yes, the Emergency & Push-to-Exit, NO/NC Button SS-075C-PEQ comes with three labels for customization: Emergency, Push to Exit, and Press Para Exit.
- · Q: What is the contact rating for these buttons?
 - A: The contact rating varies depending on the model chosen. It is either 0.5A@12VDC or 1.0A@12VDC.
- Q: Are these buttons suitable for outdoor use?
 - A: It is recommended to check the product specifications and IP rating to determine if the buttons are suitable for outdoor installations.

PRODUCT INFORMATION

Emergency/Push-to-Exit Buttons

Please visit the SECO-LARM website <u>www.seco-larm.com</u> for complete installation instructions. Please read the manual before you begin the installation

Features

Emergency NO/NC Button

SS-075CQ

Features

- Large button has "Emergency" printed on the face
- NO or NC (selectable) momentary contact
- Contact rated 0.5A@12VDC
- Screw terminals
- Off-white
- Dimensions: 3"x15/16"x5/8" (76x23x15 mm)



Emergency N.O. Button

SS-075Q

Features

- Large button has "Emergency" printed on face
- N.O. (push-to-close) momentary contact
- Contact rated 0.5A@12VDC
- Screw terminals
- · Off-white
- Dimensions: 3"x15/16"x5/8" (76x23x15 mm)



Emergency & Push-to-Exit,

NO/NC Button

SS-075C-PEQ

Features

- Three labels included: choose between "Emergency", "Push to Exit", and "Presione Para Salir"
- NO or NC (selectable) momentary contact
- Contact rated 1.0A@12VDC
- Screw terminals
- Off-white
- Dimensions: 3"x15/16"x5/8" (76x23x15 mm)







CONTACT INFORMATION

- SECO-LARM® U.S.A., Inc.
- 16842 Millikan Avenue, Irvine, CA 92606
- Phone: 949-261-2999
- 800-662-0800 Fax: 949-261-7326

Website: <u>www.seco-larm.com</u>
Email: <u>sales@seco-larm.com</u>

Copyright © 2024 SECO-LARM U.S.A, Inc. All rights reserved. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. The SECO-LARM policy is one of continual development. For that reason, SECO-LARM reserves the right to Phone: change prices and specifications without notice. SECO-LARM is not responsible for misprints.

Documents / Resources



ENFORCER SS-075CQ Emergency Push To Exit Buttons [pdf] Installation Guide SS-075CQ, SS-075C, SS-075C-PEQ, SS-075CQ Emergency Push To Exit Buttons, SS-075CQ, Emergency Push To Exit Buttons, Exit Buttons, Buttons

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.