



ENKE V8S Mobile Computer Universal Live Sound Card User Manual

[Home](#) » [ENKE](#) » ENKE V8S Mobile Computer Universal Live Sound Card User Manual 



Mobile computer universal
LIVE SOUND CARD
User Manual



Reminder: Please read the manual carefully before use to avoid any noise or no sound caused by improper use.
Thank you for your cooperation!

Contents

1 PRECAUTIONS FOR USE AND COMMON PROBLEMS

2 Control panel introduction

3 Documents / Resources

4 Related Posts


PRECAUTIONS FOR USE AND COMMON PROBLEMS

1. Long press the power button for about 3 seconds, the sound card is turned on or off the power-on indicator light is blue, and the red light is displayed when charging, and will automatically turn off when it is full. Close;
2. When the sound is low or the sound quality is not good, it means that the battery is insufficient. Please charge it. Try not to charge the sound card during a live broadcast. When the current is unstable, it will cause current interference or noise to the sound card.
3. When using, all interfaces need to be fully plugged in. If the phone has a phone case, please remove the phone case, avoid the case against the plug, and turn the plug twice after connecting; if you use a condenser microphone with high sensitivity, the surrounding environment will be noisy. It may be recorded or howling, please adjust the volume of the microphone to reduce the sensitivity;
4. During the live broadcast, the volume of the live mobile phone must be turned off, otherwise, there will be heavy sound, the volume of the accompaniment mobile phone and computer must be turned on and the recording knob of the sound card turned on on on to the right. These are the volume heard by the audience and the recording and volume;
5. For live streaming or recording songs on a single mobile phone, the music volume is adjusted on the mobile phone, and the accompaniment of the music input can be adjusted on the sound card or the accompaniment device: when listening to the live broadcast effect, do not listen to the live broadcast on the mobile phone with the live broadcast mobile phone. When testing the live broadcast effect in the same area, there will be signal interference and whistling sound:
6. When the computer is broadcasting live or recording a song, first unplug the computer speaker. then turn off the power of the speaker. connect the sound card to the computer with the charging cable, first, check whether the driver is installed successfully (there will be a prompt in the lower right corner of the computer) to ensure that the computer recognizes the Sound card: It is not recommended to use speakers for live broadcast (please use monitor ears), because the sound from the speakers will be recorded by the microphone again, resulting in double sound.
7. Each time you broadcast or record a song, you should test whether the sound card and the device are connected. Click the sound effect of the sound card (such as applause and laughter), and the sound can be recorded or the audience can hear the sound, indicating that the sound card has been connected to the device, and you can rest assured of use.
8. The four-section earphone with a microphone is inserted into the earphone hole, and the three-section monitor earphone without a microphone is inserted into the earphone hole of the speaker. and the four-section earphone with microphone is not allowed to be inserted into the earphone speaker hole. which will cause sharp noises. Do not use it with the microphone at the same time. because the headset has its own microphone. which will cause double sound The headset should be adjusted from the minimum volume. LIMU lb iuu rnyn, mere will luwirty.
9. 9 Connect the Bluetooth accompaniment and turn on the Bluetooth of the mobile phone. Search for the device

and find “V8S” and click Connect. After the connection is successful, the Bluetooth indicator light on the display will be high, indicating that the Bluetooth has been connected.

The product battery is a built-in rechargeable lithium battery. Please do not disassemble and replace it by yourself. Use the correct method to charge the sound card. Do not place the sound card near a fire source or expose it to sunlight. The heating of the battery will destroy the safety device and may cause the battery to explode or burn.


Control panel introduction



THIS PRODUCT HAS BEEN INSPECTED TO MEET THE SPECIFIED QUALITY STANDARDS AND IS ALLOWED TO LEAVE THE FACTORY:


Reminder: Use the built-in recording studio effect for National K Songs (do not select other effects that will cover the sound card)

Sing it and record songs using the original sound mode (do not choose other modes, otherwise the sound card effect will be overwritten)




THE CONNECTION METHOD OF DUAL MOBILE PHONE LIVE BROADCAST:

Reminder: The background music can be played using Kugou, Kuwo, and QQ music. If you need accompaniment, you can search for accompaniment songs or download apps like Quanmin K Song and Sing Bar to sing.




THE CONNECTION METHOD OF MOBILE LIVE BROADCAST AND LAJMFUI ILK PaAAJMIJANIMLN I.

Reminder: The computer sound card must be turned on. After the computer recognizes the sound card, there will be a prompt in the lower right corner of the computer that the driver is installed successfully. (Notebook and desktop computers are connected in the same way)



THE CONNECTION METHOD OF THE COMPUTER LIVE BROADCAST: (COMPUTER DOWN AND ACCOMPANIMENT)

Reminder: Tho computer sound card must ho turned on. After the computer recognizes the sound card, there will be a prompt in the lower right corner of the computer that the driver is installed successfully. (The connection method of desktop compute notebook all-in-one is the same).



THE DEBUGGING METHOD OF COMPUTER ACCOMPANIMENT AND COMPUTER LIVE RECORDING:



After the sound card is connected to the computer and the computer has recognized the sound card:

1. Right-click the small speaker in the lower right corner of the computer to adjust the volume and turn on the playback device. If 'MVUS8 Audio' is displayed under the speaker and set as the default, the computer accompaniment is successfully installed or the sound card has been recognized by the computer;
2. Right-click the small speaker in the lower right corner of the computer to adjust the volume, and turn on the recording device. If 'MVUSB Audio' is displayed under the microphone and it is set as default, that is, the acoustic microphone is successfully installed or the sound card has been recognized by the computer;

WARRANTY REGULATIONS

1. This product can enjoy a free warranty and maintenance within one year from the date of purchase (with the

date indicated on the delivery note). If you have a failure during normal use, please contact our company for business. and you should show this form during the warranty.

2. Machine failures caused by the following reasons are not covered by the free warranty:

- A. Parts are damaged due to man-made reasons (visible physical damage. etc.).
- B. Parts damage and malfunctions caused by the customer's transportation.
- C. Computer virus infection causes the product to not work normally.
- D. Irresistible force: such as earthquake, thunder, lightning, fire, etc., natural disasters cause accidents (stolen, lost, etc.) and the equipment cannot work normally caused of force majeure.
- E. The product cannot be used normally due to the use of third-party software.
- F. Failure and damage caused by poor power supply environment or foreign matter that the machine cannot withstand entering the equipment.
- G. Product failure caused by self-disassembly and repair.

3. We are not responsible for other equipment failures directly or indirectly caused by product failures.

Please pay attention to keeping the warranty with this card.

WARRANTY CARD

Product number: _____
Product Series: _____
Where to buy/shop: _____
Purchase date: _____
Buy account: _____
Purchasers name: _____
Purchase order number: _____
contact number: _____
contact address: _____
E-mail: _____

CERTIFICATE OF CONFORMITY

Model: _____
Inspectors: _____
Date of manufacture: _____


This product has been inspected to meet the specified quality standards and is allowed to leave the factory.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

Documents / Resources

	<p>ENKE V8S Mobile Computer Universal Live Sound Card [pdf] User Manual V8S, 2A4JZ-V8S, 2A4JZV8S, V8S Mobile Computer Universal Live Sound Card, Mobile Computer Universal Live Sound Card</p>
---	--