



EPH Controls TRFPi2 Programmable RF Thermostat Instruction Manual

[Home](#) » [EPH CONTROLS](#) » EPH Controls TRFPi2 Programmable RF Thermostat Instruction Manual 

Contents

- [1 EPH Controls TRFPi2 Programmable RF Thermostat](#)
- [2 Installation Instructions](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)



EPH Controls TRFPi2 Programmable RF Thermostat



Installation Instructions

For use in normal environments.







CAUTION!

Installation and connection should only be carried out by a qualified person.

- Only qualified electricians or authorized service staff are permitted to open the thermostat.
- If the thermostat is used in a way not specified by the manufacturer, its safety may be impaired.
- Before setting the thermostat, it is necessary to complete all required settings described in the section.

This thermostat can be mounted in the following ways:

1. To a recessed conduit box
2. To a surface-mounted box
3. Directly mounted on the wall



EPH Controls Ireland

- technical@ephcontrols.com
- www.ephcontrols.com

- technical@ephcontrols.co.uk
- www.ephcontrols.co.uk

Documents / Resources

	EPH Controls TRFPi2 Programmable RF Thermostat [pdf] Instruction Manual TRFPi2 Programmable RF Thermostat, TRFPi2, Programmable RF Thermostat, RF Thermosta t, Thermostat
---	--

References

- [EPH Home Page - EPH Controls](#)
- [EPH Home Page - EPH Controls](#)
- [User Manual](#)