


EPIC OFFICE Boost Static Return Fixed Height Workstation Frame Instruction Manual

[Home](#) » [EPIC OFFICE](#) » EPIC OFFICE Boost Static Return Fixed Height Workstation Frame Instruction Manual




EPIC OFFICE Boost Static Return Fixed Height Workstation Frame




Contents

- [1 OVERVIEW](#)
- [2 Component parts](#)
- [3 Assembly Instructions](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

OVERVIEW



Component parts




NO.	Component Name	PCS
1	Bolt: M6x16	5
2	Leveling pads	2
3	Table feet	1
4	Column	1
5	Bolt: M6x12	4
6	Screw: ST4x20	13
7	Side brackets	1
8	Rubber pad	10
9	Top frame-1	1
10	Bolt: M6x10	3
11	Centre bracket	1
12	Center rails	2
13	Top frame-2	1
14	Hand bolts M6x10	2
15	Allen Wrench(4mm)	1
16	Cable tie	2

Assembly Instructions

Step 1


Loosen the pre-installed bolts and Adjust the length of the top frame to match the size of the tabletop.



Step 2


Inset the column to the top frame.

- First fix 2pcs screws M6x12 like C displayed
- And then tighten the pre-installed bolts like B displayed




Step 3

Install the table feet Screws 4 pcs M6x16, install the 4 leveling pads.




Step 4

Install the side bracket with Screws 2 pcs M6x12,




Step 5

Connect the return frame to the single workstation and fixed with 2 hand bolts. Fix the centre brackets with 2pcs screws M6x10.



Step 6

Mount the tabletop and fix it with 24 pcs screws ST4x20 Tighten the bolts on top frame to fix it.



furniture.com.au



EPIC OFFICE
furniture.com.au

Documents / Resources

	EPIC OFFICE Boost Static Return Fixed Height Workstation Frame [pdf] Instruction Manual Boost Static Return Fixed Height Workstation Frame, Boost Static, Return Fixed Height Workstation Frame, Height Workstation Frame, Workstation Frame
---	--