




EPOMAKER RT100 98 Key Layout or Hot Plug Wired or Wireless Mechanical Keyboard User Guide

[Home](#) » [EPOMAKER](#) » EPOMAKER RT100 98 Key Layout or Hot Plug Wired or Wireless Mechanical Keyboard User Guide 

EPOMAKER RT100 98 Key Layout or Hot Plug Wired or Wireless Mechanical Keyboard



98 Key Layout/Hot Plug Wired/Wireless Mechanical Keyboard

This Quick Guide is an introduction to the use and functions of EPOMAKER RT100
For in-depth guidance on customizing software functions, please refer to the manual in EPOMAKER RT100

MODEL: EPOMAKER RT100
SIZE: 397 x 147 x 29.5±1 mm
NKRO: YES
SYSTEM: Windows XP/VISTA/7/8/10,Mac
CONNECTION: USB-C, 2.4GHz Bluetooth 3.0, Bluetooth 5.0.
WEIGHT: 1350g
HOTSWAP: YES
KEYCAPS: PBT

LAYOUT: 97 keys


Key Combination	Win Function	Mac Function
FN + ESC	Press and hold for 3s to Restore factory settings	Press and hold for 3s to Restore factory settings
FN + F1	Brightness-	Brightness-
FN + F2	Brightness+	Brightness+
FN + F3	Win+tab	Ctrl+ ↑
FN + F4	win+E	Exhale siri
FN + F5	Mail	
FN + F6	Homepage	
FN + F7	Previous song	Previous song
FN + F8	Play/Pause	Play/Pause
FN + F9	Next song	Next song
FN + Q	Short press to switch Bluetooth 1, long press Bluetooth Q to pair	Short press to switch Bluetooth 1Long press Bluetooth Q to pair
FN + W	Short press to switch Bluetooth 2Long press Bluetooth W to pair	Short press to switch Bluetooth 2Long press Bluetooth W to pair

FN + E	Short press to switch Bluetooth 3Long press Bluetooth EW to pair	Short press to switch Bluetooth 3Long press Bluetooth EW to pair
FN + R	Short press to switch 2.4G, long press R To pair	Short press to switch 2.4G, long press R To pair
FN + WIN	Lock win key	Lock win key
FN + BackSpace	Query power (battery power is available in wireless mode)	Query power (battery power is available in wireless mode)

Contents

- 1 SWITCH PROMPT
- 2 KNOB MODE
- 3 WIRED OR WIRELESS
 - 3.1 2.4G PAIRING MODE
 - 3.2 PAIRING WIRED MODE
 - 3.3 MODE SWITCHING
- 4 KEYBOARD WAKE UP/SLEEP
- 5 Customer support
- 6 Documents / Resources
 - 6.1 References
- 7 Related Posts


SWITCH PROMPT



Power switch	OFF power off (wired connection)/ON power on (wireless mode)	OFF power off (wired connection)/ON power on (wireless mode)
Mode switch	Left mac mode/right win mode	Left mac mode/right win mode

Backlight Settings	Win Function	Mac Function
FN + ↑	Backlight Brightness+	Backlight Brightness +
FN + ↓	Backlight Brightness –	Backlight Brightness –
FN + ←	Backlight Effect Speed –	Backlight Effect Speed –
FN + →	Backlight Effect Speed+	Backlight Effect Speed +
FN + DEL	Main backlight effect switching	Main backlight effect switching
FN + PGUP	Toggle monochrome lights	Toggle monochrome lights
FN + PGDN	Battery Save Mode (all lights and TV display off)	Battery Save Mode (all lights and TV display off)

KNOB MODE



TURN CLOCKWISE

Reduce Volume



TURN COUNTER CLOCKWISE

Increase Volume



PRESS KNOB


Play/Pause



CUSTOM FUNCTIONS

You can also use the software to customize the knob functions

Pressing Fn + Del at the same time allows you to switch the RGB effect of



WIRED OR WIRELESS

Use the connection mode switch on the top of the keyboard.

OFF means to turn off the power supply. At this time, inserting the cable can realize Wired connection mode and timely charging.

ON means to turn on the power and enter the wireless working mode.

PAIRING BLUETOOTH

FN+Q/W/E Long Press for 3 seconds to pair Bluetooth device

FN+Q/W/E Short Press to switch to last paired device

Turn the keyboard power switch to ON to enable wireless connection mode.

Long press FN+Q/W/E to start pairing. When pairing, the indicator light flashes quickly. After pairing is successful, the indicator light stays on for a long time, followed by the Main backlight. If pairing fails within 30 seconds, the indicator light goes out and the Keyboard enters the sleep mode.

2.4GPAIRING MODE

Switch to 2.4G wireless connection mode

FN+R

Turn the keyboard power switch to ON, turn on the wireless connection mode, and long Press FN+R to turn on the 2.4G pairing mode. The indicator light will flash quickly, and Insert the receiver to start pairing. After the pairing is successful, the prompt light will Stay on and follow the light effect of the primary key area. If pairing fails within 30 seconds, The indicator light goes out and the keyboard enters the sleep mode.

PAIRING WIRED MODE



Turn the keyboard power switch to OFF to enter the wired connection mode, and use a USB-C wire to connect the keyboard to your device.

MODE SWITCHING

If you need to switch the system or change the connection device of the keyboard, please Adjust the top mode switch of the keyboard to the operating system corresponding to the Computer. The left side is Mac mode, and the right side is Win mode. Otherwise, some shortcut Keys may not work properly.

KEYBOARD WAKE UP/SLEEP

After the keyboard enters the sleep mode, press any key to wake the keyboard. If you are in Bluetooth/2.4G mode, the keyboard will automatically connect to a Bluetooth/2.4g device.



*Options

HOT PLUG SMART SCREEN: 1.33 inches

CONNECTION MODE: Type-c

DISPLAY CONTENT: time/date/week/power/current connection mode//volume/weather temperature/ CPU power consumption/health reminder.

DISPLAY PICTURE: You can choose to change the display picture through the driver. It supports the use of the driver's own drawing board module to make a GIF dynamic background image.

Customer support



Made in China

Manufacturer: Shenzhen Changyun Technology Co., Ltd.

Address: Seventh Floor, Kai Daer Building, No.168 Tongsha Road,
Xili Street, Nanshan District, Shenzhen, Guangdong, CN

Email: support@epomaker.com

Web: www.epomaker.com

EC REP

APEX CE SPECIALISTS LIMITED

Unit 3d North Point House, North Point Business Park,
New Mallow Road Cork, T23 AT2P, Ireland

Contact: Wells **Tel:** +353212066339

UK REP

APEX CE SPECIALISTS LIMITED

89 Princess Street, Manchester, M1 4HT, UK

Contact: Wells E-mail: info@apex-ce.com



EPOMAKER

Documents / Resources



[EPOMAKER RT100 98 Key Layout or Hot Plug Wired or Wireless Mechanical Keyboard \[pdf\] User Guide](#)

RT100, RT100 98 Key Layout or Hot Plug Wired or Wireless Mechanical Keyboard, 98 Key Layout or Hot Plug Wired or Wireless Mechanical Keyboard, Layout or Hot Plug Wired or Wireless Mechanical Keyboard, Wired or Wireless Mechanical Keyboard, Wireless Mechanical Keyboard, Mechanical Keyboard, Keyboard

References

-  [Epomaker – epomaker](http://epomaker.com)

