



# EPOMAKER RT100 Mechanical Gaming Keyboard User Guide

[Home](#) » [EPOMAKER](#) » EPOMAKER RT100 Mechanical Gaming Keyboard User Guide 

## Contents

- [1 EPOMAKER RT100 Mechanical Gaming Keyboard](#)
- [2 INSTRUCTION](#)
- [3 How to synchronize](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)



## EPOMAKER RT100 Mechanical Gaming Keyboard

EPOMAKER-RT100-Mechanical-Gaming-Keyboard-PRO

## INSTRUCTION

1. Make sure the RT100 is connected in wired mode (with cable), the mode switch is set to USB and Win/Mac is correctly selected.
2. Download the driver, install it. Then right-click and run the driver as administrator.
  - **a)** If the driver is in Chinese, you can change the language here: ①→②→ Choose English (Please select English or Chinese, not auto)
  - **b)** [EPOMAKER-RT100-Mechanical-Gaming-Keyboard-1](#)
  - **c)** If the mini-screen displays abnormally (such as displaying incorrect information, blurred image or stuck on the wrong language)
    1. Firmly push the mini display into the keyboard or adjust the angles slightly until the connection is correct.
    2. In the EPOMAKER driver, update the firmware in Support > Firmware > Upgrade.
    3. Make sure the RT100 is the only keyboard connected to the computer during the keyboard

upgrade. firmware.

4. The latest firmware version is V504-O led V505.

## How to synchronize

### How to synchronize time

(Screenshot credit: <https://www.youtube.com/watch?v=XJ9-drqI9tc>)

- a)

### How to synchronize CPU

(Screenshot credit: <https://www.youtube.com/watch?v=XJ9-drqI9tc>)

- a) Make sure to run the driver as administrator.
- b)

## How to sync TEMP


- a) **Tips:** This feature is only available on EPOMAKER\_setup\_1.2.69(WIN 20230609) or a superior version.  
You can contact our support team to get the latest version if it is not available on the Epomaker download page.
- b) Make sure you are running the driver as administrator and you are logged in.
- c) Sketchpad mode > Upload file > Enter your city name in English or Chinese (please use the same language as the software language setting).
- d) Click Send.

## How to customize gif/photo on mini TV.

- a) Sketchpad Menu > Select Image, select a gif and upload it;
- b) Then go to Sketchpad menu > Upload File, click once on the preview to check if the gif looks ok. After that click on "download gif". Wait for the progress bar to reach 100% and the download should be successful.
- c) Please do not use RT100 or computer while downloading gif and wait for the bar progress reaches 100%.
- d) For detailed demonstration, click here to watch the video on our YouTube channel from 0:38.

## Firmware

- a) If the keyboard is in wired mode and the screen is plugged in, the latest firmware version of your RT100 must be V504\_OLEDV505
  - b)
-

	<a href="#">EPOMAKER RT100 Mechanical Gaming Keyboard</a> [pdf] User Guide RT100 Mechanical Gaming Keyboard, RT100, Mechanical Gaming Keyboard, Gaming Keyboard, Keyboard
---	--

References

-  [EPOMAKER RT100 Driver](#)
- [User Manual](#)