



## EPOMAKER RT100 Mechanical Keyboard User Guide

[Home](#) » [EPOMAKER](#) » EPOMAKER RT100 Mechanical Keyboard User Guide 


### Contents

- [1 EPOMAKER RT100 Mechanical Keyboard User Guide](#)
- [2 98 Key Hot Swappable Wired Wireless Mechanical Keyboard](#)
  - [2.1 APEXCE SPECIALISTS LIMITED](#)
  - [2.2 APEX CE SPECIALISTS LIMITED](#)
  - [2.3 WIRED OR WIRELESS](#)
  - [2.4 PAIRING BLUETOOTH](#)
  - [2.5 Options](#)
- [3 Read More About This Manual & Download PDF:](#)
- [4 Documents / Resources](#)

### EPOMAKER RT100 Mechanical Keyboard User Guide



**98 Key Hot Swappable Wired Wireless Mechanical Keyboard**



This Quick Guide is an introduction to the use and functions of EPOMAKER RT100. For in-depth guidance on customizing software functions, please refer to the manual in EPOMAKER RT100.

**MODEL:** EPOMAKER RT100 **WEIGHT:** 1350g  
**SIZE:** 397 x 147 x 29.5±1 mm **HOTSWAP:** YES  
**NKRO:** YES **KEYCAPS:** PBT  
**SYSTEM:** Windows XP/VISTA/7/8/10, Mac **LAYOUT:** 97keys  
**CONNECTION:** USB-C, 2.4GHz Bluetooth 3.0, Bluetooth 5.0.



**Made in China**

**Manufacturer:** Shenzhen Changyun Technology Co., Ltd. Address: Seventh Floor, Kai Daer Building, No.168 Tongsha Road, Xiii Street, Nanshan District, Shenzhen, Guangdong, CN

**Email:** [support@epomaker.com](mailto:support@epomaker.com)

**Web:** [www.epomaker.com](http://www.epomaker.com).

#### **APEXCE SPECIALISTS LIMITED**

Unit 3d North Point House, North Point Business Park, New Mallow Road Cork, T23 AT2P, Ireland

**Contact:** Wells


**Tell:** +353212066339




#### **APEX CE SPECIALISTS LIMITED**

89 Princess Street, Manchester, M1 4HT, UK


**Contact:** Wells

**Email:** [info@apex-ce.com](mailto:info@apex-ce.com).

Key Combination	Win Function	Mac Function	Backlight Settings	Win Function	Mac Function
<b>FN + ESC</b>	Press and hold for 1s to restore factory settings	Press and hold for 1s to restore factory settings	<b>FN + ↑</b>	Backlight brightness +	Backlight brightness +
<b>FN + F1</b>	Brightness-	Brightness-	<b>FN + ↓</b>	Backlight brightness -	Backlight brightness -
<b>FN + F2</b>	Brightness+	Brightness+	<b>FN + ←</b>	Backlight Effect Speed -	Backlight Effect Speed -
<b>FN + F3</b>	Win+Tab	Ctrl + ⇧	<b>FN + →</b>	Backlight Effect Speed +	Backlight Effect Speed +
<b>FN + F4</b>	Win+D	Exhale air	<b>FN + DEL</b>	Main backlight effect switching	Main backlight effect switching
<b>FN + F5</b>	Win+L		<b>FN + PGUP</b>	Toggle monochrome lights	Toggle monochrome lights
<b>FN + F6</b>	Homepage		<b>FN + PGDN</b>	Turn the backlight off/on	Turn the backlight off/on
<b>FN + F7</b>	Previous song	Previous song	<b>KNOB MODE</b> 		
<b>FN + F8</b>	Play/Pause	Play/Pause			
<b>FN + F9</b>	Next song	Next song			
<b>FN + Q</b>	Short press to switch Bluetooth 2, long press Bluetooth 3 to pair	Short press to switch Bluetooth 2, long press Bluetooth 3 to pair			
<b>FN + W</b>	Short press to switch Bluetooth 2, long press Bluetooth 3 to pair	Short press to switch Bluetooth 2, long press Bluetooth 3 to pair			
<b>FN + E</b>	Short press to switch Bluetooth 2, long press Bluetooth 3 to pair	Short press to switch Bluetooth 2, long press Bluetooth 3 to pair			
<b>FN + R</b>	Short press to switch 2.4G, long press R to pair	Short press to switch 2.4G, long press R to pair			
<b>FN + WIN</b>	Lock win key	Lock win key			
<b>FN + BackSpace</b>	Spacebar (switch to mode as needed)	Spacebar (switch to mode as needed)			
<b>FN + BackSpace</b>	Spacebar (switch to mode as needed)	Spacebar (switch to mode as needed)			

<b>SWITCH PROMPT</b>	
<b>Power switch</b>	 <b>TURN COUNTER CLOCKWISE</b> Reduce Volume <b>TURN CLOCKWISE</b> Increase Volume
<b>Mode switch</b>	 <b>TURN COUNTER CLOCKWISE</b> Increase Volume <b>PRESS KNOB</b> Play/Pause <b>CUSTOM FUNCTIONS</b> You can also use the software to customize the knob functions.

Pressing **Fn + Del** at the same time allows you to switch the RGB effect of



## WIRED OR WIRELESS

Use the connection mode switch on the top of the keyboard. OFF means to turn off the power supply. At this time, inserting the cable can realize Wired connection mode and timely charging. ON means to turn on the power and enter the wireless working mode.

## PAIRING BLUETOOTH

**FN • 0/WtE** Long Press for 3 seconds to pair Bluetooth device

**FN • 0/WtE** Short Press to switch to last paired device

Turn the keyboard power switch to ON to enable wireless connection mode.

**Long press FN+Q/W/E** to start pairing. When pairing, the indicator light flashes quickly. After pairing is successful, the indicator light stays on for a long time, followed by the

Main backlight. If pairing fails within 30 seconds, the indicator light goes out and the Keyboard enters the sleep mode.

## 2.4G PAIRING MODE

Switch to 2.4G wireless connection mode FN+R.

Turn the keyboard power switch to ON, turn on the wireless connection mode, and long Press FN+R to turn on the 2.4G pairing mode. The indicator light will flash quickly, and Insert the receiver to start pairing. After the pairing is successful, the prompt light will Stay on and follow the light effect of the primary key area. If pairing fails within 30 seconds, The indicator light goes out and the keyboard enters the sleep mode.

## PAIRING WIRED MODE


Turn the keyboard power switch to OFF to enter the wired connection mode, and use a USB-C wire to connect the keyboard to your device.

## MODE SWITCHING

If you need to switch the system or change the connection device of the keyboard, please Adjust the top mode switch of the keyboard to the operating system corresponding to the Computer. The left side is Mac mode, and the right side is Win mode. Otherwise, some shortcut Keys may not work properly.

## KEYBOARD WAKE UP/SLEEP

After the keyboard enters the sleep mode, press any key to wake the keyboard. If you are in Bluetooth/2.4G mode, the keyboard will automatically connect to a Bluetooth/2.4g device.



## Options

**HOT PLUG SMART SCREEN:** 1.33inches

**CONNECTION MODE:** Type-c

**DISPLAY CONTENT:** time/date/week/power/current connection model/volume/weather temperature/  
**CPU power consumption/health reminder.**

**DISPLAY PICTURE:** You can choose to change the display picture through the driver. It supports the use of the driver's own drawing board module to make a GIF dynamic background image.

***Read More About This Manual & Download PDF:***

## **Documents / Resources**



[EPOMAKER RT100 Mechanical Keyboard](#) [pdf] User Guide  
2A5D2-RT100, 2A5D2RT100, rt100, RT100, Mechanical Keyboard, RT100 Mechanical Keyboa  
rd, Keyboard

[Manuals+.](#)